
User Manual

Specification

Model	Wcf021
Туре	Wireless Charger
Input	12VDC 0.5-2A
Wireless Charging Output	20W (4*5W)
Input Port	Type-c
Charge Efficiency	≥73%
Charging Distance	≤6mm
Product Size	mm
Material	ABS
Colour	Black

Packaging Attachments

Wireless Charger* 1 User Manual* 1 Cable * 1



Steps For Usage

1. Unfold the wireless charger, plug in the Type-c cable and connect with the power.



2. Place the wireless charging-enabled battery in the centre of the charging area to which it belongs to start charging.



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits

for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

– Consult the dealer or an experienced radio/TV technician for help.
To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body. Use only the supplied antenna.



