


REMOTE CONTROL



1. Press and hold to begin pairing manually
2. Play/ Pause
3. EQ sound effect mode button
4. Number Pad
5. Press to switch source mode
6. Mute button
7. Previous
8. Next
9. Volume +/-
10. Single Repeat (For USB card playing mode)
11. TWS button




PORTABLE BATTERY SPEAKER

User Manual ISB354B



Control Panel Function



- 1.LED Display
- 2.**Power / Volume Wheel** : Turn to power ON / OFF and adjust volume level
- 3.**Microphone Input**
- 4.**Aux in (3 . 5mm Input)**
- 5.TF card input
- 6.**USB Media Port**
- 7.**LIGHT / MODE** : Press to change audio source between Bluetooth , Aux in , USB. Press and hold to turn LED lights ON / OFF
- 8.**Previous** : Press to replay previous track(Press and hold for 10 seconds to turn voice prompts on/off).
- 9.**Play / Pause / Pair** : Press to play / pause a track, Press and hold for 3 seconds to manually pair to a Bluetooth device.
- 10.**Next / Tws** : Press to skip to next track .Press and hold for 3 seconds to enter Party Plus mode which will allow this speaker to pair with another ISB354 speaker for True Wireless stereo.
- 11.**DC Power Input** : Use to charge the internal battery and power the speaker
Charge time is approximately 4 hours
- 12.**Charging Status LED** : Solid red light when charging . When the unit is fully charged , the light will turn off .

SPECIFICATIONS

Power Output:	10W
Frequency Response for main speaker:	50Hz-20KHz
Power Supply:	DC5V

POWER SOURCE

- 1.Please charge the unit at least 4 hours before first time using.
2. Twist the dial clockwise/anticlockwise to switch on/off the unit.

CHARGE THE BATTERY

When the battery is charging, the CHARGE STATUS lights shows on the LED display is red. After the battery has fully charged, the light turns off.

1. Connect the USB charge cable to the DC5V interface of the speaker firmly.
2. When the battery is fully charged, please disconnect the USB charge cable from the speaker.
- 3.The speaker works normally when charging.

POWER/VOLUME

Twist the dial clockwise/anticlockwise to increase/decrease the volume.

PREVIOUS/NEXT BUTTON

Under playing status, press PREVIOUS/NEXT button to get back to a previous or next song.

Play / Pause / Pair

Press to play / pause a track. Press and hold for 3 seconds to manually pair to a Bluetooth device.

LIGHT / MODE

Long press to turn on/off light.

Lightly press to enter into playing mode selection(Bluetooth,FM Radio,AUX Input, USB).

AUX IN JACK

1. Connect an audio cable to the AUX IN JACK of the speaker and to the audio output socket on the external audio devices such as MP3 player, discman, etc,then select AUX by pressing the Source / LEDs button on the control panel .
- 2.Play from an external audio device.

MIC IN JACK

Plug in microphone directly for playing.

USB JACK

Insert USB card directly for playing.

Bluetooth:

Long press **Source / LEDs** button on control panel to select Bluetooth mode. Simultaneously open the Bluetooth setting on your phone, tablet or any other bluetooth enabled audio device and select "ISB354"(no need to match code), the unit and device will then connected via Bluetooth. Press the "NEXT SONG" and "PREVIOUS SONG" button on the control panel to select the song, press "PLAY/PAUSE" button to control the playing status.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.