

YICK SHUN ELEC. TOYS MFG FCC ID: J7IYS22-23-IMC-1

JOB #: 137H0

Yick Shun YS22-23-IMC-1

EXHIBIT #: 5A

WAVERUE SUPER THURSES TRANSCENES

How to operate your transette:

4. SPEAKER/MIC

5. SIGNAL CODE KEY


GRILLE

- Open battery compartment (fig.6) and snap in a 9-volt battery.
 Replace door firmly.
 - Turn the "DN OFF" switch downward (Fig.2) to "ON" level and adjust the volume control to normal listening level.
 - Press the "PUSH-TO-TALK" button on side (Fig.3) for transmitting, and speak in a normal voice level into the speaker microphone grille (Fig.4).
 - Release the "PUSH-TO-TALK" button (Fig.3) for receiving.
 - * Best transmission and reception are obtained when ANTENNA (Fig.1) is held in vertical position.
 - To send MORSE CODE signals, by pushing the "PUSH-TO-TALK" button (Fig.3), press the signal code key (Fig.5) and quickly release to send a - (dot) or hold key longer to send a - (dash).
 - You can practice MORSE CODE without transmitting to other units by pressing the code key and not push the "PUSH-TO-TALK" button.
 - · Flexible antenna for best transmission & reception

1. FLEXIBLE ANTENNA

2. POWER ON/OFF AND VOLUME CONTROL

3. PUSH- TO -TALK BUTTON



Caution:

- * Your transceiver set has been fully adjusted prior to shipment from the factory, and be sure not to touch the internal components other than replacing the battery.
- When the sound becomes weak, it is time to change the battery.
- \bullet After use, always return the ON/OFF VOLUME CONTROL Switch to the "OFF" position.
- Keep your set in dry and clean place.
- Take out batteries when Walkie Talkie are not in use.

YICK SHUN ELEC. TOYS MFG FCC ID : J7IYS22-23-IMC-1

JOB #: 137H0

EXHIBIT # : 513