

80mm

105mm

## V40071W USER MANUAL

### PRESENTATION CHARGING BOX



1. Power Button of charging box:
  - Press it to active LED indicating light to display the charging box' power Status
  - Press and hold to power OFF.
2. Charging box cover
3. Earbud dock
4. LED charge indicator of earbud
5. LED Indicating
  - Light for charging box' power status
  - Charging indicator of charging box
6. Type-C USB/ DC5V: Charging port on charging box

### BUTTONS ON EARBUDS

#### 1/ EARBUDS CONTROL

A. Power ON/OFF: Long press R/L earbud about 4~5 seconds to power ON/OFF.

B. Hands-free call

- 1) When in Bluetooth calls, short press any control button to answer/hand-up calls.
- 2) Press and hold any of the ear bud's control button for 2 seconds to decline the calling.

**Note:** Pay attention: long press over 2 seconds will power OFF.

- 3) Dial your latest number by quick press the left ear bud's control button 4 times (Redial the latest number).

C. Play music

- 1) Short press the key to PLAY/PAUSE.
- 2) Quick press the left ear bud's control button for 2 times for the previous song, quick press the right ear bud's control button for 2 times for the next song.



- 3) Quick press the left ear bud's control button for 3 times to reduce the phone's volume , quick press the right ear bud's control button for 3 times to increase the phone's volume.

- 4) When the earphones are in music mode, quick press the right ear bud's control button 4 times to wake up SIRI.

#### 2. EARBUDS INDICATOR

Working status indicator, charging indicator.

**Note:** When wear the earphones, please refer to the L, R logo on the earbuds, insert the left earbud to the left ear and the right earbud to the right ear .

R : for right ear / L : for left ear.



### ABOUT PAIRING

#### Pairing with both sides

- a. Just take out the two earbuds from the charging box, then the earbuds will power on automatically. Otherwise, long press control button to power ON.
- b. The two earpieces will enter into pairing mode automatically; there will be "Connected" sound after they paired successfully. During this period, no action is required.

#### Pairing earphone and your smartphone

Bluetooth activation on your device, select **V40071W** to connect.

There will be "Connected" sound after they paired successfully.

### CHARGING

There is reminding sound when battery is low, and the LED on the headset would flash in red at the same time. Insert the headset into charging box to start charge.

**Note:** the earphone would be forced to disconnect with paired Bluetooth device when charging.

#### Charging for charging box

- Connect the provided Type-C USB-USB charging cable to earbud with power supply to charging.
- Charging box' LED will Flashing when charging, and 4 LED ON when fully charged.
- After full charging, charging box can recharges the earbuds 2~3 times.

#### Charging for Ear buds

- Put ear buds into the charging box, it starts charging the ear buds.
- Earbud' Red LED on when charging, Light Off when fully charged.

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID:2A2EE-V40071W