

Safety Instructions

- 1、Do not exceed the maximum power rating 10A.
- 2、Do not live working, ensure safety.
- 3、Please note and check the wiring diagram, ensure wiring INPUT and OUTPUT, wrong wiring may cause a short circuit.
- 4、Keep away from Children, heat sources and water.
- 5、When the power outage, the time group may appear inaccurately, need to reconnect between device and mobile to calibrate time.

APP download operation

Scan below QR code to download AHome



IOS



Android

Bind device steps

AHome user register

1. Download AHome App.
2. Register a new account with your email.
3. Login with your account.

WiFi Configuration

1. Long press the button(pairing button) on the device until the LED indicator fast flash.
2. Turn on phone WiFi, open AHome application on your phone then click Nework icon - Click the Plus icon - Add device interface - Click setting icon in the right top. AHome will auto gain your WiFi, then enter Wifi password to configure WiFi.
3. After LED indicator fast flash stop, shows WiFi configuration succeed.

Safety wiring diagram



1. Screw off the screw with a screwdriver


2. Pry up the red cap



3. Wiring the INPUT cable L and N

4. Cover the red cap, tight up the screw

Wiring diagram



Switch Parameter

Model : WA088

Max current : 10A

Working voltage :
AC100V-240V50/60Hz


Power consumption: Static
Power< 0.5W

Working condition temp :
-20℃ —60℃

Material : PC+ABS

Switch Size

Size : 88*39*23mm




Please check below items before use the device:

Your smart phone or tablet connect a 2.4G WiFi.

Your system of Andriod mobile or tablet must be 4.0+ version.

Your iphone or ipad can download the app from APP store

Please check and turn off the MAC filter function from the wireless router.



Product Funtion Description

Touch button control

Select device you wish to control, then press the ON/OFF or icon name area to toggle between on and off state.

Multiterminal control

In the same WiFi, one mobile can control several devices, several mobiles can control one device.

Remote control

Toggle to turn on your mobile data, can achieve remote control the device.

Timing control

DIY add time group, device auto ON and OFF through time setting.

Voice control

Voice control by modify the device name, switch name and keyword.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This device must operate with a minimum distance of20 cm between the radiator and user body.