


Micro True Wireless Earbuds & Power Case

Instruction Manual E19



- | | |
|------------------------|----------------------------|
| 1. Multi Function Keys | 5. Power Case LED |
| 2. Charging Slots | 6. Power Case Power Switch |
| 3. LED Indicators | 7. Micro-USB Input |
| 4. Microphone | |

What's included:

- 2 x Micro TruWireless Earbuds
- 1 x Power Case
- 1 x USB to Micro-USB charging cable
- 1 x Instruction Manual

Tech Specifications

- Bluetooth version: 4.2
- Speaker driver diameter: 8mm
- Output power: 5mW
- Max output: 10mW
- Frequency response: 20Hz-20KHz
- Built-in 40mAh/3.7V lithium polymer battery in each Earbud

- Charging input: 5V/60mA
- Built in 500mAh/3.7V battery (power case)
- Charging input power case: 5V/400mA
- Playback time at max volume: up to 1 hour
- It takes 1.5-2 hours to charge the Earbuds from 0 to 100%
- It takes 1.5-2 hours to charge the power case from 0 to 100%

Instructions:

- Charging the Earbud Power Case:**
Using the provided charging cable, plug the Micro-USB end into the power case and the USB end into an AC wall adapter or a computer input port. When charging successfully the LED atop the case will light red. When the charging is complete the LED will turn blue (5).
- Charging the Earbuds:**
Place the Earbuds into the charging slots. Use the (6) power case power switch to turn on the power case. The LED's on the Earbuds should light red, if not; lightly press down on the Earbuds to secure in charging position. When the Earbuds are fully charged each will light up with a Blue LED. The LED will shut off after awhile to reduce power usage.
- Connecting Earbuds via Bluetooth:**
After the power case and the Earbuds have both been completely charged, remove the Earbuds from the case and switch the case to "OFF." To pair, press and hold both multi-function buttons on both Earbuds

simultaneously until they both flash red and blue. Follow the instructions on a Bluetooth enabled device and select "Micro TruWireless" from the list.

- Powering the Earbuds OFF:**
Press and hold (1) and the LED's will light red together and then will turn off the devices.

* (Upon connecting one Earbud follow the same steps as listed above, with only one earbud).

LED Indications:

- Earbuds in power case:
Red- Charging
Blue- Fully charged
- Earbuds out of power case:
Red- Turning ON, and OFF
Blue- ON, and in pairing mode (1 out of 2)
Flashing- Pairing Mode (1 out of 2)

Multi-Function Keys:

- Press and hold: ON/OFF
- Left Earbud: Play/Pause, Answer/End Call
- Right Earbud: Single press to play the next track

SAFETY PRECAUTIONS:

- WARNING-When using this product, basic precautions should always be followed, including the following:
- Read all the instructions before using the product.
 - Upon initial use or after a prolonged storage period, fully charge it once. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.

- To reduce the risk of injury, close supervision is necessary when the product is used near children.
- Do not expose the device to moisture.
- Use of a power supply or charger not recommended or sold by device manufacturer may result in a risk of fire or injury to persons.
- Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
- Do not use the device if damaged or modified.
- Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
- Do not expose a device to fire or excessive temperature. Exposure to fire or temperatures above 212°F may cause explosion.
- Having services performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
- Do not charge the device while using the device to charge another device. Do not charge the device for more than 4-6 hours and do not leave unattended.
- Switch off the device when not in use.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

MADE IN CHINA