




# MARK YOUR EXQUISITE LIFE

---


Portable  
Label Printer  
Instruction  
Manual




nzhen Dudian Technology Co., Ltd.



# PACKING LIST




1pc Printer



1pc USB-type-c



## PRODUCT OVERVIEW



## ① Power Button

- Press and hold for 2 seconds to turn on the printer.
- Press one time, the printer will print the last label.
- Press two times, the printer prints the device information.

## ② LED Indicator or Indicator

- Blue light flashing: Bluetooth is not connected.
- Blue light on: Bluetooth is connected.
- Red light flashing: low battery.
- Red light on: charging (Light will turn off when fully charged).



## ③ Paper bin cover Open Button

- Push the button up to open the paper bin cover.






## PREPARATION BEFORE PRINTING

- ① Press and hold the power button for 2 seconds to turn on the printer.




- ② Push the button up to open the paper bin cover.





- ③ Put the label paper up-side down into the paper bin.



- ④ Close the paper bin cover.



## Mobile phone Printing Instruction



- ① Download and install the "Clabel mini" APP.




Available on the  
**App Store**




GET IT ON  
**Google Play**

Design&Print App  
easy to download and use




② Enter the phone system settings and turn on Bluetooth.



③ And click the "Edit" button.






- ④ Click the icon in the upper right corner.



- ⑤ Click the Bluetooth name of the printer to connect. The bluetooth name can be get from the device information by pressing the power button two times.



⑥ Add the content that needs to be printed and click the "Print" button to print.

⑦ And click the "OK" button to wait for printing to be completed.



## Common Problem

Q: Why is there no content in printing?

A: Please put the label paper up-side down into the paper bin.

Q: Why will the last content be printed out when I press the power button one time?

A: If you don't want to use this function, please go to "My"> "My Device", and turn off the "Memory Print" function in the Clabel mini APP with the printer connected.

Q: What should I do if all the buttons of the printer are invalid?

A: There is a small hole beside the type-c interface at the bottom of the printer, you can force it to power off by pressing it lightly with a needle.

# Parameters

Model	CT520B
Printing Technology	Thermal
Resolution	203DPI
Printing Speed	50mm/s
Label Width	15mm
Effective Printing Width	12mm
Label Warehouse Diameter	45mm
Connectivity Technology	Bluetooth
Battery Capacity	1500mAh
Charging Interface	Type-c
Size	134*80*28mm
Weight	255g

**Shenzhen Dudian Technology Co., Ltd.**

Add.: Fanshen Industrial Building, District 71,  
Baoan District, Shenzhen

————— **Made in China** —————

## FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.