Warning

- Do NOT expose product to extreme temperatures, moisture or electric shock
- 2. Do NOT attempt to open the unit for any reason. Do NOT attempt to manipulate any electrical components in the unit.
- Do NOT attempt to use if internal components have been exposed to liquid.

Package includes

1x Wireless Headset2x Soft Silicone Gels1x Charging Cable6x Ear-hook

1x User Manual

90_{mm}

Specifications

Wireless version: V4.0

Support: HSP, HFP, A2DP, AVRCP Frequency range: 2.4GHz
Transmitting power: Class 2
Working distance: ≤ 10M
Charge time: ≤ 3Hours
Talk time: ≥ 19Hours
Playback time: ≥ 18 Hours

Standby time: 300-360Hours

Ultralight Wireless Headset User Manual


Thank you for purchasing Mini Ultralight Wireless Headset. We hope you enjoy it!



Get support: service@marnanas.com

1 2

Construction



How to Charge Wireless Headset

- 1. A rechargeable battery is built-in the Wireless Headset.
- 2. Please charge over 3 hours before first use.
- The red indicator light will be on when product is charging.After full charge, indicator light will change to blue.
- 4. Please pay attention to:
- *Only a 5V DC charger or computer USB cable can be used for charging device.*

How to Connect Wireless Headset

- 1. When power off,press "power" button for 5-10 seconds,until red and blue light flashing.
- 2. Turn on Wireless function in your cellphone or audio device, and search for Marnana to connected.

How to Use Wireless Headset

- 1. Press "+" button to increase volume, press and hold "+" button to next song.
- 2. Press"-" button to decrease volume, press and hold "-" button to last song.
- 3. Press "Power" button to answer or hang up a call.
- 4. Press "Power" button for few seconds until the indicator light is off to turn off.

Frequently Asked Questions

 Failure to connect to Wireless-enabled device can be caused by:

Other Wireless devices are in pairing or sync mode and are interfering with your connection. Please remove other devices from the vicinity or turn them off.

- Static or muffled sound can be caused by any of the following:
- 1. There are major Wireless obstructions between your device and the headphone.
- 2. The distance is beyond 10M.

3 4

FCC ID: 2APTY-ME01

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter