PIXEL WALL ART SPEAKER

Instruction Manual

Item Number: MU03040




Contents:

- 1(One) Wireless RGB Speaker 15.75in. x 15.75in. x 3.54in. (40cm x 40cm x 9cm)
- 1(One) USB-C Charging Cable 39.4in.(100cm)
- 1(One) Instruction Manual

Product Specification:

Speakers: 3W x 2
Frequency: 20Hz - 20kHz
Battery Capacity: 2000mAh
Play Time: 3-4 Hours
Charge Time: 3-4 Hours
Input: 5V---1A
RGB Lighting (4 light modes)
USB Cable rating 1.0A Max

FCC ID:2AYB6-MU03040



How To Use:

Please remove the protection film before use.

- Power on: Press the power key "▶" 2 second when it is off.
- Pairing: Activate the Bluetooth function on your phone within range and select "LED ART BT SPEAKER" from the list shown.
- Play/Pause: When it is playing, press the center key "¡∥" to pause, then press again to play.
- Volume up: Hold down ">+" to increase the volume.
- Volume down: Hold down "-₩" to decrease the volume.
- Previous song: Press the "---" once to play the previous song.
- Next song: Press the ">+" once to play the next song.
- Power off: When the speaker is on standby or operating, press and hold the speaker key """ 3 seconds to shut down the speaker.
- Bluetooth mode / FM mode: Long press "♥" to switch Bluetooth mode/FM mode.
- FM mode: Short press "▶" to search and store radio stations.
- LED mode: Short press "♥" switch to change 4 LED mode or turn off the LED.
- Charging: When charging in standby or shutdown mode, insert the TYPE-C end of
 the USB power cord provided in the attachment into the TYPE-C jack of the
 speaker, and connect the other end to the computer USB port or USB charger to
 start charging. The charging LED will light up in red, and the charging indicator light
 will turn off when fully charged.

Front

Hanging the Wall Art Speaker:

- There is a hook at the upper back section of the Wall Art Speaker. The hook can be used to suspend the Wall Art Speaker on a wall or vertical surface.
- Please ensure that the hanger used is securely attached to the wall and can sustain the weight of 6.17lbs (2.8kg) to avoid potential droppage and breakage of the speaker.



№ WARNING:

- Charge and operate only as indicated in this manual, as improper use may result in damage to the product or injury.
- \bullet To avoid risk of shock or injury, do not dismantle the device or insert any objects into the speaker.
- To avoid electronic interference and/or compatible conflicts, turn off the product in any facilities where posted notices instruct you to do so.
- \bullet Do not pull the speaker charging cable. Damage may result to the cable.
- Keep out of reach of children. This is not a toy.
- Avoid exposure to moisture, liquids, heat, flame and high voltage equipment.
- Retain these instructions as they contain important information.
- Do not short circuit the input terminals of the speaker
- Do not drop, place heavy weight or allow heavy impact to the speaker
- PCB of battery should not be crushed and twisted.
- Battery body should not be bended.
- Do not disassemble and Do not dispose of in fire

Tips: Please do not turn the volume knob to the maximum level to prevent hearing damage and to prolong the service life of the system.

RF warning statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two condiions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

-WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

-NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help."

^CAUTION: FOR YOUR SAFETY, the charging cable included with this item is intended for use with this product only.

Distributed By: 1616 Holdings, Inc 701 Market Street, Suite 200, Philadelphia,PA 19106 Made in China

Back



