

SARINA


DISCO

FLOATING LIGHT SHOW SPEAKER




User Manual

## Product Diagram



## Button Functions



1. Next Track/Volume Up: Press to play next track  
Hold to raise volume
2. Previous Track/Volume Down: Press to play previous track  
Hold to lower volume
3. Play/Pause: Press to pause and resume playback
4. Answering Phone Call: Press once to pause the track and  
answer incoming phone call  
Hold(2s) to reject incoming phone call
5. Lights: Press the button to cycle through 4 LED light modes
6. Power: Press and hold(3s) to turn the device on/off  
Double-Press to swap between FM radio and Bluetooth® modes

## Bluetooth® Connection

1. Long press the on/off button to turn on speaker. It will automatically enter Bluetooth pairing mode
2. Open Bluetooth® list of input device, select “SA-POSK” in the available devices
3. Speaker will chime when connection is successful

## FM Tuner

1. Double press the power button to switch to FM tuner mode
2. Use the +/- buttons to change between stations

## Specifications

Power: 3W  
Waterproof: IPX7  
Play Time: 5-6hrs  
Frequency Response: 100Hz ~ 20KHz  
Bluetooth® Version: 5.0  
Battery: 3.7V 1200MAH  
Speaker Size: 52mm  
Input: 5V 1A  
Product Size: 6.3 x 6.3 x 2.1in (162x162x55mm)  
BT ID: D059694  
FCC ID: 2AANZPOSK

## Troubleshooting

1. If the Speaker is not responding
  - Device turns itself off after a few hours of inactivity
  - Device may need to be charged
2. Bluetooth® Interference
  - Device has a Bluetooth® range of 16.5ft (5m) be sure your connected device is within range of speaker
3. Bluetooth® cannot connect
  - Be sure you’ve connected to the correct speaker. If not you may need to reboot the speaker
  - Check for other nearby Bluetooth® devices that have connected instead of the intended device

## Notice

- Speaker should be kept in a cool dry place when not in use. Keep away from extreme heat or cold sources
- Do not dismantle or repair the your speaker
- Do not drop device
- Be sure to dispose of speaker correctly. Battery may cause fire if not disposed of properly

## FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

SARINA

SARINA guarantees the quality of this product.  
For questions or comments, please feel free to contact us  
via email at support@dglusa.com

Distributed by DGL Group, Ltd, Edison NJ 08817  
www.dglusa.com