# ULTRA THIN TWO WAY RADIO

USER MANUAL

# Radio Body x1, Battery x1, Adaptor x1, Charging Cable x1, Belt Clip x1, Hand Strap x1, User Manual x1 ----(-(РП) ...

Basic Information

Including

# Basic Parameter

Dimension: 130x52x21 5mm

Weight: 80g

Storage Channel: 14CH

Operating Voltage: 3.3-4.2V DC

Operating Temperature: -10°C~-40°C

Microphone 2 PTT Key Breathing Light A Speaker 6 Antenna

Channel +

Side PTT Key

R Power On/Off

Channel

O Volume Key

Battery

MIC Jack Earphone Jack USB Charging Port

### Power On/Off Long press "Power On/Off" Key for 2 seconds to turn on/off the radio.



 Channel Selection Short press "Channel +" to increase the channel

Short press "Channel - " to decrease the channel number



### Push To Talk Press "PTT Key / Side PTT Key" to transmit. release to exit.



Long press "Channel - " for 1.5S, then monitor

function is activate, you can listen to the channel

you selected whether someone is talking, if there

Long press 1.5S

is no signal, you will hear the sound of rustling.

## Monitor Function

 Volume Adjust Toggle "Volume +" to increase the volume. toggle "Volume - " to decrease the volume. You will hear a beep sound when the volume is maximum or minumum.

Current Channel Broadcast

current channel.

Long press "Channel + " for 1.5S to know the

Volume Level: 0-7, you can set by programming software



Toggle

Compress 1.5S

exposure environment at operating duty factors of up to 50% and is authorized by the FCC for General Population use only. An appropriate warning lable is affixed to all units. In order to comply with RF exposure requirements, a

MODIFICATION OF THIS DEVICE TO RECEIVE CELLULAR RADIOTELEPHONE SERVICE SIGNALS IS PROHIBITED LINDER ECC RULES AND FEDERAL LAW

Note: 8-14 channels must not exceed 0.5 W.

minimum distance of 2.5 cm must be maintained when held-to-face, and body-worn operations are restricted to the approved original acessories (belt clip), a minimum distance of 0 cm. Do not use this device when antenna shows

4 462.6375 FRS <sup>51</sup> 467.6375 FRS 5 462.6625 FRS 12 467.6625 FRS 6 462.6875 FRS 13 467.6875 FRS 7 462.7125 FRS 14 467.7125 FRS

# After standby for 10S, the breathing light is activate. It will lighting each 5S.

### Scan Function

Breathing Light

Scan function is activate in No. 16 channel, stop to scan after exiting No.16 channel.

### IMPORTANT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determind by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the follwing measures:

- Regrient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to

operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. This radio complies with IEEE and ICNIRP exposure limits for General Population/Uncontrolled Environments RF

(2) This device must accept any interference received, including interference that may cause undesired operation.

after long-time use.

before use.

Make sure the product is completely dry

preparations.

Do not use chemical preparations such as

stain removers, alcohol, sprays or oil

. Use a non-woven fabric with neutral cleanser

product parts with a clean and dry lint-free

A Power off the product, and remove the battery

To guarantee optimal performance as well as a

long service life of the product, please follow the

. Do not puncture or scratch the product with

. Do not place the product in corrosive agents,

. Do not handle the radio by its antenna or

When not in use, keep the accessory lacks

· Clean up the dust and fine particles on the

cloth or a brush regularly.

external microphone directly.

covered with the protective caps.

Care and Cleaning

tips below.

hard objects.

solutions or water.

before cleaning.

to clean the keys, control knobs, and shell