

<h3>产品规格</h3> <p>型号: HTC NE11</p> <p><b>蓝牙</b> 范围: ≈10m 版本: 5.0</p> <p><b>喇叭</b> 直径: 14.2mm 阻抗: 16Ω</p> <p><b>耳机功率</b> 输入: 5V=40mA 电容容量: 40mAh 使用时间: ≈5小时 充电时间: ≈1.5小时</p> <p><b>充电仓功率</b> 输入: 5V=400mA 输出: 5V=80mA 电容容量: 400mAh 充电时间: ≈1.5小时 充电仓充电时, 能给耳机充电约3次</p> <p><b>快速入门指南</b> 使用前请阅读使用说明书 HTC NE11</p>	<h3>物品清单</h3> <p>快速入门指南</p> <p>充电仓</p> <p>2 耳机</p> <p>USB-C充电线</p> <p>挂绳</p>	<h3>部件</h3> <p>耳机指示灯</p> <p>多功能触摸键</p> <p>充电触点</p> <p>耳机喇叭</p>	<h3>取出耳机并配对</h3> <p>如果您要第一次使用耳机, 请将两个耳机从充电仓中取出, 其中一个耳机的LED灯将会交替闪烁白灯和蓝灯, 表示它们处于配对模式。</p> <p>注:</p> <ul style="list-style-type: none"> <li>如果耳机未与任何设备配对, 打开后会自动进入配对模式, 配对成功后, 您会听到两声滴响声。</li> <li>如果耳机之前已配对, 打开后会自动重新连接, 连接时您会听到滴响声。</li> </ul>																					
<h3>如何佩戴耳机</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>如何清除蓝牙配对历史记录</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>充电仓基本操作</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>开机和关机</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>																					
<h3>功能操作</h3> <ul style="list-style-type: none"> <li>暂停/播放: 轻触任一耳机一次</li> <li>音量加: 轻触右耳机二次</li> <li>音量减: 轻触右耳机二次</li> <li>上一曲: 轻触左耳机三次</li> <li>下一曲: 轻触右耳机三次</li> <li>触控功能: 轻触任一耳机一次</li> <li>通话功能: 按住任一耳机2秒</li> <li>启动语音助手: 按住任一耳机2秒</li> <li>注: 单击使用时, 按住已开启的耳机2秒, 均可激活语音助手</li> <li>触控模式: 有音乐模式功能: 按住任一耳机2秒并切歌</li> <li>注: 单击使用时, 无法切换游戏模式和音乐模式</li> <li>注: 出厂设置默认为音乐模式</li> <li>注: 通过声音指示灯来播放模式</li> </ul> <p><b>指示灯显示</b></p> <table border="1"> <thead> <tr> <th>耳机指示灯</th><th>状态</th></tr> </thead> <tbody> <tr> <td>白灯闪烁/交互灯闪烁</td><td>两个耳机: 开机 单耳机: 未配对</td></tr> <tr> <td>白灯亮</td><td>充电中</td></tr> <tr> <td>无灯</td><td>配对成功或充满电</td></tr> <tr> <td>充电仓显示屏</td><td>状态</td></tr> <tr> <td>白色图标</td><td>充电中</td></tr> <tr> <td>蓝色图标</td><td>充满电</td></tr> </tbody> </table> <p>注: 为了保护您的隐私并节省电量, 无任何操作时, 显示屏将在1秒后熄灭。</p>	耳机指示灯	状态	白灯闪烁/交互灯闪烁	两个耳机: 开机 单耳机: 未配对	白灯亮	充电中	无灯	配对成功或充满电	充电仓显示屏	状态	白色图标	充电中	蓝色图标	充满电	<h3>如何清除蓝牙配对历史记录</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>充电仓基本操作</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>多功能按键功能</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>							
耳机指示灯	状态																							
白灯闪烁/交互灯闪烁	两个耳机: 开机 单耳机: 未配对																							
白灯亮	充电中																							
无灯	配对成功或充满电																							
充电仓显示屏	状态																							
白色图标	充电中																							
蓝色图标	充满电																							
<h3>查找我的耳机</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>触屏壁纸切换</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>拍摄功能</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>产品中有害物质名称及含量</h3> <p>产品中有害物质的名称及含量</p> <table border="1"> <thead> <tr> <th>部件名称</th><th>邻苯二甲酸酯 (Phthalates)</th><th>多环芳烃 (PAHs)</th><th>多溴二噁英 (PBDEs)</th><th>多溴联苯 (PBBs)</th><th>多溴二噁英 (PBDEs)</th><th>多溴联苯 (PBBs)</th></tr> </thead> <tbody> <tr> <td>印刷电路组件</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td></tr> <tr> <td>外壳等小型结构件</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td></tr> </tbody> </table> <p>注: 邻苯二甲酸酯 (Phthalates) 的含量均在 0.1% 以下, 多环芳烃 (PAHs) 的含量均在 0.1% 以下, 多溴二噁英 (PBDEs) 的含量均在 0.1% 以下, 多溴联苯 (PBBs) 的含量均在 0.1% 以下。</p>	部件名称	邻苯二甲酸酯 (Phthalates)	多环芳烃 (PAHs)	多溴二噁英 (PBDEs)	多溴联苯 (PBBs)	多溴二噁英 (PBDEs)	多溴联苯 (PBBs)	印刷电路组件	○	○	○	○	○	○	外壳等小型结构件	○	○	○	○	○	○
部件名称	邻苯二甲酸酯 (Phthalates)	多环芳烃 (PAHs)	多溴二噁英 (PBDEs)	多溴联苯 (PBBs)	多溴二噁英 (PBDEs)	多溴联苯 (PBBs)																		
印刷电路组件	○	○	○	○	○	○																		
外壳等小型结构件	○	○	○	○	○	○																		
<h3>查找我的耳机</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>触屏壁纸切换</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>拍摄功能</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>产品中有害物质名称及含量</h3> <p>产品中有害物质的名称及含量</p> <table border="1"> <thead> <tr> <th>部件名称</th><th>邻苯二甲酸酯 (Phthalates)</th><th>多环芳烃 (PAHs)</th><th>多溴二噁英 (PBDEs)</th><th>多溴联苯 (PBBs)</th><th>多溴二噁英 (PBDEs)</th><th>多溴联苯 (PBBs)</th></tr> </thead> <tbody> <tr> <td>印刷电路组件</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td></tr> <tr> <td>外壳等小型结构件</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td></tr> </tbody> </table> <p>注: 邻苯二甲酸酯 (Phthalates) 的含量均在 0.1% 以下, 多环芳烃 (PAHs) 的含量均在 0.1% 以下, 多溴二噁英 (PBDEs) 的含量均在 0.1% 以下, 多溴联苯 (PBBs) 的含量均在 0.1% 以下。</p>	部件名称	邻苯二甲酸酯 (Phthalates)	多环芳烃 (PAHs)	多溴二噁英 (PBDEs)	多溴联苯 (PBBs)	多溴二噁英 (PBDEs)	多溴联苯 (PBBs)	印刷电路组件	○	○	○	○	○	○	外壳等小型结构件	○	○	○	○	○	○
部件名称	邻苯二甲酸酯 (Phthalates)	多环芳烃 (PAHs)	多溴二噁英 (PBDEs)	多溴联苯 (PBBs)	多溴二噁英 (PBDEs)	多溴联苯 (PBBs)																		
印刷电路组件	○	○	○	○	○	○																		
外壳等小型结构件	○	○	○	○	○	○																		
<h3>连接到蓝牙设备</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>基本操作</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>音量调节界面</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>屏幕亮度界面</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>																					
<h3>连接到蓝牙设备</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>基本操作</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>音量调节界面</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>屏幕亮度界面</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>																					
<h3>连接到蓝牙设备</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>基本操作</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>音量调节界面</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>屏幕亮度界面</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>																					
<h3>连接到蓝牙设备</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>基本操作</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>音量调节界面</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>屏幕亮度界面</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>																					
<h3>连接到蓝牙设备</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>基本操作</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>音量调节界面</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>	<h3>屏幕亮度界面</h3> <p>1</p> <p>2</p> <p>3</p> <p>4</p>																					

### Quick Start Guide HTC NE11

#### Product Specifications

Model: HTC NE11

##### Bluetooth

Range: ≈ 10 m  
Version: 6.0

##### Speaker

Diameter: 14.2 mm  
Impedance: 16 Ω

##### Earphone power

Input: 5 V/400 mA  
Battery capacity: 40 mAh  
Battery life: ≈ 5 hrs  
Charging time: ≈ 1.5 hrs

##### Charging case power

Input: 5 V/400 mA  
Output: 5 V/380 mA  
Battery capacity: 400 mAh  
Charging time: ≈ 1.5 hrs  
Earphone recharges: 3 charges (when case is fully charged)

#### What's in the box

#### Components

#### Take out and pair the earphones

If you're using the earphones for the first time, remove both from the charging case. The LED on one earphone will blink white and blue alternately, indicating that they are in pairing mode.

Note:

- If the earphones have not been paired with each other, they will automatically enter pairing mode when turned on. You'll hear two beeps when pairing is successful.
- If the earphones have been paired before, they will automatically reconnect to each other when turned on. You'll hear a beep when they connect.

#### How to put on the earphones

#### Power on and off

**Power on**  
Taking the earphones out of the charging case will automatically turn them on.  
To manually turn on each earphone, press and hold the touchpad for three seconds.

**Power off**  
Placing the earphones in the charging case will automatically turn them off.  
To manually turn off each earphone, press and hold the touchpad for five seconds.

Note: If the earphones are not paired with a Bluetooth device within three minutes after powering on, they will automatically power off. They will also power off after three minutes if the paired Bluetooth device moves out of the effective connection range and has not reconnected.

#### Connect to Bluetooth device

On your device, turn on Bluetooth and choose to connect to "HTC NE11".

#### Basic operations

#### Key functions

- Play/Pause: Tap either earphone once.
- Volume up: Tap the right earphone twice.
- Volume down: Tap the left earphone twice.
- Play previous track: Tap the left earphone three times.
- Play next track: Tap the right earphone three times.
- Answer/First call: Tap either earphone once.
- Reject call: Press and hold either earphone for two seconds.
- Activate voice assistant: Press and hold the left earphone for two seconds.

Note: When using a single earphone only, press and hold the active earphone for two seconds.

- Switch between Game and Music modes: Music mode is the default mode. Press and hold the right earphone for two seconds to switch between modes. (The louder notification sound indicates Game mode.)

Note: Mode switching is disabled when you're using a single earphone only.

Earphone LED	Status
Blinking white and blue	Both earphones: Powered on Single earphone: Unpaired
Solid white	Charging
Off	Paired or fully charged

Charging case display screen	Status
Single white icon	Case charging
Solid blue icon	Case fully charged

Note: The display screen turns off after 30 seconds of inactivity to protect privacy and save power.

#### How to reset the earphones

If the earphones fail to pair or reconnect to each other, reset them by tapping both earphones five times simultaneously. Note: Resetting the earphones will clear the Bluetooth pairing history.

#### Case Display Screen: Basic Operations

**Activate the Display Screen**  
Touch Activation: Tap the display area when screen is off.  
Button Activation: Single-click the multi-function button.

**Deactivate the Display Screen**  
Auto-Deactivation: Display turns off automatically after 30 seconds of inactivity.  
Manual Deactivation: Press the multi-function button once to turn off the display.

Note: Initial activation required for first-time use.  
Method 1: Charge the charging case via the Type-C port to activate and power on.  
Method 2: Press and hold the multi-function button for 8 seconds to power on.  
Tip: The product is preset in shutdown mode upon factory shipment. Initial activation is required before first use.

#### Multi-function Button Operations

Single-click: Turn the screen on/off.  
Triple-click: Pair the earphones.  
Triple-click again: Pair the charging case with the earphones. Press and hold for 2 seconds: Open the system menu ("Powered Off" or "Restart").  
Press and hold for 8 seconds: When powered off: Powered On.  
When powered on: Restore to factory settings.

#### Status Icons Guide

Icon	Status
Solid red	Earphones in case, not connected to phone
Solid white	Case connected to earphones, but earphones offline
Solid green	Case connected to earphones, earphones paired to phone
Solid blue	Earphones charging
Solid white	Earphones in use/Earphones fully charged
Solid blue	Earphones in use/Earphones fully charged
Solid white	Case charging
Solid white	Case in use/Case fully charged

#### Case Display Screen: Feature Overview

#### Volume adjustment

Volume down minimum music is 0  
Volume up maximum music is 16

#### Spatial sound

Movie Mode Music Mode Game Mode

#### Equalizer

Click icon: Switch Between Different Sound Effect

#### Light Level

Tap the left icon: Decrease screen brightness  
Tap the right icon: Increase screen brightness

#### Language switch

Click icon: Switch between languages of different countries/regions.

#### Kaleidoscope Menu

Swipe up to enter the Kaleidoscope menu interface. Swipe left or right to navigate between options and tap to select. (White sub-menus: Swipe right to return to the main menu; swipe down to fully exit the Kaleidoscope interface.)

#### Find My Earphone

① Tap L/R buttons: Displays Screen  
② Cancel: Exits the current function  
Start Displays Screen 1 and activates the beeping sound from the earphone speaker  
③ Click icon: Stops the beeping sound

#### Screen Lock switch

Click icon: Switches between lock screen wallpapers

#### TIKTOK Page Flipping and Like Function

After connecting the earphones to the mobile phone and entering TIKTOK, you can adjust the volume, switch to the previous video, switch to the next video, and give a like using the charging case. (For iOS devices, you need to enable AssistiveTouch in Settings > Accessibility > Touch > AssistiveTouch.)  
This function is only available for use with TIKTOK software.  
Other apps may not support it.  
2. This feature may have compatibility issues with certain phones, and some phones may not be able to use it. If this feature is unavailable, please disregard it.

Switch to the previous video Like the current video Switch to the next video

#### Camera Control

Requires Bluetooth connection to a compatible device (e.g., smartphone).  
1. Native camera exclusivity: Only works with the device's pre-installed camera application. Third-party photography apps are unsupported.  
2. Compatibility limitation: Third-party restrictions may occur on certain smartphone models.  
3. Non-functional handling: Disable this feature if inoperative on your device.

Open your phone's camera app and click the device button to take photos.

#### Translation

Click icon: Accesses translation mode

#### Important Safety Instructions

Carefully read all the safety instructions in this document before using the product.

##### General safety instructions

- Use the product with care and store it in a clean environment that is free from extreme temperature, pressure, and humidity. Make sure that the product is stored in a location where it cannot be bent or deformed.
- Repairs and replacements should only be performed by authorized after-sales service staff. Do not attempt to disassemble or replace any part of the product yourself to prevent injuries or damage to the device. Any unauthorized modification to the product voids the warranty.
- Only use the product in environments where Bluetooth transmission is permitted.

##### Personal safety instructions

- Do not use the product if it is obviously defective or exhibits abnormalities such as bulging or excessive heating.
- Do not use the product when performing high-risk tasks that require your full attention.
- For your hearing protection, do not listen at high volume for long periods.
- Keep the product and its packaging out of reach of children and pets to prevent accidents such as swallowing and choking.

#### Battery safety instructions

The product has a built-in rechargeable battery. Read the following instructions to ensure safe use and disposal.

- Keep the product away from prolonged exposure to heat sources such as open fires or direct sunlight.
- Only store the product in environments with ambient temperatures of 0°C to 35°C (32°F to 95°F).
- Do not use or store the product in dust-prone, smoke-prone, high-temperature, high-pressure, or highly humid environments.
- Keep the product dry and away from liquids or moisture.
- Only use an FCC or CCC-certified charger with an output voltage of 5 V A.D.C.
- Do not use the product while charging.
- Do not leave the product charging for longer than 8 hours.
- Dispose of the product responsibly according to your local waste management guidelines.

#### FCC ID: 2BHJR-NE11

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does