



W15

说明书成品尺寸：73X93mm 材质及工艺:80g 书写纸




W15真无线蓝牙耳机
使用说明书

包装清单



耳机X2 充电仓



USB-C充电线X1 说明书

温馨提示

1、除说明书有特殊标示的操作方式以外，请勿尝试拆卸或更换产品内的任何零件。

2、请勿将产品放入水或其他任何液体中，此产品非防水设计。

3、如果有任何液体不小心进入产品内时，请立即断开连接并移开此产品。

4、为避免触电，请在安装或卸载产品时，确保手上没有沾水。

5、请勿将此产品放置于热源附近或直接暴露在火源附近。

6、请勿将本产品放置在有强大电磁力的环境中，否则会导致产品故障。

耳机规格

蓝牙版本：V5.3
传输距离：约10米
音乐时间：约5小时
喇叭尺寸：φ13mm
充电时间：1.5小时
电池容量：30mAh
额定输入：5V⚡30mA

充电盒规格

电池容量：300mAh
充电时间：1.5小时
电池电压：3.7V
额定输入：5V⚡300mA
(所有技术信息以实际性能为准)


给耳机充电：

1.当耳机的电量过低时，耳机会播报低电提醒（声音提示：Battery low），每一分钟提醒一次直至耳机低电关机，此时请及时给耳机充电。

2.在充电电量充足的情况下，将双耳机放回耳机仓，耳机进入充电状态，耳机上的红色指示灯亮起，约1.5小时后充满，耳机上的红色指示灯熄灭。

给充电座充电

使用配套的USB-C充电线给本机进行充电，约1.5小时完成充电。



LED指示灯 Type-C

充电座充电指示灯：


指示灯说明	
USB-C充电线给充电座充电	充电座红色指示灯闪烁---充电中
	充电座无指示灯 ---充满电
耳机放回充电座充电时，充电座指示灯会提示电池电量	充电座白色指示灯长亮4秒后熄灭---充电座有电
	充电座白色指示灯闪烁4秒后熄灭---充电座低电

产品操作说明

①开机
方法一：耳机在充电盒时打开充电盒上盖，取出耳机自动开机
方法二：耳机在关机状态，长按左右耳机触摸按键2秒，耳机开机
(开机提示音：“power on”)
注：开机后，在未连接手机或未被使用超过5分钟的情况下，耳机会自动关机

②关机
方法一：放回充电盒，耳机进入充电状态，充满电后关机
方法二：耳机在开机状态，长按任意一边耳机触摸按键5秒，左右耳同时关机
(关机提示音：“power off”)


③配对
步骤一：开机后,左右耳自动互连后进入与手机配对状态(提示音：“pairing”)
步骤二：打开智能设备的蓝牙列表,搜索“W15”并连接(提示音：“connected”)



连接设备成功：
语音提示：“connected”

触摸操作


■ 常规模式



语音助手：三击任意耳机触摸键
音量加：单击右耳机触摸键
音量减：单击左耳机触摸键


触摸操作

■ 音乐模式



播放/暂停：长按任意耳机触摸键2秒(“嘟”声后释放)
上一曲：双击左耳机触摸键
下一曲：双击右耳机触摸键


■ 通话模式



接听来电：双击任意耳机触摸键
结束通话：双击任意耳机触摸键
拒接电话：长按任意耳机触摸键1.5秒


耳机LED指示灯：

开机	白灯长亮2秒
关机	红灯长亮2秒后熄灭
配对	一耳机白灯每5秒闪一下，一耳机红白灯快闪
连接成功	熄灯，停止红白灯快闪状态




W15
True Wireless Bluetooth Earphones
Instruction Manual

Packing list



Earphone x 2 Charging CaseX1



USB-C Charging CableX1 Manual

Tips

1、Except for the operation methods specifically marked in the manual,please do not try to disassemble or replace any parts in the earbuds.

2、Don't put the earbuds in the water or any others liquid.The earbuds are not waterproof.

3、If any liquid enters the product by accidentally,please disconnect and remove the connection immediately.

4、Please make sure that there is no water on your hands when installing or uninstalling the product to avoid electricshock.

5、Do not put the product near by the heat source or expose it to the fire source directly.

6、Do not put the product in the environment with strong electro magneticforce, otherwise it will cause product malfunction.

Earphones specifications

Bluetooth version：V5.3
Transmission distance：About 10m
Music time：About 5 hours
Driver size: φ 13 mm

Charging time：1.5 hours
Battery capacity：30mAh
Rated input：5V⚡30mA
FCC ID: 2BATA-W15

Charging case specifications

Battery capacity：300mAh
Charging time: 1.5 hours
Battery voltage: 3.7V
Rated input: 5V⚡300mA
(All technical information is subject to actual performance)


Charge the Earphones

1. When the battery of the earphones is too low, the earphones will broadcast a reminder of low battery every minute until the earphone shuts down (Voice prompt: "Battery low"), in this case please charge the earphone in time.

2. When the charging case has sufficient charge, put the earphones back into the charging case; the earphones will enter the charging state, the red light of the earphones will turn on. Then the earphones will be full charged about 1.5 hours later, and the red light of the earphone will turn off.

Charge the Charging Case

Use the included USB-C cable to charge the charging case, which will take about 1.5 hours to complete.



LED Indicator Type-C

LED Indicator of the charging case


LED Indicator	
Charging with USB-C cable	The charging case flashes red light---in charging
	The charging case red light off ---fully charged
When put the earphones back into the charging case, the charging case indicator will remind its battery	The charging case white light stays on for 4s and goes off ---sufficient charge
	The charging case white light flashes for 4s and goes off---out of charge

Operation Instructions

①Power on
Method 1: Take both earphones out of the charging case, it will be power on automatically.
Method 2: Long press the left and right earphones touch button for 2 seconds. (Voice prompt: "Power on")
Note: The earphones will shut down automatically when they are either not connected or not in use for 5 minutes.

②Power off
Method 1: Put both earphones back into the charging case, it will enter charging state and shut down automatically after fully charged.
Method 2: Long press either earphone touch button for 5 seconds, then both the left and right earphones will be turned off at the same time.(Voice prompt: "Power off")


③Pairing
Step 1: Take out both earphones from the charging case, the earphones will power on and enter pairing mode automatically.(Voice prompt: "Pairing")
Step 2: At this time turn on the Bluetooth function of your device and search for "W15". Then press "pair", the earphones will connect to your device successfully. (Voice prompt: "Connected")



Connection succeeded:
Voice prompt: "connected"


Touch operation

■ General mode




Voice assistant: Triple click any earphone touch button
Volume up: Single click the right earphone touch button
Volume down: Single click the left earphone touch button

■ Music



Play/Pause: Press and hold any earphone touch button 2 seconds until you hear "du" and release
Last song: Double click left earphone touch button
Next song: Double click right earphone touch button

■ Call mode



Answer a call: Double click any earphone touch button
End a call: Double click any earphone touch button
Reject a call: Press and hold any earphone touch button for 1.5 seconds

LED Indicator of the Earphones

Power On	The white light stays on for 2 seconds
Power Off	The red light stays on for 2 seconds and then goes off
Pairing	The White LED flashes per 5 seconds, The "Red and White" LED flashes quickly
Connected	LED turn off

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter
The device has been evaluated to meet general RF exposure requirement.

PDF
Adobe