3-IN-1 **WIRELESS** Raise the stand to charge. **TRAVEL CHARGER** Charge your phone, watch, and earbuds with this 3-in-1 charger. USB-C Port Phone Charger Watch Charging Stand Charging Indicator Earbud Case Charging Base

OUICK TIPS:

- Double check your alignment be sure to center the device on the charging surface to ensure the most efficient and fastest charge times.
- Certain materials and thicker phone cases can interfere with wireless charging.
- · Not all devices are compatible with wireless charging, please check the devices user manual for compatibility information.
- This is a high speed 3-in-1 charger, please use the USB-C cable and power delivery wall plug that was included; using different items may cause slower charging.

WHATS INCLUDED:

- 3-IN-1 Wireless Charger
- USB-C to USB-C Charging Cable
- · Power Delivery Wall Plug

LED INDICATOR GUIDE:

- Solid Red Charging your device.
- O Solid White Fully charged.
- Flashing Red Foreign object detection, metal or other materials that may cause overheating and damage the charger, or the device your charging, remove them immediately.

HOW TO CHARGE:

- · Place the charger on a flat, sturdy surface.
- Plug the wall plug into an outlet, and the USB-C cable into both the wall plug and 3-in-1 charger. If you need to use a different power source be sure it is a USB power supply of DC9V 3A minimum. warning: please use a UL compliant power supply.
- Place your device on the correct charging surface making sure the device is centered on the charging surface or the device will not charge.
- note: The phone charging stand will charge all Qi-enabled devices. Remove anything with a magnetic strip, like credit cards, to prevent damage before charging.
- The phone charging stand allows for wireless charging up to 10W; the watch charging stand and earbud case charger allow for wireless charging up to 5W. The watch charging stand can be used flat or as a raised stand.
- Remove the phone from the phone charging stand before changing the orientation of the phone.
- Charge time will vary by device.

TROUBLESHOOTING:

- Double check the connections between the USB-C cable and wall plug, ensuring they are fully plugged in.
- Some phone cases may cause interference with wireless charging; remove the case for best
- Make sure the device is centered on the wireless charger.
- The wireless charging is compatible with newer devices as well as other Qi-enabled devices; consult your devices user quide to ensure compatibility.
- When using the earbud case charging base the device may still charge even when not fully centered, if the indicator light is red the device is being charged.
- If the indicator light flashes red while switching the phone orientation on the phone charging stand, remove the phone and recenter it in the preferred position.

SAFETY:

- Do not modify or repair this device.
- Do not use in high temperatures or extreme weather.
- Do not use chemical detergents to clean your device, use a soft dry cloth.
- Immediately unplug it from its power source if it gets wet.
- Keep the charger away from heat and direct sunlight.
- Remove credit cards and other cards with magnetic strips to prevent damage to the cards.

SAVE THESE INSTRUCTIONS

FCC ID: 2AO23-ASWC93 Model: ASWC93 Input: 5.0V=5.0A / 9.0V=3.0A Phone Charging Stand Output: 10W Max Watch Charging Stand Output: 2.5W Max Earbud Case Charging Base Output: 5W Max Made in Vietnam

This device complies with part 15 of the ECC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) this This service compares multiple 1.20 in the rounties, operation is subject to the reliability of containing. If I his device may not cause narmul interference, and 21 this device must accept any interference reliability in interference that may cause undested operation. Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are design provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, installed and useful on accordance with the instructions, may cause harmful interference to radio communication.

ever, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, in can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna
- Neorient or repocate the receiving anteriris.
 Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

8725 COLUMBINE RD EDEN PRAIRIE MN 55344-6695 PO Box # 44895 Distributed by ZSOU.

For qualified repair specialists requesting repair information and parts please contact the original manufacturer at support@zsoupc

FRONT

BACK