





## Conformité FCC (Écrit en anglais)

Rules. These limits are designed to provide

reasonable protection against harmful

interference in a residential installation.

This equipment generates uses and can

radiate radio frequency energy and, if not

installed and used in accordance with the

instructions, may cause harmful interference

no augrantee that interference will not occur

in a particular installation. If this equipment

television reception, which can be determined

is encouraged to try to correct the interference

by turning the equipment off and on, the user

by one or more of the following measures:

does cause harmful interference to radio or

to radio communications. However, there is

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC

FOLD

2. Increase the separation between the 3. Connect the equipment into an outlet on a circuit different from that to which the

1. Reorient or relocate the receiving antenna.

- receiver is connected.
- 4. Consult the dealer or an experienced radio/TV technician for help.
- 5. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received. including interference that may cause undesired operation.
- 6. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Conformité IC

exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes :

- (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences y compris celles susceptibles de provoquer un
  - fonctionnement indésirable de l'appareil. La distance entre l'utilisateur et les produits ne doit pas être inférieure à 20 cm.

## Avis

FOLD

Utilisez uniquement la commande fournie ou spécifiée par ces instructions pour contrôler cette lampe. Cette lampe ne fonctionnera pas correctement si elle est connectée à un gradateur (à incandescence) standard ou à une commande de gradation.

FOLD **FOLD FOLD** FOLD FOLD FOLD FOLD **FOLD** FOLD FOLD