

**X3**

**User Guide**

**Contents**

**1**



<b>I. CAUTIONS ON MOBILE PHONE USE.....</b>	<b>3</b>
1.1 INTERFERENCE.....	3
1.2 REASONABLE USE.....	4
1.3 QUALIFIED MAINTENANCE SERVICE.....	4
1.4 WATER-RESISTANCE.....	4
1.5 EMERGENCY CALLS.....	4
<b>2 PRECAUTIONS FOR USE OF BATTERY.....</b>	<b>4</b>
<b>3 CAUTIONS FOR CHILDREN.....</b>	<b>4</b>
<b>II. KEYS AND PARTS.....</b>	<b>5</b>
<b>III. START TO USE.....</b>	<b>6</b>
3.1 TO INSERT SIM CARD(S):.....	6
3.2 CHARGE THE BATTERY.....	8
<b>IV. BASIC FUNCTIONS.....</b>	<b>8</b>
1. LOCK AND UNLOCK THE SCREEN.....	8
2. MAKE IT YOURS.....	9
3. SWITCH TO RECENTLY USED APPLICATION.....	16
4. MAKE A CALL.....	17
5. CALL LOG.....	18
6. ANSWERING PHONE CALLS AND REJECTION.....	19
7. ADD A CONTACT.....	20

<b>8. SEND AND RECEIVE MESSAGE(S).....</b>	<b>21</b>
<b>9. BROWSER THE WEB.....</b>	<b>23</b>
<b>10. ENJOY MUSIC.....</b>	<b>23</b>
<b>11. DOWNLOAD APPLICATIONS FROM PLAY STORE.....</b>	<b>25</b>
<b>12. MANAGE APPLICATIONS.....</b>	<b>26</b>
<b>13. APPLICATIONS &amp; UTILITIES.....</b>	<b>27</b>
<b>14. SETTINGS.....</b>	<b>27</b>

## **I. Cautions on mobile phone use**

### **1.1 Interference**

All phones may be interfered, which affect phone calls.

## **1.2 Reasonable use**

Use only in the normal position. Do not touch the antenna area unnecessarily.

## **1.3 Qualified maintenance service**

Only qualified personnel may install or repair this product.

## **1.4 Water-resistance**

Your device is non water-resistant. Keep it dry.

## **1.5 Emergency calls**

Ensure the phone is switched on and in service. Enter the emergency number and press the Dialer icon.

## **2 Precautions for use of battery**

**2.1** Do not dispose of batteries near or in a fire to avoid dangers.

**2.2** Do not dispose of batteries in the garbage. Dispose of batteries to assigned battery recycling center.

## **3 Cautions for children**

Keep your device out the reach of children in case of accidental injury caused by incorrect use of the device as toys.

## II. Keys parts



- **1. Front Camera**
- **2. Receiver**
- **3. Light sensor / Proximity sensor**
- **4. Adjust volume key**
- **5. Power key**
- **6. Rear Camera**
- **7. Flashlight**
- **8. Fingerprint**
- **9. Audio socket**
- **10. MIC**
- **11. USB Connector**
- **12. Speaker**

### **III. Start to use**

#### **3.1 To insert SIM card(S):**

Insert the SIM card correctly in the card slot(s) (See figure below), suggest switch off the phone when you insert SIM card.

Insert the Micro SD card into the slot with the correct direction (See figure below), suggest switch off the phone when you insert Micro SD.

Note: Use only compatible memory cards with this device. Incompatible memory cards may damage the card or the device and corrupt the data stored in the card.



### **3.2 Charge the battery**

During charging, the battery indicator on the phone is a thunder icon. If the device is switched off during charging, there will still be a charging indication on the screen that shows the phone is being charged. If the device is overused when the battery is low, the charging icon might take some time to appear.

When the battery indicator on the screen display 'Battery is full', thunder icon will disappear, which means the completion of charging. If the phone is switched off during charging, the screen will display ' Battery is full '. It generally takes 4 hours to charge the battery. During charging, the battery, the device and the charger will get hot. This is normal.

Unplug the charger from the AC electrical outlet and disconnect the wiring between the phone and the charger after charging. .


**Cautions:** Charge the phone in a well ventilated place in which the temperature is between -10°C to +40°C. Use the charger provided by the manufacturer only. The use of unconfirmed charger may lead to dangers and violate the manufacturer's warranty clause. If the temperature is too high or too low during charging, the device will automatically send a warning and stop charging to avoid damage to the battery or any danger.

## **IV. Basic functions**

### **1. Lock and unlock the screen**

Press power button to enter Sleep mode and meanwhile the screen will be locked; press power button again to wake up and then swipe up for unlock.





## **2. Make it yours**

2.1 Home screen: It is your starting point to access all the features on your phone. It displays application icons, widgets, shortcuts, and other features. Long press home screen and Modify Wallpaper.



2.2 Long press Home screen, and then you can Modify Wallpaper; or enter Launcher and long press and hold an application till the screen vibrates, and then loosen your hold finger.



Long press the widget or icon, after the phone vibrates, select delete or uninstall (select delete for

widget, select uninstall for APP)



Swipe up and enter to applaction list.



**2.3 Notification Bar:** At the top of the screen, the Status Bar displays the time, status, and notifications. If there is a new message, missed call or something in the notification bar, you can drag it down to open notification panel and click the desired one to have a view. When you finished, you can close it by dragging the panel up or pressing “Back”.



## 2.4 Android™ and computer connection

If you connect your phone to PC via USB, you can find the USB options, choose This Device file Transfer option, you can see your phone memory in PC, this is same function like USB storage.



### 3. Switch to Recently Used Application

Press menu key.




Touch and slide this place can choose to open the history application


Touch this icon to close all history application



#### 4. Make a call



Click  and enter a complete phone number to make a call. Your phone supports smart search.



Swipe to right to view Call history and Contacts.

## 5. Call log




Press the number if you want to see the details , send message or call back, there are three options for you.

Press the number, you can view the contact details, send a message or call back.

## 6. Answering phone calls and rejection


When there is an incoming call, you can drag the icon up or down to answer or hang up it directly.




## 7. Add a contact



Touch  to enter contact

Touch  to add a new contact



No contacts yet



Click here to add new contact and in this page press menu key to enter menu view, setting, etc.

## 8. Send and Receive message(s)



Touch  enter to messaging, touch “Start chat”.



Tap this icon to select  
desired contact from phone



Touch to switch the digital input and  
symbols

Press and hold the 'Globe' icon to see the list of  
available input methods

When you are composing a new text message, you can select text for cutting or copying. The selected text is highlighted in blue

Tap  to add "Attach" including Pictures, Videos, Audios, etc to send MMS.SMS



When a new message comes, you can read by dragging notification panel and click the message, or entering Message to read it directly.  
Long press one of the all message threads, you can delete it".

## **9. Browser the Web**

### **9.1 Set up Internet/Data connection**


Enter Settings > More..., scroll down to find out Mobile network, and then enter "Access Points Names, choose the desired WAP account.

### **9.2 Switch on Data connection or Wi-Fi**

To browse the web, you need to switch on Data connection. If there is Wi-Fi around, you can switch on Wi-Fi to use it browse the web.

## **10. Enjoy music**

When you copy music to your SD card, the Music player searches the card for music files and builds a catalog of your music, based on information about each file that is stored in the file itself.





## 11. Download applications from Play Store

### 11.1 Add Google™ account

### 11.2 Enter play store and download apps



## 12. Manage Applications

Enter Setting > App.  
You can see app info.



## 13. APPLICATIONS & UTILITIES

For your entertainment purpose, applications and utilities, such as Gmail, Email, Play Store. Before accessing the applications, please turn on the data connection or connect to wifi.

## 14. Settings

## 14.1 Wi-Fi

Open Wi-Fi, search nearby Wi-Fi and connect it, then you can use Internet or download apps for free.



## 14.2 Bluetooth

Open Bluetooth, connect to other phone, you can share something like music, photos, movies etc to other people.



### 14.3 Security

Screen lock.

There are four screen lock ways for you to choose :Swipe, Pattern, PIN, Password.



CE/UKCA statements:

- Do not place in a high-temperature environment.
- Do not attempt to disassemble the battery by yourself.
- Do not destroy the batteries and chargers.
- The battery is forbidden to be used after soaking.
- It is forbidden to disassemble, strike, squeeze or throw into the fire.
- If there is a serious expansion, do not continue to use.
- To optimize battery life, only use the battery and charger supplied.
- Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
- The socket-outlet should be near the device and easily accessible.
- Avoid using your phone when it is charging. Do not cover your phone or power adapter.

For safe and effective charging that also protects your battery, you must also pay attention to the following points:

- If your AC power supply is lower voltage, or you charge from computer or other non-standard sources, you may need to charge your phone for longer.
- Your phone might not start straight away if the battery is low. Your phone will start normally once it has charged for a short while.
- The time your phone needs to charge may depend on room temperature and your battery level.
- The phone and charger may heat while charging. This is normal and shouldn't affect your phone's lifespan or performance. If your battery becomes much hotter than usual, stop charging your phone and put it in a cool place. If you phone surface is hot, avoid touching your phone for too long.

- The charger type is:

Model name: MC/X3WH2TC, MC/X3WH3TG, MC/X3WH2TI, MC/X3WH3TD

Input: 100-240V, 50/60Hz, 0.3A

Output: 5V $\overline{\sim}$  2A

### **Health and safety information**

Ensure you carefully read the information below and that you follow this information when using your phone. This is to protect you, the people around you, and your phone.

- To prevent possible hearing damage, do not listen at high volume

levels for long periods.



- Driving safety: Observe local laws and regulations while using the device. To reduce the risk of accidents, do not use your device while driving.
- While flying in an aircraft or immediately before boarding, only use your phone according to instructions provided. Use of a wireless phone in an aircraft may disrupt wireless networks, can cause danger to aircraft operation, and may be illegal.
- Electronic implants and pacemakers: A minimum distance of 15cm between a device and a pacemaker is advised to avoid potential interference with the pacemaker. Hold the device on the opposite side to the implant as precautions when making a call. If you notice that your device is causing interference with a pacemaker, switch it off immediately and contact a doctor for advice on what action to take.
- Fire hazard: Do not leave your device near heat sources. Do not leave

your device charging near flammable materials.

- Contact with liquid: Do not expose the device to liquid or touch it with wet hands. Any damage caused by water may be irreparable.
- Recycling: Observe the local regulations on phone packaging, battery and used phone disposal and bring them to the collection point for proper recycling. Do not dispose of used phones or batteries in a household rubbish bin. Take your used, unwanted lithium batteries to a designated



place. Do not dispose of them in a rubbish bin.

- Electric shock: Do not try to dismantle your device as there is a very real risk of electric shock.
- Obey all rules and regulations applicable to devices in hospitals and health care facilities.
- Do not expose your device to areas with flammables and explosives.
- Do not crush, throw, or puncture your device. Avoid dropping, squeezing, or bending your device.
- Operating temperature is  $-10^{\circ}\text{C}$  to  $40^{\circ}\text{C}$ .
- To reduce the adverse effects of prolonged radiation exposure, we advise teenagers to hold the phone away from their lower abdomen, and that pregnant women hold the phone at a distance from their stomach.

Rated Input: 5V  $\approx$  2A

Specific Absorption Rate (SAR)

- Your phone is tested to comply with applicable requirements and regulations of the European Union/UK of human exposure to radio wave.
- Specific Absorption Rate (SAR) is used to measure radio



waves absorbed by a body. The device complies with RF specifications when the device used at a distance of 5 mm from your body. The SAR limit is 2.0 W/kg averaged over 10 gram of tissue in the European Union/UK.

- This product was tested and recorded the maximum SAR value was 0.711 W/kg for the head, 1.472 W/kg for the body, 2.674 W/kg for the limbs.

Frequency bands and power

	Bands	Operation Frequency	Max.Power
GSM	900	880-915MHz	33.5 dBm
	1800	1710-1785MHz	30.5 dBm
WCDMA	1	1920-1980MHz	23.5 dBm
	8	880-915MHz	23.5 dBm
LTE	1	1920-1980MHz	24 dBm
	3	1710-1785MHz	24 dBm
	5	824-849MHz	24 dBm
	7	2500-2570MHz	23 dBm
	8	880-915MHz	24 dBm

	20	832-862MHz	24 dBm
	28	703-748MHz	24 dBm
	40	2300-2400MHz	23 dBm
	41	2540-2640MHz	23.5 dBm
Bluetooth	2.4GHz	2402-2480 MHz	EIRP 11.2 dBm
Wi-Fi	2.4GHz	2412-2472MHz	EIRP 17.61 dBm
	5GHz	5180-5240MHz	EIRP 14.58 dBm
		5260-5320MHz	EIRP 14.52 dBm
		5745-5825MHz	EIRP 13.19 dBm
GNSS		1559-1610MHz	-
FM		87.5-108MHz	-

This equipment may be operated in all European countries/UK.  
The 5150-5350 MHz band is restricted to indoor use only in the following countries.

	AT	BE	BG	CH	CY	CY	DE	DK
	EE	EL	ES	FI	FR	HR	HU	IE
	IS	IT	LI	LT	LU	LV	MT	NL
	PL	PT	RO	SE	SI	SK	TR	UK(NI)
	UK							

Hereby, You Tec Ltd declares that the radio equipment type X3 is in compliance with directive

2014/53/EU and RER 2017 (SI 2017/1206).

The declaration of conformity is available at the following internet address:<https://www.stklife.com/>.

#### FCC statements:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed

and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types X3 (FCC ID: 2A2KI-STKX3) has also been tested against this SAR limit.

The highest SAR value reported under this standard during product certification for use when properly worn on the body is 1.198 W/kg and for head is 1.031 W/kg. Simultaneous RF exposure is 1.508 W/Kg.

This device was tested for typical body - worn operations with the back of the handset kept 5mm from the body.

To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 5mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be Avoided.

The device for operation in the band 5150–5350 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

IC statements:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:  
this device may not cause interference, and  
this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme avec Industrie Canada RSS exemptes de licence standard(s). Son fonctionnement est soumis aux deux conditions suivantes:  
(1) cet appareil ne peut pas provoquer d'interférences, et  
(2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This device has been tested for compliance with IC SAR values at a typical operating near the body. To ensure that RF exposure levels below the levels tested, use accessories with this equipment to maintain a minimum separation distance of 15 mm between the body of the user and the device. These accessories should not contain metallic components. It is possible that the accessories used close to the body that do

not meet these requirements are not consistent with the SAR limits and it is advisable to avoid using them.

Ce dispositif a été testé pour la conformité avec les valeurs SAR à un fonctionnement typique près du corps . Pour assurer que les niveaux d'exposition aux radiofréquences en deçà des niveaux testés , utiliser des accessoires avec cet équipement pour maintenir une distance de séparation minimale de 15 mm entre le corps de l'utilisateur et l'appareil. Ces accessoires ne doivent pas contenir des composants métalliques. Il est possible que les accessoires utilisés près du corps qui ne répondent pas à ces exigences ne sont pas compatibles avec les limites SAR et il est conseillé d'éviter de les utiliser.

The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.