



Quick Use Guide for ASWH15DS

1. Power On: Long press 3s the multi-fuction button. a tone will be heard.
2. Bluetooth Pairing mode: White light flash indicate that into pairing mode. Choose pair name "ASWH15DS" to pair with your device. Once successful, a tone will be heard indicating that the headphone paired.
After paired successful, white lights will turn on when without music. And white lights will slowly flash every 5 seconds when play music.
3. Power Off:
 - a. Long press 3s the multi-fuction button. RED light flash 3 times.
 - b. 5 mins fail to connect with any device.
 - c. When Plug on the AUX cable
 - d. When Charging
4. Short press the multi-fuction button to play/pause the music.
5. Quick press the multi-fuction button twice to recall your last dial out number.
6. When a incoming call, short press multi-fuction button to answer, short press again multi-fuction button to hang up the call. long press to reject.
7. "+" button: short press to increase the volume. Long press to skip to next track.
8. "-" button: short press to decrease the volume. Long press to skip to previous track.
9. On lower power, a tone will be periodically heard, indicating that the headphone should be charged. The LED indicator will turn RED while charging and turn White when fully charged.
10. SD card mode: insert the SD card to the slot, the headphone will change to SD card mode and play the music inside it.

Charging port: Type C

Battery capacity: 200mah

Charging time: around 2 hrs

Play time: Up to 8 hrs

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.*
- Increase the separation between the equipment and receiver.*
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- Consult the dealer or an experienced radio/TV technician for help.*

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.