


Function Panel



FEATURES

- 1, Pause / Play & Mode
- 2, Volume Down & Last Track
- 3, Volume Up & Next Track
- 4, LED Mode Button

CHARGING THE BLUETOOTH DEVICE

1. Connect the speaker's Micro USB socket with the power source's USB port with the provided charging cable.
(Note: The Micro USB port is located on the back of the speaker.)
2. The Power indicator will show red while the battery is charging. When a full charge has been achieved the LED will turn off.
(Note: A full charge will take 2-3 hours to achieve.)
3. Disconnect charging cable when finished. Do not leave charging cable inserted into the devices when not in use.

SPEAKER CONTROLS AND FUNCTIONS

- To pause and play media use the Mode button (1).
- To increase volume press the Volume Up button (3).
- To decrease volume press the Volume Down button (2).
- Press and hold the Volume Up button (3) to play next track.
- Press and hold the Volume Down button (2) to play the last track.

PAIRING / RECONNECTING THE DEVICE

1. When the speaker is powered "On" it is automatically in searching / pairing / reconnect mode.
2. Now, turn ON the Bluetooth function of your device.
3. Search for "SP3036" to pair.
(Note: for the first time pairing or pairing a new mobile device)
4. The Speaker will reconnect automatically if your mobile phone has been paired previously.
(Note: Depending on the device's type and configuration, manual reconnection may be required.)
5. If pairing is successful, the Radial speaker will make a tone to confirm that it has connected with your mobile device.
(Note: If you cannot search for the Speaker, this means the last device is reconnecting automatically. Press the Mode button (1) for 3 seconds to initiate Bluetooth pairing mode. This can also be done to pair to a new device.)

AUXILIARY-IN FUNCTION

1. With the speaker powered on, connect the included Auxiliary cable into the Auxiliary port on the back of the speaker and plug the other end into your phones auxiliary port.
2. The speaker will now enter Aux-in mode and play media from the connected mobile device.
(Note: When using "Aux-in" mode all functions such as pause, play, and track selection are done from the mobile device.)
3. Disconnect the Auxiliary cable when finished listening.
(Note: If there is no sound while auxiliary cable is connected to Bluetooth device, ensure all other Bluetooth devices are not paired and repeat step one. If the problem persists replace cable.)

HANDS FREE CALLING

1. To answer an incoming call press the Function button (1) for two seconds to answer.
2. To end or reject an incoming call when press the Function button (1) to hang up.

LED LIGHTING MODES

1. With the speaker powered on, press the LED button (4) this will cycle through the various LED lighting modes programmed on the RADIAL Speaker.
2. You can also turn the LED lighting off completely by pressing and holding the LED button (4) allowing you to listen to music without visuals.

TROUBLE SHOOTING

No power

- Recharge your speaker using the micro USB cable. If the problem persists try using another micro USB cable

No Response From the Unit

- Ensure your bluetooth device has an A2DP profile
- Check if both devices are paired and connected.
- Restart the device and try to reconnect.

Bluetooth device will not reconnect with the Speaker

- From your Devices bluetooth menu select the "SP3036" speaker and choose "Forget". Now repeat the steps to pair the speaker with your device.

Cannot find the devices name on the bluetooth menu

- Ensure the Bluetooth function is activated on your device.

- Ensure you have paired the unit with your Bluetooth device.

Cannot hear my media or it has very low volume

- Ensure the volume is turned up on your device.
- If problem persists, power off the speaker and charge it to full battery capacity.

Sound quality is weak or is being distorted

- Connect and recharge the speaker, best sound quality will come from a fully charged speaker.

SPECIFICATIONS:

- Driver Unit size: DIA 2"
- DC Power Input : DC 3.7 V 1A
- Bluetooth: V 2.1 + EDR
- Output power: RMS 3W x 2
- Frequency: 90Hz-18KHz
- Working distance: 30 ft (Distance may vary)
- Battery: 2200 mAh (2 hours of playback)
- Power Supply: Lithium Battery
- Impedance: 40 dB

CARE AND MAINTENANCE

- To clean the unit gently wipe with a soft, damp cloth.
- Never use chemicals or hard abrasives, doing so may damage the speaker's functionality and finish.
- Keep this unit away from wet or damp surroundings. Exposure to such environments can damage the speaker and its ability to function properly.
- Do not play music at excessive levels. Damage to hearing and / or equipment may result.
- Do not tamper or open the device, doing so may result in damage and personal harm.

Limitation of Liability

In no event, under any cause of action of theory of liability, shall iWave Secure Media Inc., its distributors or suppliers be liable to you or any third party for indirect, incidental, consequential special, exemplary or punitive damages, of any and all nature whatsoever, arising out of use of or inability to use a product. This includes without limitation, property damage, loss of value of the product or any third party products that are used in or with the Wave products, even if the Wave product has been advised of the possibility of such damages that one may encounter. Without limiting the foregoing, you understand and agree that iWave has no liability for any damages or destruction to the consumer electronic devices or other personal property that are contained inside or outside of the iWave products. This includes without limitation, laptops, cellular phones, or other handheld devices, or any loss of data contained in the foregoing devices. Notwithstanding any damages that you might incur for any reason whatsoever (including without limitation, all damages referenced herein and all direct or general damages in contract, tort (including negligence) or otherwise), the entire aggregate liability of iWave and any of its distributors and/or suppliers shall be limited to the amount actually paid by you for the iWave product giving rise to liability. Some states and/or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. The limitations of liability set forth above shall apply to the maximum extent permitted under the applicable law.

Warning:
Please read these safety warnings and cautions carefully to ensure your personal safety and prevent property damage.

Fire and Electric Shock Hazard

- Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects into the speaker. Such actions could result in electric shock.
- Do not expose your speaker to extremely high or low temperatures. It can cause malfunction.
- Do not leave your speaker in direct sunlight for extended periods of time.
- Do not leave your speaker near open flames such as cooking burners, candles, or fireplaces.
- Do not block any ventilation openings.

Fall Hazard

- Do not place the speaker on high surfaces such as shelves. During music playback the speaker may move which could cause the speaker to shift and fall off the edge.

Warning:
To reduce the risk of electric shock, do not remove cover (or back). Refer servicing to qualified service personnel.

CAUTION:

- Do not use abrasive cleaners to clean your speaker. It could cause scratches and damage.
- Do not bring your speaker in to contact with any sharp objects. It could cause scratches and damage.
- Do not insert anything into your speaker unless otherwise specified in the user instructions. This may damage the units internal components.
- Do not attempt to repair, modify, or disassemble your speaker yourself. It does not contain any user-serviceable components.
- Do not attempt to replace your speaker battery, it is built-in and is not changeable.
- Use only the manufacturer supplied charger to charge your speaker. Other chargers may look similar, but using them could result in electric shock and could damage your speaker.
- Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas.
- Turn off your speaker prior to boarding an aircraft. Do not use the speaker inside an aircraft unless allowed by your airline.
- Dispose of the speaker and its battery in accordance with local regulations. Do not dispose of the battery with regular household waste.

FCC Disclaimer:

This device Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1- This device may not cause harmful interference, and
- 2- This device must accept any interference received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help or assistance.

FCC RF Radiation Exposure Statement:

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
 2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device was tested for typical hand held operations with the device contacted directly to the human body to the sides of the device.
- To maintain compliance with FCC RF exposure compliance requirements, avoid direct contact to the transmitting antenna during transmitting



iWave and the iWave logo are trademarks of iWave Secure Media, Inc. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by is under license. All other trademarks and trade names are those of their respective owners. ©2015



New York NY 10008
Support@iwavesecure.com
www.iwavesecure.com
Made in China and designed for
iWave Secure Media, Inc.
This product is not a toy.



IMPORTANT PLEASE READ BEFORE USING THIS PRODUCT