



In Bluetooth mode, press and hold the [mode key] for 2 seconds to disconnect the Bluetooth connection: After disconnection, press and hold again for 2 seconds to reconnect to the previous disconnected Bluetooth device.

⑨ Play pause/answer hang up ⑫ Play mode switch

⑩ Volume + ⑪ Volume -

The diagram shows a top-down view of a mobile phone. Four lines with circular endpoints point to specific locations on the phone's face: one to the top-left corner (labeled 9), one to the top-right corner (labeled 12), one to the bottom-left corner (labeled 10), and one to the bottom-right corner (labeled 11). The phone is represented by a simple rectangle with rounded corners and a small notch at the top center.

- 3 -

After successful Interconnection, you can long press the play button for 2 seconds to disconnect TVS Interconnection

- 4 -



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.