





Monster Airmars XKT01 MK II

Ture Wireless Bluetooth Headphone Instruction Manual


Product parameters

- Bluetooth Version ----- V5.3
- Transmission Distance-----10m
- Driver Diameter ----- Ø13mm
- Driver Impedance ----- $32\Omega \pm 15\%$
- Sensitivity ----- $-102\text{dB} \pm 3\text{dB}$
- Frequency Response Range ----- 20Hz~20KHz
- Battery Capacity (Charing Case) ----- 300mAh 3.7V
- Battery Capacity (Earbuds) -----30mAh 3.7V
- Charging Time (Charging Case) ----- <1.5 Hours
- Play Time (Earbuds) ----- $\approx 3.5\text{Hours}$
- Play Time with Charging Case ----- $\approx 15.5\text{Hours}$


Packing list

	Earbud*2		Charging Case*1
	Instruction manual*1		Type-C charging cable*1

Schematic description of the product




Earbuds



Charging Case

Charge the Charging Case

Connect the charging case to the 5V power adapter with the Type-C charging cable.



Rated input: 5V \approx 30mAh (earbuds) Rated input: 5V \approx 300mAh (charging case).

Tips:

When the Charging Case Status Light blinks ice blue quickly, it means that the charging case battery level is low. Please charge the charging case.

Status Light Guide

Status	Descriptions	Voice prompts
Power On	Earbud Status Light blinks ice blue 3 times	"Power on"
Power Off	Earbud Status Light shows solid red for 1 second then goes off	"Power off"
Pairing	The Earbud Status Light of master earbud blinks ice blue and red alternately and the Earbud Status Light of slave earbud turns off	"Pairing"
Connected	The Earbud Status Light goes off	"Connected"
Disconnected	The Earbud Status Light of master earbud blinks ice blue and red alternately and the Earbud Status Light of slave earbud turns off	"Disconnected"
Earbuds Battery Level is low	The Earbud Status Light blinks red quickly	"Battery low"
Charging Case charges earbuds	The Charging Case Status Light shows solid ice blue.	---
Charging case battery level is low	The Charging Case Status Light blinks ice blue quickly until it goes out	---
Charging Case is Charging	The Charging Case Status Light blinks red slowly	---
Charging Case is fully charged	The Charging Case Status Light shows solid red	---

Product operating instructions

1. Power On

Method 1: Take out the earbuds from the charging case, and the earbuds will automatically turn on.

Method 2: Long press the Multi-Function Button (MFB) of earbud for 3 seconds, and the earbud will turn on.

2. Power Off

Method 1: Put the earbuds back into the charging case and the earbuds will turn off.


Method 2: After 3 minutes of disconnection from the Bluetooth device, the earbuds will automatically turn off.

3. Pairing

Step 1: Take out the earbuds from the charging case, and the earbuds will automatically turn on;

Step 2: Open the Bluetooth list of the smart device, search for "Monster Airmars XKT01 MK II" for pairing, after the connection is successful, you will hear the prompt tone "Connected"

* If earbuds are out of distance, within 3 minutes of disconnection, back to the effective distance, earbuds will automatically connect the device.




Note:

* If the product is not used for a long time, it should be fully charged first and make sure the device is turned off.

* After charging, please unplug the charging cable to avoid damage to the device caused by prolonged charging.

Multi-Function Button operations

Regular Mode




Voice assistant: Press and hold left earbud MFB for 2 seconds

Volume Plus: Click the right earbud MFB

Volume down: Click the left earbud MFB

Music Mode




Pause/Play: Double-click the left/right earbud MFB

Previous track: Triple-click left earbud MFB

Next: Triple-click right earbud MFB

Telephone Mode




Answer: Double-click the left/right headset MFB

Rejection: Press and hold left/right earbud MFB for 2 seconds

Hang up: Double-click the left/right earbud MFB

Gaming/Music Mode Switching: Device Connected



Press and hold the right earbud MFB for 2 seconds to enter the game mode

Press and hold the right earbud MFB for 2 seconds to enter the music mode

Restore factory settings

After a single earbud is powered on, make sure it doesn't connect any Bluetooth device, and click the left/right earbud MFB key 5 times to clear the pairing information, then turn off the earbud.

Notes

1. After taking out the charging case, the earbuds automatically turn on, pair, and connect without pressing any buttons; After the earbuds are placed in the charging case, the charging case will automatically charge the earbuds and turn them off.
2. Regular cleaning can prolong the service life of the product. If not used for a long time, it is recommended to charge once every 15 days to extend the battery life. The surfaces of the charging pads on the earbud stem should be regularly wiped with cotton swabs and alcohol to help smooth charging, avoid poor contact, and affect the user experience.
3. Batteries (battery packs or combinations of cells) must not be exposed to lighting, baking, or similar excessive heat. It is forbidden to disassemble, impact, crush or throw into fire. If severe swelling occurs, do not continue to use. Never leave in a high temperature environment. It is forbidden to use after immersion in water.
4. Since this product adopts wireless connection, in the process of daily use, affected by the environment, mobile phone brand, usage behavior and other factors, it is normal for a short and slight sound to freeze during the process of playing music.

Warnings

1. Using earbuds at high volume for extended periods of time may damage your hearing. It is recommended to listen, call, and listen to music only at the appropriate volume.
2. Do not rinse or immerse the product in water to avoid malfunction.
3. Do not disassemble products and accessories by yourself to avoid damage and warranty voided.
4. Do not use chemical solvents or detergents to clean the product.

Name of the Parts	Hazardous Substance					
	Pb lead	Hg mercury	Cd cadmium	Cr (VI) hexavalent chromium	PBB polybrominated biphenyls	PBDE polybrominated diphenyl ethers
Housing	O	O	O	O	O	O
Loud Speakers	O	O	O	O	O	O
PCBA	X	O	O	O	O	O
Accessories Power cord, connecting cable	X	O	O	O	O	O

This table is compiled according to SJ/T 11364.

O: Indicates that this hazardous substance contained in all of homogeneous materials for this part is below the limit requirement in GB/T 26572.

X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

FCC Statement

This equipment has been tested to meet the limits for Class B digital equipment pursuant to Part 15 of the FCC Rules. These restrictions are intended to provide reasonable protection against harmful interference in residential facilities. This equipment generates and radiates radio frequency energy for use, and failure to install and use instructions in accordance with regulations may cause harmful interference to radio communications. However, there is no guarantee that there will be no interference during installation. If the device has caused harmful interference to radio or television reception, the device may be determined by turning, turning it off and on, encouraging the user to attempt one or more of the following additional measures:

- Reorient or reposition the receiving antenna.
 - Increase the spacing between the device and receiver.
 - The device is connected to a socket on a different circuit than the receiver is connected.
- Consult your dealer or experienced radio/TV technician for assistance.

This device complies with Part 15 of the FCC Rules. The operation is subject to the following two conditions:

- (1) This device must not cause harmful interference.
- (2) The device must accept any interference received, including interference that may result in unintended operation. Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

FCC ID:



Environment Friendly Use Period (EFUP)

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

Warranty Service

Dear user, this Warranty Card is the proof of your future warranty applications, please cooperate with the seller to fill in and properly keep it for future use!

User Information

User name		Email	
Contact number		ZIP code	
Mailing address			

Product Information

Product name		Product model	
Product barcode/serial number/batch Number			

Vendor Information

Name			
Address			
Contact number		Zip code	
Date of sale		Invoice number	
Remarks			

MONSTER®

Certificate of Approval

Product No: _____

Production Date _____

Quality Checker: _____

