Consciot



Industrial Floor Lamp with White Jade Glass Shade



Features

- Create a warm atmosphere: This floor lamp includes a white jade glass shade which creates soft and uniform brightness with no glare, eye caring and perfect for bedroom, living room, office lighting.
- Easy assembly and safe: The standing light is made of high quality metal; The weighted base allows it to stand still and keep stable, unlikely to tip over or wobble when hit, making it more safe around kids and pets; Hassle-free to set it up, adding elegant touch to your modern home decoration.
- Smart control: This floor lamp comes with a smart E26 A19 WiFi RGBW LED light bulb, which allows you to dim/brighten, change white light from warm to cool, create colorful ambience with 16 million colors on the APP. It also works with Alexa/Google Home, enabling you to control your lights with VOICE COMMANDS.


Product Parameters

Model	MF19334		
Input voltage	AC110-120V 60Hz		
Max power	E26 Max 60W		
Light source	9W A19 RGBW led bulb		
Material	Metal /Glass		
Certification	ETL/FCC/WWA		
Packing list	Lamp body+Glass shade+Lamp base+Led bulb		
Lamp Size	12.21"*9.85"*65.75"		


Instructions for use

Thank you for choosing our Industrial Floor Lamp, It is important to read and follow the assembly instructions carefully. The wrong assembly could cause the floor lamp to break ,potentially creating a hazardous situation. If you have any questions, feel free to call the customer service centre or contact us by e-mail, we are always happy to help, service e-mail:support@consciot.com.

Product Structure



Installation Notes



Operation Guide

1.Download Linkind APP

Get the Linkind app from App Store or Google Play.Linkind app is applicable for IOS 8 or higher, Android 4.1 or higher.





2.Registration or Log In

Tap "Create Account" to create an account, select your country and then enter your email address and password, check your email to get verification. Or choose "Sign In" if you already have a Linkind account

3. Configure the led Wifi bulb with the app

- Preparation:
 - 1) Ensure your phone is connected to your Wifi router and is able to connected to the internet.

Note:This led bulb only support 2.4Ghz network.If you connected to a 5Ghz networkbefore, please switch to the 2.4Ghz network.

2)Ensure the led bulb is connected to power and in its initial stage(run a color cycling).

Note:Note:Press the foot switch, if the bulb doesn't show a color cycling and flash once, please reset it by turn on and off the bulbs consecutively for 6 times, switch it on again to have a check.

■ Tap the icon "+" on the top right corner to Select Device Type;Tap "Lighting" and choose "Wifi RGBW A19".

4. Trouble Shooting

Q1: Why I cannot find "Linkind" APP in Google Play Store? A: Please tap "search instead for Linkind" below then you'll see our APP there. Google thought you were searching for another well-know job search brand, and give priority to it to be displayed.

Q2: Why I didn't receive the verification letter for the registration? A: 1. Please check if you entered a wrong email address during the registration; 2. Check if the mail was stuck in the spam folder; 3. Make sure you have registered on the app instead of the website.

Q3: I failed to get my smart bulb connected to the network, what should I do?

A: After ensuring the Wi-Fi of your home is 2.4G, we suggest you resetting the bulb first:

- 1. Turn on and off the bulb consecutively for 6 times, turn it on again. It will run a color shift:
- 2. Go to WLAN settings, find the WiFi of the bulb which starts with "SmartLight-xxxx", delete or forget it;
- 3. Re-add the bulb on the APP.

If you fail again, don't worry. It is not necessary the fault or bug on the product. There are multiple factors that can influence the connection. Please contact our technical team via the contact details shown on the app or the package. We will check it for you.

Q4: How can I connect the bulb to Alexa?

A: Step 1: Tap "Me" at the top left corner of Home page, select "Integrations", select "Amazon Alexa".

Step 2: Tap "Sign in with Alexa", follow the on-screen instructions to link your account. When it says "Linked with Amazon Alexa successfully", it means the connection is done.

Note: If you already have an Alexa APP account but have not signed in Alexa APP, tap "Sign in with Alexa", it will take you to the sign-in page of Alexa APP.

Step 3: If Alexa does not successfully add your Linkind devices (which must have been already added in Linkind APP), you can add them by saying "Alexa, discover device".

Q5: Why the app states "No Internet Access" when I select the WiFi of the bulb?

A: The notification is from your phone especially some Android phone instead of our APP. That is because the WiFi of the device does have no access to the Internet. You can tap "Connect" to proceed. Please do not choose "Cancel".

Q6: How can I share the light control with family members?
A: Actually there is a "Home Share" function on the app which enables you to share the control with others. You can follow below steps to share the control:

Step 1: Tap the Home you create at home page, select "Home Management". tap "My Home" to enter settings page.

Step 2: Select "Home Share" at the settings page, tap "Add a person" at the "Family management" page.

Step 3: At "Invite" page, fill in the name and E-mail of the Invitee you want to add. The "Name" here works as a note, not necessarily to be the same as that used in the APP.

Step 4: Tap "Invite". An invitation letter will be sent to the Invitee's Email box, and the invitee needs to confirm the invitation letter. Note: The Invitee's email could be either a registered Linkind account or unregistered one.

Cautions

- Do not repair/disassemble,or modify under any circumstances.
- Suggest indoor use. It is non waterproof. Do not use this product in humid environments or at high temperatures.
- Cut off power when cleaning it or not using it.
- Please stop use it if there is any defect issues found in the product and contact us immediately.
- Clean the lamp only with a soft dry cloth.
- Do not place the lamp on uneven,insecure floor.

If you have any questions, feel free to call the customer service centre or contact us by e-mail, we are always happy to help, service e-mail:support@consciot.com.

SPRING SUNSHINE TECHNOLOGY CO., LIMITED

Adr:Room 2401-2404, 24/F., Fu Fai Commercial Centre 27 Hillier Street, Sheung Wan, HongKong

Phone: 1-855-955-7007(24x7) **Website: www.consciot.com**E-mail: support@consciot.com

Made in China









FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.