



# L8 Pro

## QUICK STRAT GUIDE


产品使用手册

保修卡

合格证

使用本产品前请仔细阅读指导手册，妥善保存以备参考。  
Please read the instructions carefully before using this product and keep it well for referen.

## LAYOUT/按键布局



## INSTALLATION & FUNCTION

### CONNECTION:

#### A.Via 2.4GHz Wireless Mode

- 1, Push the slider switch to 2.4GHz Mode (The mouse will power on and the scroll wheel and the top cover lights will stay in RGB flow mode for 2 seconds as a power-on indicator.)
- 2, Plug the wireless USB Dongle into you PC or plug into the Charging Dock. (Already Connected to PC), USB Dongle and mouse distance controlled within 20CM.
- 3, Indicator for DPI Values Corresponding to CPI Button Press: 800 DPI (Red) - 1600 DPI (Color) - 2400 DPI (Blue - Default Value) - 3200 DPI (Yellow) - 6400 DPI (Pink) - 26000 DPI (Orange)

#### B.Via Wired Mode

- 1, Push the slider switch to wired mode.
- 2, Connect the mouse to any of your PC' S USB ports using the charging cable to use it in wire d mode. (Power-On Indicator Light Same as 2.4G Mode)

#### C.Via Bluetooth Mode

- 1, Push the slider switch to Bluetooth mode.
- 2, Pairing with the Desired Device. (Power-On Indicator Light Same as 2.4G Mode)

### PARING MODE:

#### A.2.4GHz Wireless Mode

- 1, Push the slider switch to 2.4GHz Mode.
  - 2, Press and hold the scroll wheel + Left Button + Right Button simultaneously for 3 seconds to activate pairing mode. The scroll wheel light will blink yellow(3 times in 1s), continuous blinking for 1 minute.
  - 3, Plug the wireless USB Dongle into you PC or plug into the Charging Dock.
  - 4, Wait until the mouse pairs with your device. The scroll wheel light will turn to regular lighting effect mode when paired.
- B. Bluetooth Mode**
- 1, Push the slider switch to Bluetooth mode.
  - 2, Press and hold the scroll wheel + Left Button + Right Button simultaneously for 3 seconds to activate pairing mode. The scroll wheel light will blink blue(3 times in 1s), continuous blinking for 3 minutes.
  - 3, Wait until the mouse pairs with your device. The scroll wheel light will turn to regular lighting effect mode when paired.

### MOUSE RECONNECTION:

- A.2.4G Wireless Mode: Scroll Wheel Light Slow Yellow Blinking (1 time per 1 second) as Indicator.  
B. Bluetooth Mode: Scroll Wheel Light Slow Blue Blinking (1 time per 1 second) as Indicator.

### LIGHTING MODE:

Mouse RGB Light Effect Control Mode: Combination key (Scroll Wheel + Back Button) to control lighting modes, combination key (Scroll Wheel + Forward Button) to adjust lighting colors.

For more parameters and mode adjustments, please visit <https://global.machenike.com/> and download the MACHENIKE L8 Pro Dual-Mode Mouse Driver for configuration settings.

### POLLING RATE :

**2.4GHz Mode:** Default polling rate of 2000Hz, adjustable in the driver software to 125-250-500-1000-2000Hz.  
**Wired Mode:** Default polling rate of 1000Hz, adjustable in the driver software to 1000-2000-4000-8000Hz.  
**Bluetooth Mode:** Default polling rate of 125, not adjustable.

### CURSOR MOVEMENT POWER SAVING:

In 2.4G wireless and Bluetooth modes, when the cursor is being moved by the mouse, the RGB lights (except for the scroll wheel) will turn off to save power. The lights will resume when the cursor stops moving.

### HYPERSCROLL WHEEL:

In 2.4G wireless and Bluetooth modes, when the cursor is being moved by the mouse, the RGB lights (except for the scroll wheel) will turn off to save power. The lights will resume when the cursor stops moving.

### CHARGING DOCK USAGE:

**Wireless Connection:** After connecting the charging dock to the PC, insert the USB Dongle into the USB port at the front of the charging dock to connect in 2.4G mode.

**Charging:** Align the charging contacts on the bottom of the mouse with the contacts on the charging dock.

Place the mouse on the charging dock to enter charging mode.

**Light Adjustment:** Press the button at the bottom of the charging dock to switch the dock's light color.

### SLEEP MODE:

In 2.4G wireless and Bluetooth modes, the mouse enters sleep mode (all LED lights turn off) after 3 minutes of inactivity, entering a light sleep mode. It automatically wakes up upon movement. After 30 minutes, it enters deep sleep. Pressing any button will wake it up. There is no sleep function in wired mode.

### LOW BATTERY SHUTDOWN:

When the voltage is below 3.5V, the RGB lighting effect remains fixed on red breathing light, and all three blue battery indicator lights blink (1 blink per second) as an indication. When the voltage is below 3.2V, the mouse will automatically shut down.

## TECH SPECS

MODEL	L8 Pro 2K Edition
CONNECTIVITY	Wired+2.4GHz+Bluetooth
SENSOR	PAW3395
DPI	26000DPI
POLLING RATE	Wired Mode: 8000Hz 2.4GHz Mode: 2000Hz Bluetooth Mode: 125Hz
RGB LIGHTING	Six Lighting Effects (Including No Light)
BATTERY LIFE	380mAh
DRIVER SUPPORT	YES
DIMENSION	Approx.122/72/39mm
WEIGHT	81g±5g

## TROUBLE SHOOTING

• Mouse Movement or Clicking Not Responding:

It may be due to the USB interface not being connected to the computer. Please ensure that the mouse is properly connected to the computer.

• Mouse Movement Too Slow or Too Fast:

It may be due to DPI settings not matching personal preference. Adjust DPI to suit personal preference.

• For any unresolved issues, please do not attempt to disassemble the mouse. Contact the seller for assistance.

• If the charging cable or adapter is lost, please contact the seller to purchase a replacement.

### PACKING CONTENTS:

Mouse, USB Dongle, Charging Dock, Data Cable, User Manual, Mouse Grip Tapes



GLOBAL



机械师 | 敢玩敢酷

合格证  
QUALIFIED CERTIFICATE

检验  
MACHENIKE CERTIFIED

## 产品安装及功能

### 一、连接方式:

**2.4G模式:** 拨动开关拨到2.4G标准模式下, 鼠标开机, 滚轮与上盖部分的灯效保持RGB流光模式开机指示2S, 然后插入接收器到电脑USB (接收器与鼠标距离控制在20CM之内) 或已有线连接电脑状态下的充电底座; DPI指示灯复用滚轮处LED, 切换DPI后, 滚轮灯需要先显示3s对应DPI颜色的显示灯效(其余灯效LED保持原有状态); 随CPI按键按压变化指示对应DPI值800 (红色) -1600 (绿色) -2400 (蓝色-默认值) -3200 (黄色) -6400 (粉色) -26000 (橙色);

**有线模式:** 拨动开关拨到有线模式, 有线连接鼠标开机, 默认DPI 灯光模式跟2.4G流光模式一样 (见上);

**蓝牙模式:** 拨动开关拨到蓝牙模式下; 鼠标开机, 连接上设备后; DPI与尾部氛围灯模式跟2.4G无线模式一样 (同上)

### 二、对码:

**2.4G模式:** 2.4G无线模式: 拨动开关拨到2.4G模式下; 长按滚轮(中键)+左键+右键3S,进入对码状态, 滚轮灯黄灯快闪 (1S 闪烁3次), 持续闪烁1min; 然后插入接收器到电脑USB (接收器与鼠标距离控制在20CM之内); 对码成功后滚轮灯光恢复至灯效模式灯光显示;

**蓝牙模式:** 蓝牙模式: 拨动开关拨到蓝牙模式下; 长按滚轮(中键)+左键+右键3S, 鼠标进入蓝牙对码状态; 滚轮灯 蓝灯快闪 (1S 闪烁3次), 持续闪烁3min; 连接上设备成功后滚轮灯光恢复至灯效模式灯光显示

### 三、鼠标回连:

2.4G无线模式: 滚轮灯黄灯慢闪指示 (1S 闪烁1次) - 蓝牙模式: 滚轮灯蓝灯慢闪指示 (1S 闪烁1次)

### 四、灯光模式:

鼠标RGB灯效控制模式: 组合键 (滚轮+后侧键) 控制灯光模式、组合键 (滚轮+前侧键) 调节灯光颜色)

更多参数及模式调节, 请登录[www.machenike.com](http://www.machenike.com)下载机械师L8 Pro双模鼠标驱动进行设置

### 五、回报率:

**2.4G模式:** 默认回报率2000Hz; 驱动中可以调节125-250-500-1000-2000Hz;

**有线模式:** 默认回报率1000Hz; 驱动中可以调节1000-2000-4000-8000Hz;

**蓝牙模式:** 默认回报率125, 不可调节

### 六、光标移动省电:

2.4G无线和蓝牙模式下; 鼠标移动光标时灯效LED除滚轮LED外的RGB灯熄灭省电; 光标停止时恢复灯光

### 七、飞梭滚轮:

按压鼠标顶部滚轮模式切换按键切换模式: 段落滚轮模式 and 无极滚轮模式

### 八、充电底座使用:

**无线连接:** 充电底座与电脑连接后, 将接收器插入充电底座前端的USB接口处即可连接2.4G模式;

**充电:** 将鼠标底部的充电触点对准充电底座上的触点, 将鼠标放置在充电底座上后, 鼠标进入充电状态;

**灯光调节:** 按压充电底座底的按钮切换底座灯光颜色

### 九、休眠:

2.4G无线和蓝牙模式下; 鼠标不使用3min后 鼠标进入休眠状态 (所有LED灯熄灭) 进入轻度休眠模式, 移动自动唤醒,30分钟之后进入深度休眠; 点击按键唤醒; 有线模式下无休眠功能

### 十、低电/低电关机值:

当电压小于3.5V时, RGB灯效固定在红色呼吸灯效, 而电量指示灯三颗蓝灯全部闪烁 (1s闪烁1次) 指示; 当低于3.2V时 鼠标自动关机。

## 产品参数

型号	L8 Pro 2K版
连接模式	有线+2.4G无线+蓝牙
传感器	原相3395
DPI	26000DPI
回报率	有线模式: 8000Hz 2.4G模式: 2000Hz 蓝牙模式: 125Hz
灯光	六种灯效(包括无光)
电池	380mAh
驱动	有
尺寸	约122/72/39mm
重量	81g±5g
执行标准	GB/T 26245-2010

### 注意事项

- 鼠标移动点击无反应:  
可能是USB接口没有连接上电脑, 请确认鼠标已连接电脑;
- 鼠标移动过慢或过快:  
可能是DPI设定与个人习惯不匹配调整DPI适应个人习惯即可
- 有不能解决的问题, 请不要自行拆卸, 请联系销售商家;
- 若充电线或适配器丢失, 可联系销售商家进行购买

### 产品清单:

鼠标、接收器、充电底座、数据线、产品使用手册、鼠标防滑贴



官方微信服务号

## MACHENIKE产品保修承诺

- 1、在用户按本技术使用说明书正确使用该产品的前提下, 本产品自购买之日起一年内免费保修。
- 2、我方因下列使用者个人的原因而造成的故障将不提供免费保修服务。如:
  - (1) 擅自拆装、改装该产品而造成的故障;
  - (2) 在使用、搬运的过程中不慎摔打、跌落、进液、供电规格不符而造成故障;
  - (3) 因缺乏合理的保养而造成的故障;
  - (4) 没有按使用说明书正确指示进行操作;
  - (5) 第三方厂品、服务或行为导致的故障或损坏等等。
- 3、在要求提供免费保修服务时, 您必须提供清晰、完整和准确的销售发票和保修卡, 购买产品时, 可要求销售商提供上述上述销售发票和保修卡。
- 4、保修范围外的维修服务, 将按规定收费。

## 保修卡

尊敬的用户:

感谢您选购本公司产品, 我公司将按照《中华人民共和国消费者权益保护法》和国家技术监督局、国家工商行政管理局、财政部关于《部分商品修理更换退货责任规定》的有关规定, 为您提供保修服务, 请认真填写此卡并妥善保管, 以便日后凭此卡维修。

客户姓名: \_\_\_\_\_ 电子邮件: \_\_\_\_\_

联系电话: \_\_\_\_\_ 邮政编码: \_\_\_\_\_

通信地址: \_\_\_\_\_

产品名称: \_\_\_\_\_ 产品型号: \_\_\_\_\_

购机日期: \_\_\_\_\_

购机渠道: \_\_\_\_\_

机身编号: \_\_\_\_\_

## 产品性能故障表

送修日期	性能故障描述	工程师签字	完成日期


## 备注:

- 1、请妥善保管此卡, 保修时需出示此卡及购买凭证。
- 2、产品自购买之日起, 凭购买凭证整机免费保修1年。
- 3、下列情况不属于免费服务范围, 但可实行收费维修、终身服务;
  - 1) 不能出示保修说明及发票;
  - 2) 发票涂改;
  - 3) 意外因素或使用不当造成损坏;
  - 4) 未经我司许可, 自行修理造成的损坏;
  - 5) 超过三包有效期, 经修复仍可继续使用;

尺寸: 100\*1250MM

材质: 120g书写纸

印刷: 黑白双面印刷



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.