Adaptor with ferrite must be used with this equipment to ensure compliance with the Class B FCC limits. Power Adapter information: Model No.: ADS-40RJ-12 12036E Manufacturers Name: SHENZHEN HONOR ELECTRONIC CO.,LTD INPUT: 1.0A

OUTPUT: 3.0A

The $5\,I\,50\text{-}5350~\text{MHz}$ band is restricted to indoor use only in the following countries.

	AT	BE	BG	HR	CY	CZ	DK
	EE	FI	FR	DE	EL	HU	IT
	IT	LV	LT	LU	MT	NL	PL
	PT	RO	SK	SI	ES	SE	UK

E ADD / REMOVE OPTION MODULE

Before installing other accessories on the products of Qbic without following the Procedure of Cutting the Power below, the Client should be responsible for any consequence.

Cautions

Electrostatic discharge (ESD) can damage system components. Do the described procedures of cutting power only at an ESD workstation. If no such station is available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the computer chassis.

Procedure of Cutting the Power

- I. In order to turn off system, please press the power button or turn off in O.S.2. Make sure the light of LED is off.
- 3. After the light is off, remove the adaptor, and wait for 10 seconds.
- 4. Please use the correct screw driver to remove the screws on the housing cover.
- 6. Do NOT remove any component on the motherboard. Besides, the motherboard is not allowed to be removed.

7. Lastly, install other components (e.g. SSD, LTE module, WiFi module...)

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.Consult the dealer or an experienced radio/panel PC technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device rnust accept any interference received, including interference that may cause undesired operation.

Correct Disposal of this product. This marking indicates that this product should not be disposed with operation, other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

" FCC & CE RF Radiation Exposure Statement Caution: To maintain compliance with the FCC & CE's RF exposure guidelines, place the product at least 20cm from near by persons."

FCC/CE-RED Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Operations in the 5GHz products are restricted to indoor usage only.

The frequency, mode and the maximum transmitted power in EU are listed below:

- 2402-2480MHz: 4.9 dBm(BT); 9.91 dBm(BLE)

- 2412-2472 MHz: 16.81 dBm

- 5150-5250MHz: 12.08 dBm


- 5725-5825MHz: 12.7 dBm



Quick Start Guide

This quick guide will help you go through installation quickly

Box PC BXP-320/BXP-321



The colour and the appearance may differ depending on the product, and the specifications are subject to change without prior notice to improve the performance.





Box PC







(BXP-320 with Ipcs

BXP-321 with 2pcs)

HDMI Cover



Setscrew M2 (BXP-320 with 3pcs BXP-321 with 3pcs)

Ouick Start Guide


Ve**l**cro Strip

GPIO connector

DC Power Adapter

External Antenna


GPS with Ipcs)



QUICK START GUIDE


C Installation






Insert the M.2 SSD card

2. LTE module Card Installation



Insert the LTE module card

3. Cables Connection



Fix DC jack with DC cover and M2 screw

Fix HDMI connector with HDMI cover and M2 screw (BXP-320)

Step 1

QUICK START GUIDE

Step 2

IT and " and "

Fix the card slot with screw

Fix the card slot with screw

🔒 Step 2















Step 7







t I

for US ₽: F ()

for EU

 $\hat{\mathbf{T}}$



DC & Micro SD (WIFI with Ipcs/LTE with Ipcs Card Cover


4. Surface Mount

Mark the screw hole location on the surface

Step 2



Fix Box PC with screws



* Recommand to mount Box PC with four M4 screws according to the above illustration.



* Please ensure the mounting surface is clean and smooth before using the Velcro strip.

6. Removing Front Cover

