

Quick Guide

Wireless Earphones





Charging for Earphones:

Fully charge the battery for 1-2 hours before using the earphones for the first time, or when they

Put the earphones into the charging case, they will charge automatically. The indicators of earphones will be lit-on orange and indicators of charging case will be lit-on white.

When earphones are fully charged, the indicators of earphones and charging box will be both off.

Charging for Charnging Case:


When the charging case is connected with charger (or computer USB port) by charging cable, the indicator will be flash in orange. When the charging case is fully charged, the indicator will

When the charging case is out of battery, the earphones will not turn on/off automatically when removed from or placed back into the charging case. In this case, turn the earphones on/off manually.

Product Lable



First Use & Pairing



Touch the MFB for 2 secs on both earphones to turn on the earphones. (You will hear the prompt tone). The earphones will automatically enter pairing mode. Take out earphones from the charging case, the earphones will automatically power on

Paring Mode



indicator on of one earphone will flash into orange and white ,and the indicator of rest one will be off when earphones are connected.

Turn on the device's Bluetooth setting your device will show "connected".



 Touch the MFB for 5 secs on both earphones to power off the earphones.
The earphones will automatically turn off when without paring for 10 mins. earphones will automatically power off.

Manual Power-Off

Insert the earphones directed towards your ear canal. Twist gently until the earphones fit comfortably and get better sound experience.





If you have problem to connect the earphones with your device, don't worry about it, please

follow the step as below: 1. Make sure paired devices has turned off Bluetooth function, clean all the paring records if

- 2. Turn off both earphones manually.
- 3. Touch on both earphones for 10 seconds, LED on both earphones will flash in Orange and
- White alternatively and then white lights flash 5 tmes. Once the LED on one earbud flashing in orange and White, and the LED on rest one is off, that means reset is done successfully. 4. Please follow above operation to finish pairing.

sensory or mental abilities, or those lacking experience or knowledge, provided they are correctly supervised, or if the instructions related to the use of the device have been adequately given and if the risks involved have been understood. Children must not play with this device. Children should not clean or maintain the device without supervision.

5. The electrical socket must remain easily accessible if it serves as the means of disconnection.

This logo means that no naked flames, such as a candle can be placed on or near the device.

ensure that it is collected separately. Collection systems and locations (sorting

your end-of-life product to the proper recycling process, you are helping to protect the

4. This device may be used by children aged 8 years or older and by those with reduced physical,

centres, rubbish dumps) are provided for you by local councils and retailers. By entrusting

6. Always unplug the device before cleaning it.

environment and your health.

3. Use this device in temperate climates only.

Care and Maintenance

- 7. Clean the device with a soft dry cloth only. Never use solvents.
- 8. Attention should be drawn to the environmental aspects of battery disposal.

2. The electrical and electronic equipment are part of a

Separate collection. Do not throw electrical or electronic equipment away with unsorted municipal waste, but

- 9. The battery (batteries or battery pack) shall not be exposed to excessive heat such as sunshine,
- 10. Use the apparatus in moderate climate only.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses

and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is
- Consult the dealer or an experienced radio/TV technician for help.
- Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment. FCC Radiation Exposure Statement
- The device has been evaluated to meet general RF exposure require- ment. The device can be

used in portable exposure condition without restriction.