


# Sea-Doo Rise Remote operators guide section

## Model: NewX

\*This remote-control operator guide will be part of a complete vehicle operator guide



## Power OFF Sequence




3 sec Press :



Model name



Stay 1 sec



Stay 1 sec

OR

After 10 min of no action  
The controller an haptic feedback will occur. (find the pattern)



A screen with 15 sec timer will be displayed to let the user know that the controller will shut down.  
Any action on the controller will wake up & restarts the shut down automatic pattern.

## MAIN SCREENS



## Low Battery screen behavior

If low board battery when on this screen an haptic feedback & this screen will be displayed

In case of Board & Controller Low Battery



Battery icons can change alternately every 2 sec.

## SETTINGS MENU



Press :  
While open

**40**  
MIN  
80%

Settings\*\*

d Settings  
LEARNING MODE  
GENERAL  
PAIRING  
DISPLAY  
EXIT

Select Settings :  
Short Press



**LEARNING MODE**  
GENERAL  
PAIRING  
**DISPLAY**  
EXIT

### LEARNING MODE

Power level selection  
(Lock control)

### GENERAL

Units  
Language  
Software update  
About

### PAIRING

Start Pairing

### DISPLAY

Speed  
REM. Time  
Power Level  
Speed \ Rem. Time  
Rem. Time \ Speed

### EXIT

\*\* Note: After 10 sec off inaction into the SETTINGS the screen return to the selected MAIN screen



d Settings  
LEARNING MODE  
GENERAL  
PAIRING  
DISPLAY  
EXIT

### Learning Mode

**LEARNING MODE**  
**3**  
POWER LEVEL



Press Up-down to  
select the Power level

### Settings

d Settings  
LEARNING MODE  
GENERAL  
PAIRING  
DISPLAY  
EXIT

Press Ride settings  
button to  
select & automatically  
return to previous menu

d Settings  
LEARNING MODE  
GENERAL  
PAIRING  
DISPLAY  
EXIT

### General

GENERAL  
UNITS  
LANGUAGE  
SOFTWARE UPDATE  
ABOUT  
EXIT



### Units

UNITS  
METRIC  
IMPERIAL

### General

GENERAL  
UNITS  
LANGUAGE  
SOFTWARE UPDATE  
ABOUT  
EXIT

Ride settings button select &  
automatically return to previous menu

d Settings  
LEARNING MODE  
GENERAL  
PAIRING  
**DISPLAY**  
EXIT

### DISPLAY

DISPLAY  
Speed  
Rem. Time  
Power Level  
Speed \ Rem. Time  
Rem. Time \ Speed



## NOTIFICATIONS


Connection lost or Not paired



GPS lost



Tether cord disconnected



Low Battery

In case of Board & Controller Low Battery



Battery icons change alternately every 2 sec. Battery & % flash.

Locked remote



If no action after 10 sec\*\* on the throttle button the remote locked  
If bluetooth connection is lost for 3 sec\*\*, the remote locked again  
(Fall in the water).

Appears 15 sec or until it's unlocked

Appears 3 sec

- Remote gets unlocked after the SECOND RELEASE

REMOTE WHILE CHARGING



If no action after 15 sec on the controller the screen will close. If the user touch any buttons the screen will wake up to show the battery status

Normal Operation




WARNING ACTIVE



LIMP HOME ACTIVE



ALARM ACTIVE



## **NOTICE**

**Use only the supplied charging  
adapter to charge the remote  
control**

### FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### ISED Warning

English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause interference.
  - This device must accept any interference, including interference that may cause undesired operation of the device.
- French: Cet appareil contient des émetteurs/récepteurs exemptés de licence qui sont conformes aux RSS exemptés de licence du Canada en matière d'innovation, de science et de développement économique. L'utilisation est assujettie aux deux conditions suivantes:

Cet appareil ne peut pas provoquer d'interférence.

- cet appareil doit accepter toute interférence, y compris les interférences qui peuvent provoquer un fonctionnement indésirable de l'appareil.

### ISED Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used installed and operated with minimum distance 0mm between the radiator and your body. L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. Cet équipement doit être installé et utilisé avec une distance minimale de 0 mm

entre le radiateur et votre corps.

***Mexico***

IFETEL

Marca: BRP

Modelo(s): [REDACTED]

Número: [REDACTED]

NOM-[REDACTED]

La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

***Brazil***



Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.

***Japan***

This device is granted pursuant to the Japanese Radio Law (電波法) and the Japanese Telecommunications Business Law (電気通信事業法). This device should not be modified (otherwise the granted designation number will become invalid).