

# USER MANUAL

FCC ID:2AEPISILVERPRO



## SILVER PRO



Read the instruction manual before  
start operating the smartphone

Thank you for purchasing this KALLEY product.  
For more information please visit us at  
**[www.kalley.com.co](http://www.kalley.com.co)** or contact us for free  
to the line 01 8000 524 065

# Kalley®



## Content

2. Know your phone
3. Accessories
3. Instruction for Card Installation
4. Language
4. Dialling
5. Message
5. Photography
6. Safety Information
8. Environment

### **WARNING:**

To reduce the risk of electric shock, do not remove the cover, there are no parts inside that can be repaired by the user, consult qualified service personnel.

### **IMPORTANT:**

Read this user manual carefully so that you become thoroughly familiar with your new product before first use.

### **DEAR CUSTOMER:**

Thank you for purchasing this KALLEY product. To ensure your safety and long time of use without inconvenience with your product, please read carefully the safety instructions.

The contents of this manual may differ in certain aspects of the description of your phone depending on the version of your software and your telephone operator.

## Operating instructions



### Know your phone

1. Headset jack
2. Front softlight
3. Front camera
4. Earpiece
5. Light sensor
6. Screen
7. Speaker
8. USB port
9. Micphone
10. Rear camera
11. Fingerprint sensor
12. Flash
13. Volume
14. Power off/on




Image for your reference.  
Consult the product in the package



## Accessories

- Power Adapter
- USB Cable



## Instruction for Card Installation


Micro SIM+Nano SIM+TF Card

### Network

GSM: 850/900/1800/1900MHz

WCDMA: 850/1700/1900MHz

LTE: B2/B4/B5/B7/B12/B17



SIM 1



SIM 2



SD



Integrated  
Battery

3000mAh



.....→ Loading

Kind	Battery of Li-polymer
Load voltage limit	4.35V
Power	11.40 Wh

### Warning

- Use only Ulefone-approved batteries specifically designed for your phone.
- Incompatible batteries can cause serious injuries or damage to your phone.
- Never place batteries or phones on or in heating devices, such as microwave oven or radiator. Batteries may explode when overheated.

### Language


Enter the Settings app, scroll down to find the "Language and Input" setting, and then select your language in the list.



### Dialling

You can call from the Phone app, the Contacts app or other apps and widgets. Wherever you see a phone number, you can usually touch to make a call








To make a call to one of your contacts:

1. Touch "  " on home screen or in the apps drawer.
2. Choose or search out a contact
3. Place a call to the contact

For latest calls, please go to the recents list "  ".  
You can also input the phone number on the dial pad to make a call "  ".



## Message

To send a message:

1. Press "  " on the home screen or app drawer.
2. Press "  " to write a new message.
3. Type contact name, phone number, or press "  " to add one or more contacts as message receivers.
4. Type text message.
5. Press "  " to add pictures, videos, or audio files
6. Send message by pressing "  ".

## Photography

To take a photo:

1. Open camera "  "
2. Frame your picture.
3. Touch the shutter "  " to take the picture.

It's normal that some systematic texts are not translated to your language.

## Operating instructions



### Safety Information

Please read this safety information carefully so that you can use your phone in complete safety

1. Children: Be very careful with children and your phone. A mobile phone contains a number of detachable parts. Exercise great care when children are in close proximity to the phone. The phone contains small parts that could be swallowed or cause choking. If your phone is equipped with a camera or lighting device, do not use it too near children or animals.
2. Hearing: Prolonged listening at full power using a lightweight headset or headphones can damage your hearing. Reduce the volume to the lowest possible level when listening to music or conversations. Avoid high volumes over extended periods.
3. Driving: Exercise care when driving. Driving requires maximum attention at all times in order to minimize the risk of accidents.

Using a mobile phone can distract the user and result in an accident. You must fully comply with the local regulations and laws in force regarding the use of cell phones whilst driving. You are not allowed to use the

phone whilst driving. A hands- free kit should not be regarded as an alternative solution. Flying: Turn your phone off when flying. Remember to turn your phone off when you are in a plane as it may cause interference.

4. Hospitals: Turn your phone off near any medical devices. It is extremely dangerous to leave a phone switched on near medical devices as it may cause interference. You must observe any instructions or warnings in hospitals and treatment centers. Remember to turn your phone off in service stations. Do not use your device in a petrol station near fuel. It is dangerous to use your phone inside a professional garage.
5. Electronic implants and pacemakers: Users who wear a pacemaker or who are fitted with an electronic implant must hold the phone on the opposite side to their implant as a precaution when making a call. If you notice that your phone is causing interference with a pacemaker, switch it off immediately and contact the manufacturer of the pacemaker for advice on what action to take.
6. Fire hazard: Do not leave your device near heat sources such as radiators or cookers. Do not leave your phone charging near flammable materials as there is a real risk of fire.



7. Contact with liquid: Do not expose the phone to liquid or touch it with wet hands: any damage caused by water may be irreparable.
8. Use only ulefone-approved accessories. The use of Unauthorized accessories may damage your phone or cause a safety risk.
9. Do not destroy the batteries and chargers. Never use a battery or charger that has been damaged, keep batteries away from magnetic objects as the latter might cause a short-circuit between the positive and negative terminals of your batteries and permanently destroy the battery or phone. As a general rule, you should not expose the batteries to very high or low temperatures (below 0°C or above 45°C). Differences in temperature may reduce battery autonomy and service life.
10. Shocks and impact: Handle and use your phone with the utmost care. Protect your phone: shocks and impact may damage it. Some parts of your phone are made from glass and might break if the phone is dropped or is subject to severe impact. Avoid dropping your phone. Do not touch the screen with sharp objects.
11. Electric shock : Do not try to dismantle your phone as there is a very real risk of electric shock.
12. Maintenance: If you want to clean your handset, use a dry cloth (do not use a solvent, such as benzene, or alcohol).
13. Recharge your phone in a well-ventilated area. Do not recharge your device when it is resting on a soft surface.  
Damage to magnetic strips: keep your phone away from
14. credit cards as they may damage the data on the magnetic strips.





### Environment

There are no parts that the user can repair. Request repairs to qualified service personnel.

#### SPECIAL WARNING



The recycling symbol indicates that this cell phone can not be disposed of with household waste.



Android and other brands are brands Google Inc. Commercial

#### Emergency call

If any emergency arises, dial 112/911 (or other emergency call number) for emergency help.

Due to the nature of cellular networking, the success of emergency call is not guaranteed.

#### **FCC Warning:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types SILVER PRO (FCC ID: 2AEPISILVERPRO) has also been tested against this SAR limit. The highest reported SAR values for head, body-worn accessory are 0.71 W/kg, 0.86 W/kg respectively. The Max simultaneous SAR is 0.96 W/kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The logo features the word "Kalley" in a bold, white, sans-serif typeface. A thick, white, curved line arches over the letters "a" and "l", starting from the top of the "a" and ending at the top of the "l". A small registered trademark symbol (®) is positioned to the upper right of the final "y".

**Kalley®**