

Model:C6607-C



Thank you for choosing the C6607-C. In order to optimize the user experience, please read this manual carefully before operation, and keep this manual properly for future use.

Warning:

1. This product is not a toy. To avoid fire, burns, personal injury or electric shock, please install out of the reach of children.
2. In order to ensure the normal operation of the lamp, please use the voltage indicated on the package.
3. Please do not modify the lamps during the warranty period.
4. Do not install near gas or electric heaters, fires, candles or any dangerous objects.
5. Before installation, please check whether the lamps and various parts are in good condition.
6. Be sure to cut off the power before installation.
7. Do not expose the lamp to corrosive conditions.
8. If the power cord is damaged, please cut off the power immediately and stop using it.

Technical Specification:

Connection method: 2.4G Wifi&Bluetooth

Control method: APP/Voice/Button

Adapter input voltage:100-240VAC

Rated working voltage:DC24V

Rated current:1A

Rated power: 4*6W

Lamp color: RGBCW


Color temperature:2200k-6500k

Memory function:yes

Working temperature:-20℃~+40℃

Protection class of lamps and controllers:IP67

Work with Amazon Alexa and Google Assistant.




Packing list:

1. Landscape Lights * 4
2. Ground Plug * 4
3. C015 Controller * 1
4. Waterproof Adapter DC24V/1A (IP44) * 1
5. Remote Controller * 1
6. Copy of the manual * 1
7. Gecko Screw Pack * 4




Dimension Data :



Manual of Controller:




Button Instruction:


Switch : Short press is on/off. When the device is on, long press in 5 seconds is reset to pairing mode. Light will blink in red.

Installation Method:


Installation method 1:



Installation method 2:



APP Intelligent operation introduction:



Add color with one click

Add color individually


Erase Color

Add points

Color light and white light adjustment

Swipe the brightness bar to adjust the light brightness in the current static mode


color adjustment
You can move the color dial clockwise or counterclockwise to adjust your preferred color to the white circle, which can be adjusted left or right to adjust the color fullness



Custom mode
You can DIY your favorite color scene


Collection mode
Long press the icon to collect your favorite dynamic scenes, or long press the icon to delete the dynamic scenes you don't need

Select a scene list to select different scene types



Switching between local microphone mode and mobile music mode

Different music scenes and sensitivity modulation




Set name for DIY mode to reserve.

It supports gradient, jump, breathing, flashing, flowing water, rainbow and other modes DIY.

Slide the slider to adjust the brightness of the lamp

Click "+" to add your favorite color


Intact:set the lamp to one color
Section:divide the light into multiple segments and set them to different colors



Pairing Instruction:


APP Download. Search the **Smart Life** from Google Play or App Store.
You can also scan the QR code from below.

1.Download the APP and **Log In** with existing account or **Sign Up** the new account.




2.Power on the device, confirm the device is blinking rapidly in white. Turn on the Bluetooth and Wi-Fi of phone. Please make sure the phone is connecting the **2.4GHz** Wi-Fi router.


3.Tap **Add Device** or the plus icon (+) in the top-right corner on the **Home** page to go to the device adding page.




4.Enter the Wi-Fi password and click Next. Make sure the Wi-Fi is 2.4GHz not the 5GHz. Because the Wi-Fi chip is 2.4GHz. Wait about twenty seconds and the device will be added completely.



5. Then the device can be found in home page. Now you can play it with your imagination.



6. Click the edit icon in the upper right corner to show more gameplay.



Notice:

1. Please make sure to perform network pairing in 2.4G wifi or hotspot mode;
2. If the connection times out or the network connection cannot be reached, please reconnect to a strong signal location;

Bluetooth control steps

Note: The device has already joined my app normally (2.4GWIFI+Bluetooth is required for the first connection), Bluetooth control is generally used for devices with poor WIFI signals or disconnected network connections;

1. Turn off the phone's WiFi;
 2. Turn on Bluetooth and open the device on the APP;
- Then the device can be controlled through Bluetooth;

Common problems and solutions:

1. Unable to connect to your Wi-Fi network.
 - (1). Please ensure that the correct Wi Fi password is entered during use.
 - (2). Ensure that the connection is 2.4G wifi and that the device currently does not support 5G wifi,
 - (3). Check if there are any issues with your internet connection. If the Wi Fi signal is too weak, please move to a place with a strong signal or reset the wireless router and try again.
2. The installer is not working properly.
 - (1)Then close all applications running in the background and reopen the Smart Life APP.
 - (2) Uninstall and reinstall the Smart Life app and repeat.
3. The smart string light is not responding.
 - (1) Check whether the smart string light is turned off. If yes, turn them on and wait until the smart light strip reconnects to The wireless network works automatically.
 - (2) Check if there is any problem with your internet connection. If necessary, reset the wireless router and try again.

Guarantee:

1. During the warranty period, we provide services including refunds or free replacement for those who use the device for its intended purpose.
2. This warranty does not include:
 - (1) Malfunction or damage caused by improper use, repair or modification.
 - (2) Failure or damage due to falling.
 - (3) Failure or damage caused by fire, earthquake, flood, lightning and other natural disasters.

- (4) Malfunction or damage when used other than for its intended purpose.
- (5) Failure or damage caused by third-party products.
- (6) Failure or damage to the product caused by human factors.

FCC Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following.

Measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).

MADE IN CHINA