Vector User manual

There are three standard methods of attaching our tracking tags to an Asset.

- 1. Stick 3M tape
- 2. Keyring
- 3. Rivet / Screw

Simply pick your preferred attachment method above and attach each tag to its corresponding asset.

Tags are delivered turned off. Hold button for 3 seconds to turn on. It will play a short sound and flash Blue LED three times.

You can press the button to make sure that the tag is turned on - Tag will flash a red / blue LED after a short press if turned on. When turned off there is a smaller green flash.

Notes:

- The rubber pieces filling the key ring holes on our Vector Tags can be removed by using a tool to lever them out.
- Tag orientation can be important for signal propagation
- Remember that the Tags have a replaceable battery, so make sure the battery can be accessed



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.