FCC Statement

Operations of this device is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Information for the user: Changes or modifications not expressly approved by Consumer 2.0 / Rently could void your authority to operation the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experience radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

The Device has been evaluated to meet general RF expose requirement.

To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully support by the operating and installation configurations of the transmitter and its antenna(s).

IC Caution

RSS-Gen Issue 5 "&" RSS-Gen numéro 5

English:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. RF exposure statement: The equipment complies with IC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

French:

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

(1) Cet appareil ne doit pas causer d'interférences.

(2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Tout changement ou modification non expressément approuvé par la partie responsable de la conformité pourrait annuler l'autorité de l'utilisateur à utiliser l'équipement.

Déclaration d'exposition RF: L'équipement est conforme à la limite d'exposition aux radiations de la IC établie pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

Please visit Rently.com for the terms and conditions and privacy policy





SMART HOME QUICKSTART GUIDE Hub 4

support@rentlykeyless.com | 888-340-6340



The Rently Hub 4 is the brain of your smart home. It connects to the cloud using 4G LTE, Wi-Fi, and Ethernet. The hub integrates your Rently devices and ensures they are connected to the Rently online and mobile apps for remote operation.



Unpackage contents and ensure that your Rently hardware was not damaged during transport.



Install your smart home accessories according to the provided instructions.



Step 3

Plug the Rently Hub 4 into a power outlet within 20-30 feet of all smart home devices.



Step 4

Optional: Plug in the Ethernet cable. After a few minutes, the light on the hub will turn solid blue, indicating the hub is online.



Step 5

Log in to the manager portal by visiting secure.rently.com. Input your credentials, select a property, and start controlling devices remotely!



Step 6

From the manager portal, you can easily send out resident and provide guest access.