

## Sensor III Installation Overview


revised 08/14/2017



Step 1: Gather required tools and materials.



Step 2: Measure and mark location.



Step 3: Use template to start pilot hole.



Step 4: Finish drilling hole (4" diameter x 3" deep).



Step 5: Remove core, using pry bar if necessary.



Step 6: Level sensor in hole using a base of sand.



Step 7: Insert sensor, paying attention to orientation.



Step 8: Seal sensor in place.



#### FCC/INDUSTRY CANADA NOTICE

Pursuant to FCC 15.21 of the FCC rules, changes not expressly approved by Fybr might cause harmful interference and void the FCC authorization to operate this product.

This device complies with Part 15 of the FCC Rules and Innovation, Science and Economic Development Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause harmful interference. and (2) this device must accept any interference received, including interference that may cause undesired operation.

This product complies with FCC OET Bulletin 65 & Innovation, Science and Economic Development Canada's RSS-102 radiation exposure limits set forth for an uncontrolled environment.

Cet appareil est conforme à des règlements Innovation, Sciences et Développement économique Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes: (1) Ce dispositif ne doit pas causer d'interférences nuisibles, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable.

Ce produit est conforme aux limites d'expositions aux rayonnements dénies pour un environnement non contrôlé du Bulletin 65 FCC OET et RSS-102 Industry Canada.