
# 说明书成品尺寸: 73X93mm 80g书纸





播放时间: ≈ 5h

奈申时间(頁机):≈15h

配合充电仓续航时间: ≈ 16H

额度输入(耳机): 5V === 35mA

充电时间(充电盒):≈1.5h

电池容量(充电盒) : 200mAh/3.7V

额度输入(充电盒): 5V === 200mA

电池容量(耳机): 35mAh/3.7V

2. 若耳机放在充电盒内 , 给充电盒充电的同时也能为耳机充电。 充电盒给耳机充电(白灯常亮,充满灯灭),充电盒充电(白灯单闪,充满常亮) 低电量状态: 充电仓低电时(低于3.1V) , 白灯快闪报警, 直到仓没电熄灭

1. Type-C USB 充电线,连接充电盒与 5V/1A 输出的 USB 电源接口连接。



额定输入: 5V === 35mA (耳机)



- 、除说明书有特殊标示的操作方式以外,请勿尝试拆卸或更换产品内的任何零件
- 2、请勿将产品放入水或其他任何液体中,此产品非防水设计。 方式 2: 长按左/右3秒开机键 3、如果有任何液体不小心进入产品内时,请立即断开连接并移开此产品。
- 4、为避免触电,请在安装或卸载产品时,确保手上没有沾水。
- 5、请勿将此产品放置于热源附近或直接暴露在火源附近。
- 6、请勿将本产品放置在有强大电磁力的环境中,否则会导致产品故障。

### 耳机灯光及提示音

模式	灯光状态	提示音
配对状态	白冰蓝灯交替闪烁	/
充电状态	冰蓝灯长亮,充满熄灭	/
低电量	冰蓝灯快闪	低电量提示音
开机	白灯长亮一秒熄灭	开机提示音
关机	冰蓝灯长亮——秒熄灭	关机提示音
蓝牙已断连	回连模式: 主耳白冰蓝 交替闪烁,副耳熄灭	蓝牙已断连提示音

### 产品操作说明

- 方式 1: 充电盒上盖打开,取出耳机自动开机
- ②关机 方式 1: 放回充电盒,耳机自动关机 方式 2: 长按左/右多功能按键5秒关机

### ③蓝牙配对与连接

- 1.请将蓝牙耳机和手机(或其他的蓝牙连接设备)的距离在1米的范围内,越近越好; 2.确保耳机在关机状态,长按多功能键约3秒,开机后自动进入配对状态,等待连接; (左右耳配对成功,提示音:左右耳已配对提示音);
- 3.开启用户手机蓝牙功能(或其他蓝牙设备),并进行搜索或扫描,此时手机会搜 索到附近所有的蓝牙设备,点选搜索到的耳机名称QS-002,成功配对连接后,此 时可以进行手机电话, 听歌了

开机未连接状态:连击左/右耳机5次后左/右耳机关机(清除配对和连接的所有信息)





### 产品中有害物质名称及含量

# ── 长按左/右耳功能键2S启动/关闭语音助手 音量+:单击右耳机多功能按键, 最大提示音(咚咚)


□ 音量 -: 単击左耳机多功能按键,

最小提示音 (咚咚) 本表格依据SJ/T11364的规定编制 O:表示该有害物质在该部件所有均质



■ 诵话模式

■ 音乐模式



				有害物质		
部件名称	铅(Pb)	汞(Hg)	镉(Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路组件	0	0	0	0	0	0
売等小结构件	0	0	0	0	0	0

- GB/T26572规定限量要求以下 X:表示该有害物质至少在该部件的某一均质材料中的含量超出 GB26572规定的限量要求。 表单标记"X"的部件,皆因全球技术发展水平限制而无法实现有害
- 物质的替代。

本表格依据SJ/T11364的规定编制 印刷电路板组件\*:包括印刷电路板及其零部件,电子元器件等。 根据产品型号不同 您所购买的产品可能不会含有以上所有部件





本使用手册没有任何形式的担保、立场表达或其他暗示,本使用手册所提到的产品、规格 及信息仅供参考、内容亦会随时更新于网页、恕不另行通知。

就本文件附随的产品做如下保证: 如产品在您购买日起十二(12) 个月("保修期")内,在

- 正常使用情况下因质量瑕疵发生损坏,能修理的,免费修理;经厂家确认无法修理的,免 费更换;修理或更换后的产品,在剩余保修期(最短不少于30天)内继续享有保修。购 买日以销售发票日期为准: 如无法确定购买日. 则保修期自产品生产日期起按十三(13)
- 如申请保修,请先致电产品服务热线,并按我们指示的方式执行。申请保修时,您需要提 供准确、完整和清晰填写的有效销售发票。以上保证不适用于下列情况: 1.超过三包有效期的;
- 2.涂改保修卡、产品编码与产品本体不符:
- 3.因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏; 4 因不可抗力 (加地震 战争 火灾等) 或意外导致的故障或损坏。
- 5.拉链、塔扣因受力过大而损坏
- 6.因承载过重造成的脱线或撕裂;
- 8.有烧损或水浸迹象的产品;
- 9 因擅自抵改导致的指标:
- 10 产品正常使用过程中发生的老化、脱色、磨损、破裂和其他损耗
- 1.如产品原有标识标签被更改或损毁,本保证将失效。
- "品及随附物料的齐备和外观完好不属于保证范围,您应在接收产品时当场检验并对任何
- 以上保证是我们就产品做出的全部保证,且仅在中国大陆地区境内适用。本文件的任何内
- 容均不影响根据法律规定不能排除或限制的消费者权利。

Discurring.

This user manual does not have any form of guarantee position expression or other implication. The mentioned products, specifications and information are freference only, and the content, will also be updated on the web at any time freference only, and the content, will also be updated on the web at any time.

服务监督热线:400-885-8808


Warranty Statement

without additional separate notice





QS-002 Open-ear BT Headphones Instructions& Warranty Card



# Product Parameters

Driver Sensitivity: 110db ± 3db

Playback Time: ≈ 5 Hours

Frequency Response Range: 20hz~20khz

Battery Capacity (Headphone): 35mAh/3.7V

Charging Time (Headphones):≈ 1.5 Hours

Battery Capacity (Charging Case): 200mAh/3.7V

Charging Time (Charging Case):≈ 1.5 Hours

Rated Input (Charging Case): 5V===200mA

Rated Input (Headphone): 5V===35mA

BT version:V 5.4 Transmission Distance:>10 Meters Driver Diameter: Φ 14.2mm Driver Impedance: 32 Ohms

# 1. Type-C USB charging cable, connect the charging case to the USB power

Cooperate With The Charging Compartment For Battery Life :≈ 16Hours

- interface for 5V/1A output. 2. If the earphones are placed in the charging case, charging the charging case can also charge the earphones.
- Charging the earphones with a charging case (white light always on, full light off), charging with a charging case (White light single flashing, always on when fully charged)
- Low battery state: When the charging compartment is low (below 3.1V), the white light will flash quickly and sound an alarm until the compartment runs out of battery and goes out



Rated Input: 5V==35mA (Headphone) Rated Input: 5V==200mA (Charging Case)

- L、Except for the operation methods specifically marked in the manual, please do not try to disassemble or replace any parts in the earbuds. 2. Don't put the earbuds in the water or any others liquid.
- The earbuds are not waterproof.

Describe

- 3. If any liquid enters the product by accidentally please disconnect and remove the connection immediately.
- 4. Please make sure that there is no water on your hands when Installing or uninstalling the product to avoid electricshock.
- 5. Do not put the product near by the heat source or expose it to the fire source 6. Do not put the product in the environment with strong electromagnetic force
- otherwise it will cause product malfunction.

### Headphone Lights And Warning Tones

Mode	Describe		oodiid prompt	
Paired State	White Ice Blue Light Flashes Alternately		/	
State Of Charge	Ice Blue Light Stays On, Full Off		/	
Low Power	Ice Blue Lights Flash	Low battery v	warning sound	
Power_on	The White Light Stays On For A Second And Goes Out.		Power on prompt sound	
Power_off	Ice Blue Light Stays On For A Second And Goes Off.		Power off prompt sound	
BT Disconnected	Back-to-back Mode: Main Ear White Ice Blue Alternately Flashing, Secondary Ear Off		BT disconnected prompt sound	

### Product Operating Instructions

- Method 1: Open the top cover of the charging case, take out the headset and turn it on automatically.
- Method 2: Long press the left/right power on button for 3 seconds.

2 Power off Method 1: Put it back to the charging case, the headset will automatically turn off. Method 2: Long press the left/right multi-function button for 5 seconds to turn phone.

3BT pairing and connection

- 1. Please keep the distance between the BT headset and the cell phone (or other BT-connected devices) within 1 meter, the closer the better. 2. Make sure the headset is in the off state, long press the multi-function key for about 3 seconds, it will automatically enter the pairing state after power on and wait for connection;
- (The left and right ear pairing is successful, beep: Left and right ear paired warning tone); 3. Turn on the BT function of the user's cell phone (or other BT devices), and

search or scan, at this time the phone will search for Search for all the BT devices in the neighborhood, click the name of the searched headset QS-002, after successful pairing and connection, you can make cell phone calls, listen to songs. Then you can make phone calls and listen to songs. 4 Clear Pairing

Power on unconnected state: Left/right headset turns off after 5 consecutive clicks on the left/right headset (clears all information of pairing and connection)



# Function key operation





is (dong dong)

■ Talk Mode



## Names And Contents Of Hazardous Substances In Products

Part Names	Harmful Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	0	0	0	0	0	0
Small structural parts such as shell	0	0	0	0	0	0

nomogeneous materials of the part is in below the limit required by X:Indicates that the hazardous substance at least in a certain homogeneous material of the part exceeds The limit requirements.

O:Indicates that the content of the hazardous substance in all

The parts marked with "X" on the form are all harmful due to the limitations of global technological development. Substitution of substance Including printed circuit boards and their parts, electronic components

etc.and depending on the product model, the earbuds you purchased may not contain all the above components. Electronic and electrical products sold in the

People's Republic of China must mark this LOGO, the ber in the logo represents the product under normal

> Certificate of Approval Product No: Production Time: (PASS) QC:

Warranty statement:
The product attached to this document is guaranteed as follows:If the product is twelve (12) months from the date of purchase("Warranty Period") under normal conditions of use due to quality defects damaged, can be repaired.Free repair; free replacement if the manufacturer confirms that it cannot be repaired; repaired or replaced product. Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 50 days). Purchased by sale the ticket date shall prevail; if the purchase date cannot be determined, the warranty of the continue of the product service hotline first and execute it in the manner instructed by us When applying for warranty, please and to provide an accurate, complete and clearly filled out valid sales invoice. The above guarantee does not apply to the following situations: Exceeding the validity period of the three packs; Altering the warranty card and product code does not match the product body; Couses coused by misuse, abuse or improper transportation, use, maintenance or

S.Couses caused by misuse, abuse or improper transportation, use, maintenance is storage obstacles or damage;
 4.Failure or damage caused by force majeure (such as earthquake,war,disaster, etc.) or accident bad;
 5.The zipper and tower buckle are damaged due to excessive force;
 6.Disconnection or tearing a caused by excessive load;
 7.Any damage caused by sharp objects;
 8.Products with signs of burning of flooding;
 9.Damage caused by unauthorized disassembly;
 10.Acing disentaring advancing number and other losses that occur during the

Do Aging, discoloration, obrasion, rupture and other losses that occur during the normal use of the product.

1.If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materia are not within the scope of the guarantee. You should check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China. Nothing in this document affects consumer rights that cannot be excluded or restricted under the law profit.

E-mail: service@keesion.com







### FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.