

User manual

Model:U152

Brand: unnecto™

Contents:

FOR YOUR SAFETY	2
ABOUT YOUR PHONE	3
GETTING STARTED	4
BASIC FUNCTIONS.....	4
CONTACTS.....	5
WRITING A MESSAGE.....	5
BLUETOOTH.....	5
SIM CARD SETTINGS.....	5
PHONE SETTINGS.....	5
SECURITY.....	6
NETWORK SETTINGS	7
FCC CAUTION.....	8
LEGAL INFORMATION	9

Specifications of Battery and Charger

Battery: Li-ion 3.7 V|800 mAh|2.96 Wh

Max Charging Voltage: 4.2 V

Charger: Input: 100-240 VAC|50/60 Hz|150 mA

Output: DC 5.0 V|550 mA

For Your Safety

1. Road Safety

Always keep your hands free to operate your vehicle while driving. Park your vehicle before using your phone.

2. Turning off your phone for air travel

Use of wireless telephones in an aircraft may disrupt the operation of the aircraft. It is dangerous and illegal. Please ensure that the phone is turned off before going aboard.

3. Turn off your phone in hospitals

Follow any restrictions or rules. Switch off your phone near medical equipment.

4. Turn your phone when refueling

Switch off your phone at a gas station.

5. Switch off phones near blast points

Don't use your phone where blasting is in progress. Observe restrictions and follow any regulations or rules.

6. Enhancements and Batteries

Use only the approved enhancements and batteries. Do not connect incompatible products.

7. Emergency Calls

Ensure that the phone is switched on. Enter the emergency number, and then press the call key. Do not end the call until given permission.

1. About your phone



2. Getting started

2.1 Installing the SIM card

Press and hold the power/end key to turn off the phone.

Remove the battery cover and then the battery.

Insert the SIM card into the SIM card holder. Ensure that the metal contacts face the phone.

Re-install the battery. Place the battery cover onto the back of your phone and slide it forward until the latch catches the cover.

Note: A SIM card can be easily damaged if its metal contacts become scratched. Therefore, take special care when holding or inserting it and keep it away from children.

2.2 Charging the battery

The battery is not fully charged when it is first unpacked. It takes three charging-discharging cycles for the battery to reach its peak performance.

Charge a battery according to the following steps:

- Connect the charger to the connection jack of the phone in the proper direction, and connect the charger to a main socket.
- The phone displays "Charger Connected!" and starts charging after properly connected. The battery icon dynamically displays the charging process. In switch-off state, the phone dynamically displays the charging process.
- When the battery is fully charged, the charging process stops automatically, and the battery icon indicates full grid on the screen. After the battery is fully charged, remove the charger from the phone and socket as soon as possible.

3. Basic Functions

3.1 Power on and off

To turn the phone on and off press and hold the power button at the top of the device.

3.2 Make a call

Enter the phone number including the area code. Press Call key to complete the call.

3.3 Make an extension call

When making an extension call, press "*" key several times to get the "P" that is a prefix of extension numbers. It will dial automatically after several seconds since you dialed the telephone number.

3.4 Make an international call

First, enter the country code, then the area code and the phone number, and press the call key. "+" is needed when entering a country code. The "+" icon can be entered by pressing the "*" key several times.

4. Contacts

The phone provides two kinds of storage for your media: the SIM card and the phone internal memory. The phone can store up to 300 entries. The capacity of the SIM card depends on the type of SIM card provided by your network operator.

5. Writing a Message

First choose “New SMS” from the menu. Then choose “Create a new message” and enter your message text. Additionally you can press the menu key (Options) and select the required items, including options to insert template, add contact info, and save to Drafts. You may press the send button when the message is ready to send.

6. Bluetooth

To turn on your Bluetooth, first navigate to the Applications menu and choose Bluetooth and the “On” option. From the Bluetooth menu you can find all other available Bluetooth enabled devices. From the Bluetooth menu you may also connect your hands-free device if it is shown in the list (the Bluetooth connection icon would appear in the status column on the top of screen).

Paired devices will display previous devices connected to the phone’s Bluetooth.

7. SIM Card Settings

When you are on a flight where the use of 2G MOBILE PHONE is prohibited, select “Airplane Mode” so that the phone will not connect to any network. However, alarm and calendar reminder will remain on. You can still use the entertainment features such as the audio player and camera in flight mode.

8. Phone Settings

8.1 Time and date

Set time: Set your time.

Set date: Set the current date

Time format: Format for the time.

Date display type: Set display type

Update time setting: Update date and time automatically from network

8.2 Select language

Select the language for your handset. There are a variety of languages for you to choose: [English], [Francais], [Portugues] and [Espanol] Input method settings: Set input method for text entry.

8.3 Shortcut settings

Set all shortcut keys

8.4 Auto power on/off

Set the time to power on/off the phone automatically.

8.5 Restore factory settings

Reset the phone to default values (factory settings).

To reset the phone, the password is required. By default the password is "1234".

8.6 Display settings

Wallpaper settings: Set the standby image of the phone.

Idle display setting: Set Idle display.

Contrast: Set the backlight brightness.

Keypad backlight time: Set the Keypad backlight timer

Auto keypad lock: The keypad lock prevents unintentional phone usage. However, you can still receive calls and make emergency calls from the phone.

9. Security

The phone provides several security options to protect your phone from misuse.

1. PIN

Open: If you choose to enable your phone PIN you will need to enter the PIN every time you use the device.

Update: to update your PIN you must enter the old PIN first.

Close: enter the correct PIN code.

Warning: Please be careful using this function. Do not forget your password. If your password is forgotten, please consult the network operators. If your code is entered incorrectly 10 times, the SIM card will cease to function.

9.1 Phone lock

If the phone lock is activated, the phone lock password will be requested after the phone turned on. The default password is "1234". If the phone is locked, only emergency calls can be made but calls can still be received.

Modify the cell phone password

The password of your 2G MOBILE PHONE can be reset.

Lock screen by end-key

Set a key lock according to hang up key screen.

Fixed dial number

Open the fixed dial-up function. If not you should find an operator for help.

Blacklist

The phone cannot receive calls from a number if the number was added to the black list of the phone.

10. Network settings

Data account

Customize your Internet account. To add to the Internet account, In the Internet interface, press “Option” and then add new account and input the proper APN settings into the new account. Save the account.

GPRS Service

You can choose to turn Data on/Off

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ -Reorient or relocate the receiving antenna.
- ▶ -Increase the separation between the equipment and receiver.
- ▶ -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

This 2G MOBILE PHONE meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: 2G MOBILE PHONE (FCC ID: 2ADR3U152) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.871W/kg and when properly worn on the body is 1.519W/kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.