


YKY2503 Instruction Manual

Product Location



Description


1. POWER/MODE button	9. Fan
2. PREV button	10. Light
3. PLAY/PAUSE button	11. AUX socket
4. NEXT button	12. TF Card
5. F/L (Fan / Light) button	13. USB
6. VOLUME knob	14. Type-C connector (DC5V/1A)
7. LED Display	15. LED indicator
8. Speaker	16. Wind pipe

Power On/Off


To power on, press and hold the  for over 2 seconds. Without USB or TF, it defaults to Bluetooth mode.

To power off, press and hold the  for over 2 seconds. There are prompt sounds for both actions.


Mode Switching

With USB, TF, or AUX connected, short press  to cycle through modes: BT → USB → TF → AUX. Without connections, it defaults to Bluetooth.

Bluetooth (BT) Function


Short press  to enter BT mode; the display shows "bLUE" and blinks.

Pair with devices named **YKY2503**.

Controls: , Prev, Next. Auto power-off after 30 minutes of inactivity.


USB Playback

Insert USB to switch to USB mode; it starts reading music automatically.


Playback controls: , Prev, Next. Auto power-off after 30 minutes of inactivity.

TF Playback

Insert TF card to switch to TF mode; it reads music automatically.

Playback controls: , Prev, Next. Auto power-off after 30 minutes of inactivity.

AUX IN Function

Insert a 3.5mm audio cable to switch to AUX mode; playback starts with external devices.  mutes sound.

Fan Function

Default fan off. Short press F/L to cycle through fan speeds. Long press NEXT to turn off the fan.

Color Light Function

Default lights on (L-01 mode). Long press F/L to change modes. Long press PREV to turn off lights.

Volume Adjustment

Rotate the VOLUME knob to adjust (00-30).

Charging Function

Built-in battery; USB-C charging (5V, 1A max). Red LED indicates charging.

When the battery is low, the unit will emit a "Biz Biz" sound, and the display will indicate "L0." Please charge the battery immediately..

Forced Reset

Use a toothpick to press the AUX reset switch if frozen.

Reminder

Contains a rechargeable battery.

Charge for 6-8 hours for optimal battery life.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.