

PMN:IP CAMERA

Quick Guide

WiFi Bulb camera



Email: usservice@isecugroup.com

WiFi 2.4G / 5G

Before operating this unit please read these instructions carefully and save them for future use.

Interface description

This manual is suitable for various types of cameras.

(The appearance may be different due to different batches. The details are subject to the receipt. This manual is only for the installation instructions of this series of equipment.)

WiFi Bulb camera



Description

- 1. Reset button**
The working state of the device, long press 5 seconds to restore the factory settings, the camera will have a voice prompt broadcast.
- 2. SD card slot**
TF card, storage video and playback video.
- 3. Power supply**
Power input.

Installation and placement

WiFi Bulb camera



Software Installation

APP Download and installation

Users can search "EseeCloud (IP Pro, VII Cam)" on APP Store or Google Play, or scan the QR code below to install the APP.

Note: For iOS system, it requires IOS 9.0 version or above. For Android Android 4.1 or above.



Step 1

If you are prompted to open certain permissions (such as location, message notification, etc.) during APP installation, click Allow (agree).

Step 2

Account register: Open the APP, click "Register", enter your email or phone number to create an account.

Account login: On the login interface, enter the account/phone number/email, and the corresponding password, and click the "OK" button to log in.

Third-party login: APP supports third-party login. Click the third-party social software icon, jump to the APP to complete the authorization and log in.



Bluetooth adding process with network

*Before adding a camera, please make sure that the Bluetooth function of the mobile phone has been turned on, and do not turn off the Bluetooth during the adding process. If a prompt box pops up during the adding process to enable Bluetooth or Bluetooth authorization, please follow the steps in the prompt to enable it;

Step 1

After the camera is powered on, open the "EseeCloud" APP and click the "+" icon in the upper right corner to enter the interface of adding devices.

(If the permission prompt pops up, click agree)

Step 2

The APP will automatically search for a new device and click the Add button when it finds the device.



(If you do not see the pop-up device box, please click "scan to add" to scan the QR code on the camera body)



Step 3

Enter the WiFi name and password on the distribution network screen.



Step 4

After the network is configured successfully, the system prompts you to enter the device name. Click Next.



Step 5

Users can choose to enable or disable message push according to your own preferences (generally recommended to enable).



Step 6

Congratulations, you have successfully connected the device.

Or you can add camera by WiFi configuration

Step 1

Open the APP, click the "+" icon in the middle of the interface to enter the scan code interface;



Step 2

Click "Camera scan code add" method



Step 3

Check whether the camera light is blinking



Step 4

Point the camera at the QR code that appears on the screen of the phone



Step 5

Click "Camera scan code add" method




Step 6

After the network configuration is successful, set a name for the camera.



Step 7

Click "Camera scan code add" method



Step 8

Click "Camera scan code add" method



Help FAQ

Q1: Why is the pairing network unsuccessful?

- Please make sure that the distance among the camera, the router and the mobile phone should be close enough when configuring the network.
- Please make sure that the WiFi signal connected to the mobile phone 2.4G WiFi and 5G WiFi are both ok.
- Please check whether the WiFi name and password are correct.
- Please long press the reset button for 5 seconds and try again after restoring the camera to the factory settings.



Q2: Why is there no playback?

- Make sure that the TF card has been inserted into the camera and try to turn on/off the camera.
- Enter the camera settings menu to check the storage status "in good condition" (if the status is abnormal, click to "Format the memory card").



Q3: Why is the camera offline?

- It may caused by router WiFi signal interference or network reasons. Power off and restart the optical modem, router or camera.
- The camera maybe too far away from the WiFi router, try to get the camera next to the WiFi router.
- Whether the WiFi password has been changed, try to reset the camera and try pairing again.

After Service

- Thanks for your purchase and support, we appreciate all your valuable feedback.
- If you have any questions about our products, please feel free to contact us.

Email: usservice@isecugroup.com

bulb camera use instruction video



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

ISED Statement

English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada.

L'exploitation est soumise aux deux conditions suivantes :

(1) Cet appareil ne doit pas provoquer d'interférences.

(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

L'appareil numérique du ciem conforme canadien peut - 3 (b) / nmb - 3 (b).

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian Information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

L'appareil destiné à fonctionner dans la bande 5150-5250 MHz est uniquement destiné à une utilisation en intérieur afin de réduire le potentiel d'interférences nuisibles aux systèmes mobiles par satellite cocanaux.

This radio transmitter (ISED certification number: 31926-W3M) has been approved by Industry Canada to operate with the antenna types listed with the maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device. Le présent émetteur radio (ISED certification number: 31926-W3M) a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal. Les types d'antenne non inclus dans cette liste, et dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.