


Lite Bluetooth gamepad — instruction manual



- press **home** to turn on the controller
- press & hold **home** for 3 seconds to turn off the controller
- Press and hold **home** for 8 seconds to force turn off the controller

Switch



- 1 – put the controller on S mode first then press **home** to turn on the controller. LED starts to rotate
 - 2 – press **pair** button for 2 seconds to enter its pairing mode. LED turns off for 1 second then starts to rotate again
 - 3 – go to your Switch Home Page to click on Controllers, then click on Change Grip/Order. LED becomes solid when connection is successful
- controller will auto reconnect to your Switch with the press of **home** once it has been paired

Windows (X - input)



- 1 – put the controller on X mode first then press **home** to turn on the controller. LEDs 1 & 2 start to blink
 - 2 – press **pair** button for 2 seconds to enter its pairing mode. LEDs turn off for 1 second then start to rotate again
 - 3 – go to your Windows device's Bluetooth setting, pair with [8BitDo Lite gamepad]. LED becomes solid when connection is successful
- controller will auto reconnect to your Windows device with the press of **home** once it has been paired
 - USB Connection: connect your 8BitDo Lite controller to your Windows device via USB Cable after step 1

Turbo function



- 1 – hold the button you would like to set turbo functionality to and then press the **star** button to activate/deactivate its turbo functionality
- d-pad and analogue sticks are not included
 - this does not apply to Switch mode

battery



status –		LED indicator –
low battery mode	→	red LED blinks
battery charging	→	red LED stays solid
battery fully charged	→	LED turns off

- built-in 480 mAh Li-on with 18 hours of play time
- rechargeable with 1 – 2 hour charging time

power saving




- 1 minute with no Bluetooth connection, will power off
- 15 minutes with Bluetooth connection but no use, will power off
- press **home** to wake up your controller

support



- please visit support.8bitdo.com for further information & additional support

Lite 蓝牙手柄 — 使用说明



- * 开机: 按 [home] 键。
- * 关机: 按住 [home] 键 3 秒。
- * 按 [home] 键 8 秒可强制关机

Switch



1. 将开关置于 S 档位, 轻按 [home] 键开启手柄, 指示灯滚动闪烁。
 2. 按住 [配对] 键 2 秒, 指示灯熄灭 1 秒后继续滚动闪烁, 手柄进入配对状态。
 3. 打开 Switch 主机 Controllers 设置, 进入 Change Grip / Order 界面, 等待手柄连接, 连接成功后指示灯呈常亮显示。
- * 下次连接轻按 [home] 键可自动连接。

Windows (X - input)



1. 将开关置于 X 档位, 轻按 [home] 键开启手柄, 1、2 号指示灯同时闪烁。
 2. 按住 [配对] 键 2 秒, 指示灯熄灭 1 秒后继续滚动闪烁, 手柄进入配对状态。
 3. 打开 Windows 设备蓝牙, 搜索 [8BitDo Lite gamepad] 连接, 连接成功后指示灯呈常亮显示。
- * 下次连接轻按 [home] 键可自动连接。
 - * 有线连接: 第 1 步后通过 USB 线缆连接到设备。

Turbo 连发功能



- 按下需要设置连发的功能键, 再按下 [星号] 键可开启/关闭按键的连发功能。
- * 左、右摇杆与方向键不支持连发。
 - * 连接 Switch 时不可用。

电池



电量状态		指示灯状态
低电量	→	红灯闪烁
充电中	→	红灯常亮
充电完成	→	指示灯熄灭

- * 内置 480mAh 锂电池, 可持续使用约 18 小时。
- * 可使用配备的 USB 线缆进行充电, 充电时间约 1~2 小时, 充电完成后指示灯熄灭。

自动关机



- * 开机后 1 分钟内无连接或连接后 15 分钟无操作会自动关机。
- * 使用时按 [home] 键唤醒可自动连接。

固件升级



- * 请访问 <http://support.8bitdo.cn/> 了解详细信息。

FCC Statement

15.19

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

15.21

Note: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

15.105(b)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help