Orthogonal Axis	X
Test Mode	UNII-2A_TX N (HT20) Mode 5320 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7095.7230	49.64	-3.12	46.52	68.30	-21.78	Peak	
2 *	10640.0750	34.11	2.78	36.89	54.00	-17.11	AVG	
3	10640.8250	47.96	2.78	50.74	74.00	-23.26	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX N (HT40) Mode 5270 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5272.9000	51.14	39.22	90.36	68.30	22.06	Peak	NO limit
2	5273.0000	43.23	39.22	82.45	999.00	-916.55	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX N (HT40) Mode 5270 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7024.9350	51.19	-3.25	47.94	68.30	-20.36	Peak	
2 *	10540.0050	47.28	2.33	49.61	68.30	-18.69	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX N (HT40) Mode 5270 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5267.5000	43.85	39.22	83.07	999.00	-915.93	AVG	NO limit
2 *	5273.5000	51.40	39.22	90.62	68.30	22.32	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX N (HT40) Mode 5270 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7026.4850	50.06	-3.25	46.81	68.30	-21.49	Peak	
2 *	10538.0050	47.43	2.32	49.75	68.30	-18.55	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX N (HT40) Mode 5310 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5313.5000	50.87	39.27	90.14	68.30	21.84	Peak	NO limit
2	5314.4000	44.92	39.28	84.20	999.00	-914.80	AVG	NO limit
3	5350.0000	21.51	39.32	60.83	74.00	-13.17	Peak	
4	5350.0000	6.56	39.32	45.88	54.00	-8.12	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX N (HT40) Mode 5310 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7080.9650	50.09	-3.15	46.94	68.30	-21.36	Peak	
2	10619.7850	47.03	2.69	49.72	74.00	-24.28	Peak	
3 *	10622.4600	34.46	2.70	37.16	54.00	-16.84	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX N (HT40) Mode 5310 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5307.5000	44.72	39.27	83.99	999.00	-915.01	AVG	NO limit
2 *	5314.0000	46.12	39.28	85.40	68.30	17.10	Peak	NO limit
3	5350.0000	21.68	39.32	61.00	74.00	-13.00	Peak	
4	5350.0000	6.85	39.32	46.17	54.00	-7.83	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX N (HT40) Mode 5310 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7081.7000	49.73	-3.15	46.58	68.30	-21.72	Peak	
2	10620.9000	47.80	2.69	50.49	74.00	-23.51	Peak	
3 *	10622.1900	34.48	2.70	37.18	54.00	-16.82	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX A Mode 5500 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5460.0000	20.70	39.46	60.16	74.00	-13.84	Peak	
2	5460.0000	6.12	39.46	45.58	54.00	-8.42	AVG	
3	5470.0000	18.89	39.47	58.36	68.30	-9.94	Peak	
4 *	5497.2000	53.50	39.51	93.01	68.30	24.71	Peak	NO limit
5	5501.0000	49.02	39.51	88.53	999.00	-910.47	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX A Mode 5500 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7333.3530	49.28	-2.70	46.58	74.00	-27.42	Peak	
2	7343.2930	36.89	-2.68	34.21	54.00	-19.79	AVG	
3 *	11000.9400	34.13	4.40	38.53	54.00	-15.47	AVG	
4	11001.5300	46.31	4.40	50.71	74.00	-23.29	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX A Mode 5500 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5460.0000	20.96	39.46	60.42	74.00	-13.58	Peak	
2	5460.0000	5.99	39.46	45.45	54.00	-8.55	AVG	
3	5470.0000	20.25	39.47	59.72	68.30	-8.58	Peak	
4	5500.9000	48.41	39.51	87.92	999.00	-911.08	AVG	NO limit
5 *	5502.7000	53.86	39.52	93.38	68.30	25.08	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX A Mode 5500 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7332.1600	48.68	-2.70	45.98	74.00	-28.02	Peak	
2	7341.4000	36.90	-2.68	34.22	54.00	-19.78	AVG	
3	11003.5150	46.78	4.40	51.18	74.00	-22.82	Peak	
4 *	11003.7550	34.05	4.40	38.45	54.00	-15.55	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX A Mode 5580 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5580.8000	51.65	39.70	91.35	999.00	-907.65	AVG	NO limit
2 *	5582.7000	53.72	39.71	93.43	68.30	25.13	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX A Mode 5580 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7439.8550	37.24	-2.50	34.74	54.00	-19.26	AVG	
2	7448.4150	48.17	-2.49	45.68	74.00	-28.32	Peak	
3	11159.1550	46.72	4.22	50.94	74.00	-23.06	Peak	
4 *	11161.2850	34.06	4.22	38.28	54.00	-15.72	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX A Mode 5580 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5580.9000	49.91	39.70	89.61	999.00	-909.39	AVG	NO limit
2 *	5582.7000	54.84	39.71	94.55	68.30	26.25	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX A Mode 5580 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7437.6200	49.15	-2.51	46.64	74.00	-27.36	Peak	
2	7439.9350	36.92	-2.50	34.42	54.00	-19.58	AVG	
3 *	11158.1550	34.00	4.22	38.22	54.00	-15.78	AVG	
4	11160.7850	47.19	4.22	51.41	74.00	-22.59	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX A Mode 5700 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5699.2000	49.94	39.98	89.92	999.00	-909.08	AVG	NO limit
2 *	5702.5000	52.07	39.99	92.06	68.30	23.76	Peak	NO limit
3	5725.0000	19.63	40.05	59.68	68.30	-8.62	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX A Mode 5700 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7599.0600	49.09	-2.27	46.82	74.00	-27.18	Peak	
2	7600.1350	38.42	-2.27	36.15	54.00	-17.85	AVG	
3 *	11397.5150	34.03	3.95	37.98	54.00	-16.02	AVG	
4	11397.6900	46.51	3.95	50.46	74.00	-23.54	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX A Mode 5700 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5702.6000	48.91	39.99	88.90	999.00	-910.10	AVG	NO limit
2 *	5703.2000	53.57	39.99	93.56	68.30	25.26	Peak	NO limit
3	5725.0000	20.62	40.05	60.67	68.30	-7.63	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX A Mode 5700 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7598.7600	48.65	-2.27	46.38	74.00	-27.62	Peak	
2	7600.0600	37.04	-2.27	34.77	54.00	-19.23	AVG	
3 *	11397.8949	34.08	3.95	38.03	54.00	-15.97	AVG	
4	11399.1950	46.65	3.94	50.59	74.00	-23.41	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT20) Mode 5500 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5460.0000	20.07	39.46	59.53	74.00	-14.47	Peak	
2	5460.0000	6.01	39.46	45.47	54.00	-8.53	AVG	
3	5470.0000	22.29	39.47	61.76	68.30	-6.54	Peak	
4 *	5499.3000	52.53	39.51	92.04	68.30	23.74	Peak	NO limit
5	5500.8000	47.96	39.51	87.47	999.00	-911.53	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT20) Mode 5500 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7331.5650	48.79	-2.70	46.09	74.00	-27.91	Peak	
2	7333.5100	37.01	-2.70	34.31	54.00	-19.69	AVG	
3	11001.9850	44.63	4.40	49.03	74.00	-24.97	Peak	
4 *	11003.7250	34.42	4.40	38.82	54.00	-15.18	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT20) Mode 5500 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5460.0000	21.85	39.46	61.31	74.00	-12.69	Peak	
2	5460.0000	4.72	39.46	44.18	54.00	-9.82	AVG	
3	5470.0000	20.97	39.47	60.44	68.30	-7.86	Peak	
4	5499.3000	46.20	39.51	85.71	999.00	-913.29	AVG	NO limit
5 *	5501.4000	52.65	39.51	92.16	68.30	23.86	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT20) Mode 5500 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7333.4650	37.04	-2.70	34.34	54.00	-19.66	AVG	
2	7334.2450	49.39	-2.69	46.70	74.00	-27.30	Peak	
3 *	10998.6200	34.36	4.39	38.75	54.00	-15.25	AVG	
4	10999.1750	47.94	4.40	52.34	74.00	-21.66	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT20) Mode 5580 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5581.2000	49.76	39.70	89.46	999.00	-909.54	AVG	NO limit
2 *	5583.9000	51.77	39.71	91.48	68.30	23.18	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT20) Mode 5580 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7439.9250	49.41	-2.50	46.91	74.00	-27.09	Peak	
2	7439.9250	37.48	-2.50	34.98	54.00	-19.02	AVG	
3	11157.5100	47.15	4.22	51.37	74.00	-22.63	Peak	
4 *	11159.9050	34.26	4.22	38.48	54.00	-15.52	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT20) Mode 5580 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5572.8000	51.93	39.68	91.61	68.30	23.31	Peak	
2	5581.4000	47.68	39.70	87.38	999.00	-911.62	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT20) Mode 5580 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7438.0750	49.38	-2.51	46.87	74.00	-27.13	Peak	
2	7440.0400	37.76	-2.50	35.26	54.00	-18.74	AVG	
3 *	11160.0350	34.42	4.22	38.64	54.00	-15.36	AVG	
4	11160.1350	47.35	4.22	51.57	74.00	-22.43	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT20) Mode 5700 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5698.6000	49.19	39.98	89.17	999.00	-909.83	AVG	NO limit
2 *	5702.6000	51.81	39.99	91.80	68.30	23.50	Peak	NO limit
3	5725.0000	22.41	40.05	62.46	68.30	-5.84	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT20) Mode 5700 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7600.0950	38.49	-2.27	36.22	54.00	-17.78	AVG	
2	7600.6800	48.64	-2.27	46.37	74.00	-27.63	Peak	
3 *	11397.7500	33.89	3.95	37.84	54.00	-16.16	AVG	
4	11398.1250	46.41	3.95	50.36	74.00	-23.64	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT20) Mode 5700 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5702.2000	52.26	39.99	92.25	68.30	23.95	Peak	NO limit
2	5703.1000	47.51	39.99	87.50	999.00	-911.50	AVG	NO limit
3	5745.0000	20.93	40.09	61.02	68.30	-7.28	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT20) Mode 5700 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7600.0350	37.03	-2.27	34.76	54.00	-19.24	AVG	
2	7600.3850	50.03	-2.27	47.76	74.00	-26.24	Peak	
3 *	11397.5850	34.08	3.95	38.03	54.00	-15.97	AVG	
4	11399.2550	46.56	3.94	50.50	74.00	-23.50	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT40) Mode 5510 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5460.0000	20.04	39.46	59.50	74.00	-14.50	Peak	
2	5460.0000	5.09	39.46	44.55	54.00	-9.45	AVG	
3	5470.0000	19.79	39.47	59.26	68.30	-9.04	Peak	
4 *	5506.2000	48.34	39.52	87.86	68.30	19.56	Peak	NO limit
5	5513.3000	43.53	39.54	83.07	999.00	-915.93	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT40) Mode 5510 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	11018.8600	34.35	4.38	38.73	54.00	-15.27	AVG	
2	11019.3550	47.01	4.38	51.39	74.00	-22.61	Peak	
3	7366.8070	37.27	-2.64	34.63	54.00	-19.37	AVG	
4	7366.6820	50.01	-2.64	47.37	74.00	-26.63	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT40) Mode 5510 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5460.0000	20.64	39.46	60.10	74.00	-13.90	Peak	
2	5460.0000	5.16	39.46	44.62	54.00	-9.38	AVG	
3	5470.0000	22.33	39.47	61.80	68.30	-6.50	Peak	
4	5506.2000	42.48	39.52	82.00	999.00	-917.00	AVG	NO limit
5 *	5514.5000	45.74	39.54	85.28	68.30	16.98	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT40) Mode 5510 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7368.8370	49.74	-2.63	47.11	74.00	-26.89	Peak	
2	7369.1070	37.21	-2.63	34.58	54.00	-19.42	AVG	
3 *	11018.1600	34.19	4.38	38.57	54.00	-15.43	AVG	
4	11018.7350	47.10	4.38	51.48	74.00	-22.52	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT40) Mode 5550 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5554.4000	52.51	39.64	92.15	68.30	23.85	Peak	NO limit
2	5554.6000	45.06	39.64	84.70	999.00	-914.30	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT40) Mode 5550 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7397.6200	48.66	-2.58	46.08	74.00	-27.92	Peak	
2	7398.6400	36.49	-2.58	33.91	54.00	-20.09	AVG	
3	11100.6750	47.78	4.29	52.07	74.00	-21.93	Peak	
4 *	11102.0650	34.42	4.28	38.70	54.00	-15.30	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT40) Mode 5550 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5554.6000	44.42	39.64	84.06	999.00	-914.94	AVG	NO limit
2 *	5561.4000	49.62	39.66	89.28	68.30	20.98	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT40) Mode 5550 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7398.8650	49.91	-2.58	47.33	74.00	-26.67	Peak	
2	7399.8300	37.03	-2.58	34.45	54.00	-19.55	AVG	
3	11099.9100	47.99	4.29	52.28	74.00	-21.72	Peak	
4 *	11099.9700	34.54	4.29	38.83	54.00	-15.17	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT40) Mode 5670 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5665.6000	46.07	39.90	85.97	999.00	-913.03	AVG	NO limit
2 *	5668.7000	52.61	39.91	92.52	68.30	24.22	Peak	NO limit
3	5725.0000	20.29	40.05	60.34	68.30	-7.96	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT40) Mode 5670 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7560.0950	38.90	-2.32	36.58	54.00	-17.42	AVG	
2	7560.3750	49.04	-2.32	46.72	74.00	-27.28	Peak	
3	11337.4700	47.31	4.02	51.33	74.00	-22.67	Peak	
4 *	11338.6350	34.30	4.01	38.31	54.00	-15.69	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT40) Mode 5670 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5659.0000	44.46	39.89	84.35	999.00	-914.65	AVG	NO limit
2 *	5659.5000	49.33	39.89	89.22	68.30	20.92	Peak	NO limit
3	5725.0000	21.86	40.05	61.91	68.30	-6.39	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX N (HT40) Mode 5670 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7560.5500	46.56	-2.32	44.24	74.00	-29.76	Peak	
2	7560.5500	36.41	-2.32	34.09	54.00	-19.91	AVG	
3 *	11338.7550	33.88	4.01	37.89	54.00	-16.11	AVG	
4	11339.2400	40.61	4.01	44.62	74.00	-29.38	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX A Mode 5745 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5715.0000	19.90	40.02	59.92	109.40	-49.48	Peak	
2	5725.0000	19.87	40.05	59.92	122.20	-62.28	Peak	
3 *	5743.2000	51.46	40.09	91.55	122.20	-30.65	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX A Mode 5745 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7659.8550	48.82	-2.20	46.62	74.00	-27.38	Peak	
2	7660.3200	36.23	-2.20	34.03	54.00	-19.97	AVG	
3	11488.9600	47.47	3.84	51.31	74.00	-22.69	Peak	
4 *	11489.5550	34.23	3.84	38.07	54.00	-15.93	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX A Mode 5745 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5715.0000	19.68	40.02	59.70	109.40	-49.70	Peak	
2	5725.0000	19.52	40.05	59.57	122.20	-62.63	Peak	
3 *	5743.1000	54.79	40.09	94.88	122.20	-27.32	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX A Mode 5745 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7658.4050	48.89	-2.20	46.69	74.00	-27.31	Peak	
2	7659.7900	36.01	-2.20	33.81	54.00	-20.19	AVG	
3 *	11487.6400	34.14	3.84	37.98	54.00	-16.02	AVG	
4	11490.6750	46.81	3.84	50.65	74.00	-23.35	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX A Mode 5785 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5715.0000	20.35	40.02	60.37	109.40	-49.03	Peak	
2	5725.0000	21.01	40.05	61.06	122.20	-61.14	Peak	
3 *	5786.0600	49.11	40.19	89.30	122.20	-32.90	Peak	
4	5850.0000	21.49	40.34	61.83	122.20	-60.37	Peak	
5	5860.0000	22.24	40.37	62.61	109.40	-46.79	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX A Mode 5785 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7713.2080	36.12	-2.13	33.99	54.00	-20.01	AVG	
2	7713.5880	48.67	-2.13	46.54	74.00	-27.46	Peak	
3	11567.8700	46.86	3.79	50.65	74.00	-23.35	Peak	
4 *	11568.1050	34.24	3.79	38.03	54.00	-15.97	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX A Mode 5785 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5715.0000	19.33	40.02	59.35	109.40	-50.05	Peak	
2	5725.0000	20.75	40.05	60.80	122.20	-61.40	Peak	
3 *	5785.6000	51.62	40.19	91.81	122.20	-30.39	Peak	
4	5850.0000	19.57	40.34	59.91	122.20	-62.29	Peak	
5	5860.0000	21.58	40.37	61.95	109.40	-47.45	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX A Mode 5785 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7713.1630	48.53	-2.13	46.40	74.00	-27.60	Peak	
2	7714.0830	35.93	-2.13	33.80	54.00	-20.20	AVG	
3 *	11568.7200	34.19	3.79	37.98	54.00	-16.02	AVG	
4	11569.1500	46.77	3.79	50.56	74.00	-23.44	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX A Mode 5825 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5825.8000	48.36	40.29	88.65	122.20	-33.55	Peak	
2	5850.0000	21.35	40.34	61.69	122.20	-60.51	Peak	
3	5860.0000	21.15	40.37	61.52	109.40	-47.88	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX A Mode 5825 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7764.2370	48.62	-2.07	46.55	68.30	-21.75	Peak	
2	11652.3450	46.10	3.74	49.84	74.00	-24.16	Peak	
3 *	11652.4700	34.05	3.74	37.79	54.00	-16.21	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX A Mode 5825 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5826.2000	51.57	40.29	91.86	122.20	-30.34	Peak	
2	5850.0000	22.88	40.34	63.22	122.20	-58.98	Peak	
3	5860.0000	20.82	40.37	61.19	109.40	-48.21	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX A Mode 5825 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7766.5220	48.27	-2.06	46.21	68.30	-22.09	Peak	
2	11648.8450	46.38	3.74	50.12	74.00	-23.88	Peak	
3 *	11652.4550	33.88	3.74	37.62	54.00	-16.38	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT20) Mode 5745 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5715.0000	21.42	40.02	61.44	109.40	-47.96	Peak	
2	5725.0000	19.83	40.05	59.88	122.20	-62.32	Peak	
3 *	5737.6000	49.63	40.08	89.71	122.20	-32.49	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT20) Mode 5745 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7658.7250	49.30	-2.20	47.10	74.00	-26.90	Peak	
2	7660.0550	36.20	-2.20	34.00	54.00	-20.00	AVG	
3 *	11487.6200	34.31	3.84	38.15	54.00	-15.85	AVG	
4	11492.1350	47.80	3.84	51.64	74.00	-22.36	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT20) Mode 5745 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5715.0000	20.59	40.02	60.61	109.40	-48.79	Peak	
2	5725.0000	19.73	40.05	59.78	122.20	-62.42	Peak	
3 *	5743.2000	52.00	40.09	92.09	122.20	-30.11	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT20) Mode 5745 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7659.6750	36.50	-2.20	34.30	54.00	-19.70	AVG	
2	7660.0850	48.66	-2.20	46.46	74.00	-27.54	Peak	
3 *	11488.4400	34.20	3.84	38.04	54.00	-15.96	AVG	
4	11492.1350	46.91	3.84	50.75	74.00	-23.25	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT20) Mode 5785 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5715.0000	21.20	40.02	61.22	109.40	-48.18	Peak	
2	5725.0000	20.81	40.05	60.86	122.20	-61.34	Peak	
3 *	5786.0000	48.89	40.19	89.08	122.20	-33.12	Peak	
4	5850.0000	21.93	40.34	62.27	122.20	-59.93	Peak	
5	5860.0000	20.13	40.37	60.50	109.40	-48.90	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT20) Mode 5785 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7713.4080	35.96	-2.13	33.83	54.00	-20.17	AVG	
2	7714.1480	48.13	-2.13	46.00	74.00	-28.00	Peak	
3 *	11567.5500	34.27	3.79	38.06	54.00	-15.94	AVG	
4	11568.8200	46.27	3.79	50.06	74.00	-23.94	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT20) Mode 5785 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5715.0000	20.90	40.02	60.92	109.40	-48.48	Peak	
2	5725.0000	20.77	40.05	60.82	122.20	-61.38	Peak	
3 *	5787.5000	52.13	40.19	92.32	122.20	-29.88	Peak	
4	5850.0000	20.88	40.34	61.22	122.20	-60.98	Peak	
5	5860.0000	19.14	40.37	59.51	109.40	-49.89	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT20) Mode 5785 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7713.1980	48.40	-2.13	46.27	74.00	-27.73	Peak	
2	7713.5180	36.58	-2.13	34.45	54.00	-19.55	AVG	
3	11568.3650	46.78	3.79	50.57	74.00	-23.43	Peak	
4 *	11568.7200	34.31	3.79	38.10	54.00	-15.90	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT20) Mode 5825 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5826.6000	47.80	40.29	88.09	122.20	-34.11	Peak	
2	5850.0000	20.60	40.34	60.94	122.20	-61.26	Peak	
3	5860.0000	19.48	40.37	59.85	109.40	-49.55	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT20) Mode 5825 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7766.1820	48.05	-2.06	45.99	68.30	-22.31	Peak	
2	11651.0850	47.20	3.74	50.94	74.00	-23.06	Peak	
3 *	11651.6050	33.08	3.74	36.82	54.00	-17.18	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT20) Mode 5825 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5829.3000	51.27	40.29	91.56	122.20	-30.64	Peak	
2	5850.0000	21.23	40.34	61.57	122.20	-60.63	Peak	
3	5860.0000	22.42	40.37	62.79	109.40	-46.61	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT20) Mode 5825 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7765.1570	48.27	-2.06	46.21	68.30	-22.09	Peak	
2	11652.6350	46.24	3.74	49.98	74.00	-24.02	Peak	
3 *	11652.6950	33.92	3.74	37.66	54.00	-16.34	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT40) Mode 5755 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5715.0000	20.79	40.02	60.81	109.40	-48.59	Peak	
2	5725.0000	20.53	40.05	60.58	122.20	-61.62	Peak	
3 *	5764.2000	44.63	40.14	84.77	122.20	-37.43	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT40) Mode 5755 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7671.4130	48.80	-2.18	46.62	74.00	-27.38	Peak	
2	7673.1780	36.58	-2.18	34.40	54.00	-19.60	AVG	
3 *	11507.8800	34.41	3.82	38.23	54.00	-15.77	AVG	
4	11508.7699	47.25	3.82	51.07	74.00	-22.93	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT40) Mode 5755 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5715.0000	20.60	40.02	60.62	109.40	-48.78	Peak	
2	5725.0000	20.07	40.05	60.12	122.20	-62.08	Peak	
3 *	5748.8000	48.27	40.10	88.37	122.20	-33.83	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT40) Mode 5755 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7670.9480	36.49	-2.18	34.31	54.00	-19.69	AVG	
2	7672.4680	49.12	-2.18	46.94	74.00	-27.06	Peak	
3	11507.9500	47.73	3.82	51.55	74.00	-22.45	Peak	
4 *	11508.2950	34.60	3.82	38.42	54.00	-15.58	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT40) Mode 5795 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5715.0000	21.63	40.02	61.65	109.40	-47.75	Peak	
2	5725.0000	19.99	40.05	60.04	122.20	-62.16	Peak	
3 *	5790.2000	45.91	40.20	86.11	122.20	-36.09	Peak	
4	5850.0000	18.95	40.34	59.29	122.20	-62.91	Peak	
5	5860.0000	21.29	40.37	61.66	109.40	-47.74	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT40) Mode 5795 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7726.6520	36.43	-2.11	34.32	54.00	-19.68	AVG	
2	7727.7470	48.99	-2.11	46.88	74.00	-27.12	Peak	
3 *	11591.2800	34.51	3.77	38.28	54.00	-15.72	AVG	
4	11592.1400	47.50	3.77	51.27	74.00	-22.73	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT40) Mode 5795 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5715.0000	22.19	40.02	62.21	109.40	-47.19	Peak	
2	5725.0000	21.56	40.05	61.61	122.20	-60.59	Peak	
3 *	5803.9000	47.81	40.23	88.04	122.20	-34.16	Peak	
4	5850.0000	21.65	40.34	61.99	122.20	-60.21	Peak	
5	5860.0000	21.22	40.37	61.59	109.40	-47.81	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-3_TX N (HT40) Mode 5795 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7626.2280	36.65	-2.24	34.41	54.00	-19.59	AVG	
2	7626.7530	49.10	-2.24	46.86	74.00	-27.14	Peak	
3	11591.2100	47.57	3.77	51.34	74.00	-22.66	Peak	
4 *	11594.3400	34.52	3.77	38.29	54.00	-15.71	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT20) Mode 5180 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5150.0000	20.66	39.07	59.73	74.00	-14.27	Peak	
2	5150.0000	8.04	39.07	47.11	54.00	-6.89	AVG	
3 *	5176.3000	52.23	39.10	91.33	68.30	23.03	Peak	NO limit
4	5180.7000	47.69	39.11	86.80	999.00	-912.20	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT20) Mode 5180 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	6906.8520	48.36	-3.63	44.73	68.30	-23.57	Peak	
2 *	10360.7400	46.43	2.13	48.56	68.30	-19.74	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT20) Mode 5180 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5150.0000	20.26	39.07	59.33	74.00	-14.67	Peak	
2	5150.0000	8.15	39.07	47.22	54.00	-6.78	AVG	
3	5178.7000	47.29	39.11	86.40	999.00	-912.60	AVG	NO limit
4 *	5179.3000	54.07	39.11	93.18	68.30	24.88	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT20) Mode 5180 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	6906.5370	48.86	-3.63	45.23	68.30	-23.07	Peak	
2 *	10357.1449	46.17	2.13	48.30	68.30	-20.00	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT20) Mode 5200 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5201.1000	47.15	39.13	86.28	999.00	-912.72	AVG	NO limit
2 *	5201.2000	51.88	39.13	91.01	68.30	22.71	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT20) Mode 5200 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	6933.3180	49.18	-3.53	45.65	68.30	-22.65	Peak	
2 *	10399.4300	45.52	2.14	47.66	68.30	-20.64	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT20) Mode 5200 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5196.8000	46.26	39.13	85.39	999.00	-913.61	AVG	NO limit
2 *	5201.2000	53.67	39.13	92.80	68.30	24.50	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT20) Mode 5200 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	6933.9580	49.53	-3.53	46.00	68.30	-22.30	Peak	
2 *	10398.4950	46.28	2.14	48.42	68.30	-19.88	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT20) Mode 5240 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5241.4000	52.96	39.18	92.14	68.30	23.84	Peak	NO limit
2	5243.0000	47.37	39.19	86.56	999.00	-912.44	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT20) Mode 5240 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	6986.1350	50.44	-3.34	47.10	68.30	-21.20	Peak	
2 *	10479.3250	46.77	2.15	48.92	68.30	-19.38	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT20) Mode 5240 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5240.6000	46.79	39.18	85.97	999.00	-913.03	AVG	NO limit
2 *	5244.5000	49.05	39.19	88.24	68.30	19.94	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT20) Mode 5240 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	6986.3600	51.02	-3.34	47.68	68.30	-20.62	Peak	
2 *	10480.1600	46.61	2.15	48.76	68.30	-19.54	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT40) Mode 5190 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5150.0000	20.13	39.07	59.20	74.00	-14.80	Peak	
2	5150.0000	8.09	39.07	47.16	54.00	-6.84	AVG	
3 *	5188.5000	47.65	39.12	86.77	68.30	18.47	Peak	NO limit
4	5193.3000	43.87	39.12	82.99	999.00	-916.01	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT40) Mode 5190 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	6920.2650	50.60	-3.58	47.02	68.30	-21.28	Peak	
2 *	10378.0900	46.69	2.13	48.82	68.30	-19.48	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT40) Mode 5190 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5150.0000	20.20	39.07	59.27	74.00	-14.73	Peak	
2	5150.0000	8.12	39.07	47.19	54.00	-6.81	AVG	
3	5187.1000	43.14	39.12	82.26	999.00	-916.74	AVG	NO limit
4 *	5193.3000	50.24	39.12	89.36	68.30	21.06	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT40) Mode 5190 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	6918.6550	49.27	-3.59	45.68	68.30	-22.62	Peak	
2 *	10379.4850	46.03	2.13	48.16	68.30	-20.14	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT40) Mode 5230 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5150.0000	21.54	39.07	60.61	74.00	-13.39	Peak	
2	5150.0000	8.22	39.07	47.29	54.00	-6.71	AVG	
3 *	5228.4000	48.69	39.17	87.86	68.30	19.56	Peak	NO limit
4	5233.1000	43.52	39.17	82.69	999.00	-916.31	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT40) Mode 5230 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	6973.1380	49.79	-3.39	46.40	68.30	-21.90	Peak	
2 *	10461.7350	46.63	2.14	48.77	68.30	-19.53	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT40) Mode 5230 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5150.0000	20.29	39.07	59.36	74.00	-14.64	Peak	
2	5150.0000	8.45	39.07	47.52	54.00	-6.48	AVG	
3	5226.3000	43.66	39.17	82.83	999.00	-916.17	AVG	NO limit
4 *	5232.8000	49.49	39.17	88.66	68.30	20.36	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT40) Mode 5230 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	6973.1130	50.54	-3.39	47.15	68.30	-21.15	Peak	
2 *	10458.8300	47.09	2.14	49.23	68.30	-19.07	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT80) Mode 5210 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5150.0000	19.63	39.07	58.70	74.00	-15.30	Peak	
2	5150.0000	7.77	39.07	46.84	54.00	-7.16	AVG	
3	5216.0000	38.12	39.15	77.27	999.00	-921.73	AVG	NO limit
4 *	5228.4000	43.36	39.17	82.53	68.30	14.23	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT80) Mode 5210 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	6946.4670	49.91	-3.49	46.42	68.30	-21.88	Peak	
2 *	10417.6350	47.53	2.14	49.67	68.30	-18.63	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT80) Mode 5210 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5150.0000	20.83	39.07	59.90	74.00	-14.10	Peak	
2	5150.0000	8.04	39.07	47.11	54.00	-6.89	AVG	
3	5203.6000	37.42	39.14	76.56	999.00	-922.44	AVG	NO limit
4 *	5230.6000	44.11	39.17	83.28	68.30	14.98	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-1_TX AC (VHT80) Mode 5210 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	6945.8720	50.29	-3.49	46.80	68.30	-21.50	Peak	
2 *	10421.5599	47.52	2.14	49.66	68.30	-18.64	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT20) Mode 5260 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5261.4000	53.07	39.21	92.28	68.30	23.98	Peak	NO limit
2	5263.1000	47.17	39.21	86.38	999.00	-912.62	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT20) Mode 5260 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7013.1100	50.03	-3.27	46.76	68.30	-21.54	Peak	
2 *	10518.8300	46.47	2.23	48.70	68.30	-19.60	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT20) Mode 5260 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5258.7000	46.72	39.21	85.93	999.00	-913.07	AVG	NO limit
2 *	5261.3000	54.32	39.21	93.53	68.30	25.23	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT20) Mode 5260 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7011.0950	50.01	-3.27	46.74	68.30	-21.56	Peak	
2 *	10519.7300	47.12	2.24	49.36	68.30	-18.94	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT20) Mode 5300 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5301.1000	56.43	39.26	95.69	68.30	27.39	Peak	NO limit
2	5303.1000	48.73	39.26	87.99	999.00	-911.01	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT20) Mode 5300 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7066.5200	50.14	-3.17	46.97	68.30	-21.33	Peak	
2 *	10598.3150	47.00	2.59	49.59	68.30	-18.71	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT20) Mode 5300 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5298.7000	48.99	39.26	88.25	999.00	-910.75	AVG	NO limit
2 *	5301.1000	55.34	39.26	94.60	68.30	26.30	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT20) Mode 5300 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7066.5500	49.54	-3.17	46.37	68.30	-21.93	Peak	
2 *	10599.3300	46.77	2.60	49.37	68.30	-18.93	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT20) Mode 5320 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5318.8000	49.11	39.28	88.39	999.00	-910.61	AVG	NO limit
2 *	5322.0000	54.64	39.29	93.93	68.30	25.63	Peak	NO limit
3	5350.0000	21.11	39.32	60.43	74.00	-13.57	Peak	
4	5350.0000	7.23	39.32	46.55	54.00	-7.45	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT20) Mode 5320 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7093.5180	50.16	-3.13	47.03	68.30	-21.27	Peak	
2 *	10638.3050	34.27	2.77	37.04	54.00	-16.96	AVG	
3	10640.1150	46.72	2.78	49.50	74.00	-24.50	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT20) Mode 5320 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5318.7000	49.17	39.28	88.45	999.00	-910.55	AVG	NO limit
2 *	5324.5000	54.06	39.29	93.35	68.30	25.05	Peak	NO limit
3	5350.0000	22.86	39.32	62.18	74.00	-11.82	Peak	
4	5350.0000	6.92	39.32	46.24	54.00	-7.76	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT20) Mode 5320 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7095.7830	50.07	-3.12	46.95	68.30	-21.35	Peak	
2 *	10638.5250	34.37	2.77	37.14	54.00	-16.86	AVG	
3	10638.6050	46.19	2.77	48.96	74.00	-25.04	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT40) Mode 5270 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5273.2000	43.22	39.22	82.44	999.00	-916.56	AVG	NO limit
2 *	5274.6000	50.61	39.23	89.84	68.30	21.54	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT40) Mode 5270 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7026.4300	50.68	-3.25	47.43	68.30	-20.87	Peak	
2 *	10538.5400	47.48	2.32	49.80	68.30	-18.50	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT40) Mode 5270 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5271.7000	43.90	39.22	83.12	999.00	-915.88	AVG	NO limit
2 *	5273.5000	51.12	39.22	90.34	68.30	22.04	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT40) Mode 5270 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7025.2600	49.96	-3.25	46.71	68.30	-21.59	Peak	
2 *	10541.0599	47.25	2.33	49.58	68.30	-18.72	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT40) Mode 5310 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5311.7000	50.29	39.27	89.56	68.30	21.26	Peak	NO limit
2	5314.2000	44.93	39.28	84.21	999.00	-914.79	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT40) Mode 5310 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7079.3950	49.76	-3.15	46.61	68.30	-21.69	Peak	
2	10620.1650	47.14	2.69	49.83	74.00	-24.17	Peak	
3 *	10621.2750	34.44	2.70	37.14	54.00	-16.86	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT40) Mode 5310 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5307.7000	44.65	39.27	83.92	999.00	-915.08	AVG	NO limit
2 *	5313.1000	50.91	39.27	90.18	68.30	21.88	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT40) Mode 5310 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7079.6850	49.35	-3.15	46.20	68.30	-22.10	Peak	
2	10617.6550	47.42	2.68	50.10	74.00	-23.90	Peak	
3 *	10620.4349	34.59	2.69	37.28	54.00	-16.72	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT80) Mode 5290 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5293.0000	47.02	39.25	86.27	68.30	17.97	Peak	NO limit
2	5296.4000	39.57	39.25	78.82	999.00	-920.18	AVG	NO limit
3	5350.0000	21.23	39.32	60.55	74.00	-13.45	Peak	
4	5350.0000	6.76	39.32	46.08	54.00	-7.92	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT80) Mode 5290 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7052.2080	49.77	-3.20	46.57	68.30	-21.73	Peak	
2 *	10579.0900	47.13	2.51	49.64	68.30	-18.66	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT80) Mode 5290 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5286.8000	46.42	39.24	85.66	68.30	17.36	Peak	NO limit
2	5291.8000	38.75	39.25	78.00	999.00	-921.00	AVG	NO limit
3	5350.0000	21.13	39.32	60.45	74.00	-13.55	Peak	
4	5350.0000	7.28	39.32	46.60	54.00	-7.40	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2A_TX AC (VHT80) Mode 5290 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7052.6530	49.65	-3.20	46.45	68.30	-21.85	Peak	
2 *	10580.4750	47.18	2.51	49.69	68.30	-18.61	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT20) Mode 5500 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5460.0000	18.56	39.46	58.02	74.00	-15.98	Peak	
2	5460.0000	5.67	39.46	45.13	54.00	-8.87	AVG	
3	5470.0000	20.84	39.47	60.31	68.30	-7.99	Peak	
4	5502.9000	47.07	39.52	86.59	999.00	-912.41	AVG	NO limit
5 *	5503.8000	51.20	39.52	90.72	68.30	22.42	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT20) Mode 5500 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7332.6330	49.24	-2.70	46.54	74.00	-27.46	Peak	
2	7333.3680	37.19	-2.70	34.49	54.00	-19.51	AVG	
3	10999.8400	46.68	4.40	51.08	74.00	-22.92	Peak	
4 *	11001.8600	34.34	4.40	38.74	54.00	-15.26	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT20) Mode 5500 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5460.0000	19.83	39.46	59.29	74.00	-14.71	Peak	
2	5460.0000	6.53	39.46	45.99	54.00	-8.01	AVG	
3	5470.0000	19.78	39.47	59.25	68.30	-9.05	Peak	
4	5502.9000	46.66	39.52	86.18	999.00	-912.82	AVG	NO limit
5 *	5507.2000	50.25	39.53	89.78	68.30	21.48	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT20) Mode 5500 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7333.2230	37.05	-2.70	34.35	54.00	-19.65	AVG	
2	7333.4880	49.28	-2.70	46.58	74.00	-27.42	Peak	
3	10999.1500	47.33	4.40	51.73	74.00	-22.27	Peak	
4 *	11000.9650	34.35	4.40	38.75	54.00	-15.25	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT20) Mode 5580 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5579.4000	49.76	39.70	89.46	999.00	-909.54	AVG	NO limit
2 *	5587.6000	51.00	39.72	90.72	68.30	22.42	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT20) Mode 5580 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7439.9000	37.51	-2.50	35.01	54.00	-18.99	AVG	
2	7440.4200	49.97	-2.50	47.47	74.00	-26.53	Peak	
3 *	11157.5800	34.34	4.22	38.56	54.00	-15.44	AVG	
4	11157.9300	47.13	4.22	51.35	74.00	-22.65	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT20) Mode 5580 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5572.8000	51.90	39.68	91.58	68.30	23.28	Peak	NO limit
2	5581.3000	47.74	39.70	87.44	999.00	-911.56	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT20) Mode 5580 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7440.1200	36.84	-2.50	34.34	54.00	-19.66	AVG	
2	7440.1750	49.45	-2.50	46.95	74.00	-27.05	Peak	
3	11159.7550	46.56	4.22	50.78	74.00	-23.22	Peak	
4 *	11160.2750	34.31	4.22	38.53	54.00	-15.47	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT20) Mode 5700 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5698.3000	49.81	39.98	89.79	68.30	21.49	Peak	NO limit
2	5698.7000	48.22	39.98	88.20	999.00	-910.80	AVG	NO limit
3	5725.0000	22.09	40.05	62.14	68.30	-6.16	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT20) Mode 5700 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7598.5700	48.63	-2.27	46.36	74.00	-27.64	Peak	
2	7599.9850	38.56	-2.27	36.29	54.00	-17.71	AVG	
3 *	11399.7050	34.18	3.94	38.12	54.00	-15.88	AVG	
4	11401.1400	46.69	3.94	50.63	74.00	-23.37	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT20) Mode 5700 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5702.8000	50.64	39.99	90.63	68.30	22.33	Peak	NO limit
2	5706.8000	46.24	40.00	86.24	999.00	-912.76	AVG	NO limit
3	5725.0000	21.96	40.05	62.01	68.30	-6.29	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT20) Mode 5700 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7597.9150	48.62	-2.27	46.35	74.00	-27.65	Peak	
2	7600.0100	38.36	-2.27	36.09	54.00	-17.91	AVG	
3 *	11398.3650	34.32	3.95	38.27	54.00	-15.73	AVG	
4	11399.1300	47.15	3.94	51.09	74.00	-22.91	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT40) Mode 5510 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5460.0000	21.05	39.46	60.51	74.00	-13.49	Peak	
2	5460.0000	5.30	39.46	44.76	54.00	-9.24	AVG	
3	5470.0000	20.43	39.47	59.90	68.30	-8.40	Peak	
4 *	5506.1000	47.59	39.52	87.11	68.30	18.81	Peak	NO limit
5	5508.1000	43.57	39.53	83.10	999.00	-915.90	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT40) Mode 5510 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7345.3320	50.40	-2.67	47.73	74.00	-26.27	Peak	
2	7346.8470	37.16	-2.67	34.49	54.00	-19.51	AVG	
3 *	11017.8150	34.49	4.38	38.87	54.00	-15.13	AVG	
4	11021.9100	48.01	4.37	52.38	74.00	-21.62	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT40) Mode 5510 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5460.0000	17.39	39.46	56.85	74.00	-17.15	Peak	
2	5460.0000	5.25	39.46	44.71	54.00	-9.29	AVG	
3	5470.0000	20.36	39.47	59.83	68.30	-8.47	Peak	
4	5506.9000	42.55	39.53	82.08	999.00	-916.92	AVG	NO limit
5 *	5507.4000	48.29	39.53	87.82	68.30	19.52	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT40) Mode 5510 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7346.5520	37.07	-2.67	34.40	54.00	-19.60	AVG	
2	7347.8170	49.76	-2.67	47.09	74.00	-26.91	Peak	
3 *	11017.5550	34.19	4.38	38.57	54.00	-15.43	AVG	
4	11018.6200	46.82	4.38	51.20	74.00	-22.80	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT40) Mode 5550 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5548.3000	52.55	39.62	92.17	68.30	23.87	Peak	NO limit
2	5554.5000	45.01	39.64	84.65	999.00	-914.35	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT40) Mode 5550 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7400.1750	36.50	-2.58	33.92	54.00	-20.08	AVG	
2	7400.8400	49.26	-2.57	46.69	74.00	-27.31	Peak	
3 *	11097.9750	34.61	4.29	38.90	54.00	-15.10	AVG	
4	11099.1849	47.06	4.29	51.35	74.00	-22.65	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT40) Mode 5550 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5560.6000	49.18	39.65	88.83	68.30	20.53	Peak	NO limit
2	5560.8000	42.24	39.65	81.89	999.00	-917.11	AVG	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT40) Mode 5550 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7399.1600	35.87	-2.58	33.29	54.00	-20.71	AVG	
2	7402.6000	49.01	-2.57	46.44	74.00	-27.56	Peak	
3	11097.8900	47.12	4.29	51.41	74.00	-22.59	Peak	
4 *	11098.6000	34.46	4.29	38.75	54.00	-15.25	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT40) Mode 5670 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1 *	5658.2000	47.74	39.89	87.63	68.30	19.33	Peak	NO limit
2	5666.6000	45.97	39.91	85.88	999.00	-913.12	AVG	NO limit
3	5725.0000	22.50	40.05	62.55	68.30	-5.75	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT40) Mode 5670 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7560.2050	38.81	-2.32	36.49	54.00	-17.51	AVG	
2	7561.0550	49.84	-2.32	47.52	74.00	-26.48	Peak	
3 *	11338.3000	34.37	4.01	38.38	54.00	-15.62	AVG	
4	11339.8400	46.83	4.01	50.84	74.00	-23.16	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT40) Mode 5670 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5659.0000	44.36	39.89	84.25	999.00	-914.75	AVG	NO limit
2 *	5662.1000	49.11	39.90	89.01	68.30	20.71	Peak	NO limit
3	5745.0000	21.38	40.09	61.47	68.30	-6.83	Peak	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT40) Mode 5670 MHz

Horizontal



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	7560.1700	38.23	-2.32	35.91	54.00	-18.09	AVG	
2	7560.6300	48.98	-2.32	46.66	74.00	-27.34	Peak	
3	11338.5550	47.13	4.01	51.14	74.00	-22.86	Peak	
4 *	11342.3300	34.33	4.01	38.34	54.00	-15.66	AVG	

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X
Test Mode	UNII-2C_TX AC (VHT80) Mode 5530 MHz

Vertical



No.	Freq.	Reading Level	Correct Factor	Measure ment	Limit	Margin		
	MHz	dBuV/m	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	5460.0000	19.24	39.46	58.70	74.00	-15.30	Peak	
2	5460.0000	5.24	39.46	44.70	54.00	-9.30	AVG	
3	5470.0000	18.27	39.47	57.74	68.30	-10.56	Peak	
4	5524.4000	38.17	39.57	77.74	999.00	-921.26	AVG	NO limit
5 *	5528.2000	42.97	39.58	82.55	68.30	14.25	Peak	NO limit

REMARKS:
(1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.