USER MANUAL

ĽK C € RoHS 卷 @







eVatmaster Consulting GmbH Bettinastr.30

60325 Frankfurt am main, Germany contact@evatmaster.com




EVATOST CONSULTING LTD Suite 11,First Floor,Moy Road Business

Centre, Taffs Well, Cardiff, Wales, CF15 7QR contact@evatmaster.com

OST_UK_20220715000002

Made in China



Technical parameters
Battery type. Polymer battery
Executive standard: GB 31241-2014
Capacity: 1200mAh
Mireless output: 2.5W(IWatch)
Size: 5014515m
Weight: 38.59

- Use the Type C charging cable to charge for power bank.
 It is recommended to connect the power adaptor to charge for power bank.
 It can be connected to the USE port of the computer to charge for power bank.
 While charging, the blue LED power indicator of the power bank blinks successively.
 When fully charged, the LED power indicator of the power bank is steady with blue color.

- Power bank is used to charge for digital products like iWatch.
 Put the Watch on power bank wireless charging area, then press the button to wait for 8 seconds, the power bank will be automatically charged for Watch.
 While charging for Watch, the LED power indicator lights up with blue color.
 After Watch is tully charged, the power bank will be antuited down automatically within 30 seconds after

- The charging time of this power bank is about 2-3 hours. The specific time is subject to the actual situation.
 If the power bank cannot be charged or the iMatch cannot be charged, please check whether the connection cable is normal and firm, or whether the charging port accessories are suitable. It is recommended to use a regular brand power adapter to charge for power bank.
 Thero is a conversion rate of power bank, so the capacity of power bank is not equal to the rechargeable.
- capacity.

 4. If the power bank cannot be turned on for short circuit protection due to improper operation, please charge

- Warning: Failure to follow these safety instructions may result in fire, electric shock, damage or other injury.
- Please try to keep the storage temperature of the product between 10-35°C.
 Do not fall, do not disassemble or puncture, repair the power bank by yourself.
 Do not expose the power bank to fire, high temperature or water.
- 4. Stop using the power bank if you find any abnormal phenomena such as expansion or expansion of the
- charged device.

 5. This device is not suitable for using by persons with immature physical, perceptual and mental abilities In its userice is not suitable for using by process with immutute physical, perceptional experience and ex

- Power bank *1
 Type C charging cable *1
 User manual *1

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference.
- (2)This device must accept any interference received, including interference that may
- (2)This device must accept any interference received, including interference that may cause undesired operation.

 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Initially the complex of the country of the

- Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an autlet on a circuit different from that to which the
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The devicecan be used in portable exposure condition without restriction.

