Specification

| Style:	Headset/over ear/on ear
BT Version:	V5.3
Audio range:	20Hz. -20KHz
Frequency Range:	2.402GHZ ~ 2.480
BT profiles :	HSP, HFP, A2DP, AVRCP
Emission range:	>15M
Music/Talk times:	About 10-15 hours
Charging times:	About 2-3 hours
Stand-by time:	About 1000 hours
Music player:	Stereo
Battery:	3. 7V/400mAh LiPO
FM audio:	87.5-108 0MHz
TF card input:	Micro sd 128M-32G
Audio formats:	MP3
Aux line in:	3.5mm socket
Speaker:	40mm/32Ω
Microphone:	42dB±3
SNR:	≥95dB
Working Temperature:	10-45 DEGREE
Producer:	Made in china

Safety Precautions

● Please do not split the headphones.
● Keep the device out of extreme heat and humid.
● Please do not overcharge. If don'tuse it for a long time, please. still to charge battery from time to time in order to protect it.
● Please wear the headsets correctly during use, and adjust the angle of the headsets in the pinna , to make it achieve : the best comfortable and sound quality.

User Manual
WIRELESS HEADPHONES

Operation chart

Prev/Vol-
Play /Pause/ Call
Next/Vol+ Mode change
PowerON/OFF
LED indicator light

Micro sd (TF) card
USB-Type-c
3.5mmAUX line in
Microphone

Charge the headphones :

When the power of the headset is low, Please charge it in time. And connect the charger correctly, The red light is always on during the charging process, and the red light is off when fully charged, Please take out the charger.

Operate

Power on/off:
Push the switch " ● OFF/ON " to turn the headset power on or off.

Pair and connection of headphones:
In the headset BT model, The red and blue led lights flash alternately, To turn on the BT switch of your mobile phone or other wireless device To find name and enter of the headset to be paired, Such as: "D-812" &"D-Headphone" & "D-812L" etc, Until the connection is successful.

Play / Pause:
After connecting the device, Click " ▶/┌ "to pause or play.

Increase volume:
Long press " V/▶▶ " to increase the volume.

Volume down:
Long press " ◀◀/V- " to decrease the volume.

Next/previous music:
Press the " ◀◀/V- " key once to switch to the previous song.
Press the " V/▶▶ " key once to switch to the next song.

Answer the phone:
When a call come in,Press " ▶/┌ " once to answer the call,
Press again end the call. Long press to reject the call.

FM mode:
In BT mode, Press " V/▶▶ " twice to switch to FM mode or exit,Then press the " ▶/┌ " button to search for FM stations, The LED light will flash, when the flashing stops, you can listen to more FM music, press" -V/▶▶ ◀◀/V " to switch FM stations.

Aux Line in:
Plese using in power off mode (switch push off),Save battery power.

Play from card:
Please insert the mp3 music micro sd card into the slot correctl,

Low latency game/Normal mode(or no) :
Please Press the " ▶/┌ " key 3 times to Change.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept Any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction