


60x100mm, 70g 书纸, 单黑, 单面印刷

Overview:

M17

Bluetooth Pairing:

1. Turn on the mouse. Flip the switch up to Bluetooth mode.

Press the Bluetooth button for at least 3 seconds to enter pairing mode.

The light indicator starts to flash quickly.

The mouse can be paired with the device within 120 seconds.

2. Turn on the Bluetooth of the device for search. Once the Bluetooth mouse and device are paired, the light will turn off in 3 seconds.



2.4G Connection:

1. Insert the 2.4G receiver into your PC's USB port.
2. Slide the mouse power switch downward to 2.4G mode for instant use.

USB port



LED Status:

1. Supports 3-level of DPI adjustment. 800/ 1200/ 1600. The DPI selection button blinks once for 800 DPI, twice for 1200 DPI and thrice for 1600 DPI.
2. The DPI selection button blinks for 60s when the battery is low.

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.