

Welcome to use Celink Sport

Please read all instructions carefully before using your Celink Sport.

1.Please log in to "Google Play", or "APP Store", search "Celink Sport" for download.




2.Scan the following QR code to download the APP directly.
*Applicable for both IOS and Android.



01


Quick Start Guide

Touch Operation



Scroll up and down to switch watch faces.

Touch Operation



Click the side button one time to return to the main interface.

02

Bracelet Activation

Before Using the APP and Sport, make sure your phone meets the following requirements:
IOS 9.0 and above and support Bluetooth 4.0,
Android 4.3 and above.

Strap on your Celink Sport, and begin a fashion journey.

Charging Activation:Please charge Sport with 5V output Charger to activate the bracelet.Turn on Bluetooth of the phone, and launch the App, Log in to your personal account with Email, We-chat, or QQ account.

After login, choose the matching bracelet model.

03

Pair Celink Sport

—Enable the phone's Bluetooth, turn on the bracelet.
—Flip to [More]-[About] Interface of the bracelet, you will read the Bracelet ID.



—Launch APP, find and select the matching Bracelet model.
—It will start to search, and bracelet ID will show up in the list for connection.
—Confirm the connection on the Bracelet Screen.



⌚ Activation:Single press the side button/when plugged into power source for charging.
🔒 Lock screen/back to last page:Single press the side button.

04



Support multiple sport modes: outdoor running, race walking and biking.



*Burn after reading"style notification management, more respectful to your privacy.




When connected with your smart phone, you can enjoy the simplified access to your music by music control function on your Sport.



Heart rate become visible now, improve awareness to your health and fitness condition.

05



When there is incoming calls, Sport will alert you by light vibration.



Sport will record your exercise achievements faithfully and sort them out to present clearly.

Steps Distance

Calories Heart rate

Multi-sport Mode Share

Goals setting Find phone

Time Alarm Alert

Notification Non-disturbance

Music control Camera control

Weather Watch faces

Restore settings

06

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Start GPS

Starting race walking, outdoor running, or biking on the Sport will automatically activate the GPS.



- ① Choose a sport mode;
- ②The GPS will start automatically and require a certain time for loading, please wait patiently for 1-2 minutes.
- ③ After the GPS starts successfully, enter the countdown state.
- ④ At the end of countdown, starts to record the exercise data.
- ⑤ Press right side button, enter the pause interface, you can select finish the exercise too.

* After the exercise, Sport will send the data to APP, which will generate routes map based on GPS information(as per right picture)

Remarks:GPS position is affected by the weather and surrounding buildings. If the positioning is unsuccessful, please re-enter sport mode and try again.

07

FAQs

The bracelet cannot be connected to the APP.

- ① Return the bracelet to the factory setting.
- ② Restart the phone
- ③ Switch the Bluetooth on.
- ④ Please check whether the bracelet is connected by other mobile phones. To disconnect IOS phone with Sport, in addition to unbind the Sport in the APP, you also have to ignore the "GPS Band 01" in the phone's Bluetooth setting.

The bracelet cannot control the phone's music play.

If the bracelet is connected to android phone,check whether the following three settings are normal:

- ① The Bluetooth of cell phone and bracelet need to be both enabled; and the APP and bracelet is in the connected state.
- ② Specify the default music player in the Apps Bracelet Settings-music control.
- ③ Due to compatibility issues of some music players, problems may happen that the bracelet could not display the song names or unable to control music play. (Such as QQ music)

If the iPhone is connected to the bracelet, check whether the following two settings are normal:

- ① The Bluetooth of your phone and your watch need to be enabled; and the watch is connected to the APP.
- ② The Bluetooth "GPS Band 01" of bracelet needs to be connected manually, when it connects with the Bluetooth of the phone for the first time, when you enter the "Music" interface of bracelet and shows "connecting", the Bluetooth of the phone can only search the "GPS Band 01"Bluetooth successfully.

08

Fail to answer or reject a call on the bracelet?

If the android phone is connected to the bracelet, Check if the authorization related calls for Sports APP in the software authorization management of the phone has been enabled or not.

If the iPhone is connected to the bracelet, check that the following settings are normal:

- ① Enable the notification function of the APP. If not,A message bar will POP up at the top of first Page, click the prompt, and then follow the guidance to enable notification. The SMS notification function of APP should be switched on.
- ② Setting-Notification-Type of notification-Both switches of "Notification Allowed" and "Display in Notification Centre"should be switched on. (If the phone system is IOS 9,SMS notification Settings cannot be checked for "no recent project")

Attention:If the phone system is IOS7 , you will fail to answer or reject a call via bracelet because of low system version.


09

Charging

- ① Put the bracelet on the specified charger
- ② Plug-in the USB connector for the charger into any power source with USB port, it takes 60-70 minutes to fully charge the battery.
- ③ It will vibrate to notify you when charging starts, charging interrupted or charging finished.
- ④ It will remind you to charge by vibration when battery is low.

How to wear the bracelet

Wear the bracelet one finger' width left to the Carpal bone, keep one finger space between the bracelet and the wrist for appropriate tightness, to guarantee the accurate reading of heat rate.



10

Display	Screen brand	PMOLED
	Screen size	0.96"
	Resolution	128*64
Device	Screen Control Mode	Touch Screen+Button(Support L/R wrist, bright screen)
	Bluetooth	BLE 4.2
	G sensor	3 Axis G Sensor
	Heart rate	YES
	Motor	YES
Battery	Button	Single press to return
	Battery	80mAh
charging time		70 minutes(Test by Celink)
Usage time		About 5 days (Test by Celink)
Standby time		About 45 days(Test by Celink)
Independent GPS		YES
GPS ON		About 3 Hours
Charger		Magnetic charging
Strap		Double color TPU
Strap Length		113mm*80mm(Bracelet body not-including)
Water-proof		IP67

11

Celink Sport

GPS Sport Band

User Manual

