

# **Allway Open Wireless Earphone**

## **PL20 Product Instructions**

Please read this instructions carefully and keep them properly



## ① Packaging list:



PL20

\*1



Storage bag \*1



Magnetic charging cable \*1



Product Brochure\*1

## ② Configuration

Product Name: Open Wireless Earphone

Product Model: PL20

Product Size: 125\*110\*45mm

Distance: >10m

Bluetooth Version: BT5.3

Speaker Diameter: 14.2mm

Impedance: 16  $\Omega$

Frequency Response: 20Hz-20KHz

Frequency Band: 2.400GHz-2.4835GHz

Battery: 100mAh

Charging time: 1.5h

Usage time: 7h

Standby time: 40h

Input: 5V=0.5A

Type of charge: Magnetic charging cable


Material: PC+ABS

Number of connections: 2

Weight: 19.3g

Specifications are laboratory test data.

\*Playback times are from Allway acoustic lab tests and may vary depending on equipment settings, environment, usage and many other factors.



- ①Touch area    ②Noise cancelling mic    ③Led    ④Sound drain hole    ⑤Sound output hole  
 ⑥Charging pin    ⑦Sound drain hole    ⑧Call mic    ⑨Multi-functional Button

### ③ Operation instruction

#### Power ON

- Short press the Multi-functional Button to power on.
- When the power is off, the Earphone will automatically turn on when charging.

#### Power OFF

- Long press Multi-function Button 3s to shut down.
- Automatic switch-off of the Earphone after a full charge.

- Automatic switch-off after 10min disconnection from Bluetooth.
- Automatic switch-off when the power is exhausted.

### **Pairing**

- Quickly press the Multi-function button twice to enter pairing mode.
- When there is no pairing record, automatically enter pairing mode after power on.
- when there is a pairing record, automatically connect back to the paired device after power on.

### **Reset**

- In the power on state, long press the Multi-function Button for 10s.

### **Multi-Device Connectivity**

- PL20 supports Multi-device connection: when the Earphone is in pairing, two devices can be connected at the same time; after pairing timeout, you need to re-enter pairing mode.

### **Bluetooth Pairing**

Step 1 - Turn on your device's Bluetooth and remove the Earphone



When the device is connected to the Earphone, the battery level of the Earphone is displayed.

Step 2 - Select "Allway PL20" to connect

## Operating Instructions



### Call Control

Answer/hang up/Cancel

Call: double touch

Reject: long touch 2s

### Music Control

Play/pause: two touches

next song: long touch 2s

### Volume Control

Volume up: single touch

Note: Different key functions can be customized through the App.

## Charging Instructions



### To Charge The Earphone:

Use the complimentary magnetic charging cable to charge the Earphone, at which point Bluetooth is automatically disconnected.

## Indicator Light Description

Power on

Blue light on for 2s



Power off

Red light on for 1s



Pairing status

Red and blue lights flashing alternately



Earphone charging in

Blue light slow flashing



Earphone is fully charged

Red light on for 1s



Restore factory settings

After the blue light is on for 2s, the red and blue lights flash alternately



## **Safety Information**

1. Never disassemble the earbuds. There are no user-serviceable parts inside,
2. Do not expose the earbuds to temperatures below 32 F(0 °C) or to temperatures above 113°F(45°C).
3. Do not use the earbuds in a thunderstorm. This could prevent the earbuds from working properly, and also increase your chance of being electrically shocked.
4. Do not use oil or any volatile liquid to clean this product.
5. Do not listen at high volumes for extended periods of time.
6. Do not use the earbuds in traffic.
7. Do not use the earbuds any time it would be dangerous to be unaware of noises around you.

## **Allway (1) Year Limited Warranty**

Allway warrants to the original retail purchaser that this product is to be free from defective materials and workmanship for a period of one year from the date of purchase, if it is properly used and maintained. If this product proves defective in either material or workmanship, Allway, at its option, will (a) repair the product, or (b) replace the product, at no charge for parts or labor. If the product model is no longer available and cannot be repaired effectively or replaced with an identical model, Allway at its sole option may replace the unit with a current model of equal or greater value. In some cases, modification to the mounting surface may be required where a new model is substituted. Allway assumes no responsibility or

liability for such modification. To obtain a repair or replacement under the terms of this warranty, please return to dealer first, if possible, and the dealer will direct you accordingly for repairs or replacement. You will be required to submit a copy of the original receipt.

Return shipping for exchanges/repairs is the sole responsibility of the original retail purchaser,

Limitations:

This limited warranty does not cover failure of the product resulting from improper installation, misuse, abuse, accident, neglect, mishandling, or wear from ordinary use or environmental deterioration.

This limited warranty does not cover cosmetic damage, including paint damage, or consequential damage to other components or premises which may result for any reason from the failure of the product.

This limited warranty is null and void for products not used in accordance with Allway's instructions.



**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.