

### Tuner True Wireless Bluetooth Earbuds

Instruction Manual | VWS-VWS-D10

**Product Parameters**

- Model: NBG
- Version: V.3
- Bluetooth profile: AVRCP/A2DP/HFP/HSP
- Audio codec: SBC/AAC
- Effective range: Within 10 m
- Bluetooth frequency band: 2402MHz-2480MHz
- Frequency range: 20Hz-20KHz
- Earbuds battery capacity: 30mAh/0.11Wh
- Earbuds rated input: 5V=30mA
- Charging case battery capacity: 300mAh/1.1Wh
- Charging case rated input: 5V=260mA
- Interface type of charging case: USB-C
- Shell: ABS

**Interface Instruction**

**1. Power on**

a. When you remove the earbuds from the charging case, the earbuds automatically power on.

b. When it is power off, hold the multi-function button for 3 seconds to power on. Within 10 seconds after the power on, it will search for the last connected device. If it fails to find, it will enter the pairing mode.

**2. Pairing and connection:**

① Earbuds are ready to pair right out of the charging case.

Note: If the pairing fails, please check whether the earbuds are fully charged and repeat the operation above. Or, change the function of the multi-function button to power off and restart your earbuds.

② Open the Bluetooth menu on your device. In the list of discovered Bluetooth devices, tap or click your Vention Tuner.

Note: For the first time pairing, please keep the pairing range within 1m. After the pairing is successful, earbuds automatically power off when placed back in the case with the lid closed, and you can use either earbud independently.

**3. Power off**

a: Auto power off

① Power off automatically after not connected for more than 5 minutes






② When the earbuds are not paired with the phone due to the long distance, it will automatically power off if it is not connected for more than 5 minutes

b: Manual power off




① Earbuds automatically power off when place back in the charging case.

② When it is connected, hold the multi-function button for 7 seconds and make sure the earbuds are not in use, and the earbuds will power off after the white light is on for 1 second.

**Packing list**



For more interesting information and events, please follow us on social media platforms:



Facebook      LinkedIn      Instagram

For warranty service or support, please contact Vention team:  
Website: [www.ventiontech.com](http://www.ventiontech.com)    Email: [vention@ventiontech.com](mailto:vention@ventiontech.com)

**4. Music mode:**

- Play: Press the multi-function button once (left or right)
- Pause: Press the multi-function button once (left or right)
- Skip backward: Press the multi-function button of the left earbud twice
- Skip forward: Press the multi-function button of the right earbud twice

Note: (Not support skip backward function when you use one earbud.)

**5. Phone mode:**

- Reject the call: Press the multi-function button for 2 seconds (left or right)
- Answer a call: Press the multi-function button once (left or right)
- End a call: Press the multi-function button once (left or right)

**6. Activate Siri voice assistant:**

When it is connected, press the multi-function button for 2 seconds (left or right) to activate your Siri voice assistant within your iOS settings

**7. Reset all settings:**

When the earbuds are power off (and turn off the device's Bluetooth function), hold down the multi-function button for about 5 seconds. The earbuds will activate the pairing mode (white lights blink), and then quickly tap the multi-function button for 4 times. After the white light is on for 1 second, the earbuds have been reset all the pairing data.

**8. Charging case indicator description:**

The green light will stay blinking while the charging case is charging, and will stay on when it is fully charged.

**Important Safety Instructions**

Please read all instructions and warnings before using this product. Inappropriate use will cause damage to the product or personal safety.

- Do not expose products containing batteries to excessive heat [e.g. from storage in direct sunlight, fire or the like]; do not store this product in high temperature, strong light and strong magnetic field environment, do not place in other harsh environment such as fire source. If your earbuds ever goes into water, please dry it naturally before using.
- Improper use of the product can easily cause product damage or may endanger personal and property safety.
- If consumers violate the product instructions and use them improperly, the company will not bear any consequences or legal liability for personal and property damage.
- Non-professionals are strictly forbidden to disassemble this product.
- Use this product only with an agency-approved power supply that meets local regulatory requirements.

**Declaration on toxic or hazardous substances and elements contained in electronic products**

Parts name	Toxic or Hazardous Substances or Elements					
	CAD (Pb)	Heavy metal (Cd)	Cadmium (Cd)	Hexavalent chromium (CrVI)	Polychlorinated biphenyls (PCB)	Polybrominated diphenyl ethers (PBDE)
PCB/s	X	○	○	○	○	○
Ceramic Parts	X	○	○	○	○	○
IC Parts	X	○	○	○	○	○
Charging Cable	○	○	○	○	○	○
Casing	○	○	○	○	○	○

This table is prepared in accordance with the provisions of SJ/T 11364.  
○ Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572.  
X Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement of GB/T 26572.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2A724-NBG

折叠尺寸:70x90mm    展开尺寸:90x280mm

材质:157g哑粉纸    风琴折

蓝色印刷    C: 100    M: 0    Y: 0    K: 0    参考 : Pantone Process Cyan C

宁波福茂通讯科技有限公司 NINGBO FULMAN COMMUNICATION TECHNOLOGY CO., LTD					
品名 PART NAME	NBG系列 Tuner TWS真无线蓝牙耳机-说明书			型号 PART MODEL	VWS-D10
设计 DESIGNER	李红梅	单位 UNIT	mm	客户代码 Client NO.	
校对 CHECK		版本 REV	A1	图号 DWG. NO.	
核准 APPR.		PAGE 页数	1/1	更新 UPDATE	2022/11/02