


User Guide

Door/Window Sensor



THANK YOU

We appreciate the trust and confidence you have placed in Defiant through the purchase of this Door/window sensor . We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Defiant!

Safety information


⚠ WARNING: Keep batteries away from children at all times. This product contains a coin/button style cell battery and, if swallowed, can cause severe internal burns within 2 hours of ingesting and can lead to death. Keep away from infants and small children at all times. If battery is swallowed or comes in contact with the inside of the body, immediately seek emergency medical attention. If the battery is replaced by an incorrect size, there is a risk of the battery erupting and causing injury. Dispose of used battery promptly, when it has been removed.

⚠ CHOKING HAZARD: Keep batteries and any small parts away from infants and small children at all times. This item is not a toy and should not be given to children.

⚠ IMPORTANT: Do not expose to wet conditions. Periodically check the condition and security of the batteries.

⚠ CAUTION: Correct disposal of batteries. In the US, each state has their own recycling regulations. To find out what your state provides and requires for battery disposal, both Earth911 and Call2Recycle offer online resources to help. Earth911 has an accurate Recycling Locator for all types of batteries; simply enter your ZIP code to find the nearest battery recycling center. Call2Recycle offers a network of local recycling centers and drop-off locations for rechargeable batteries, including local municipalities and national retailers such as The Home Depot.

Package contents




Door/window sensor *2



Screws*4



Reset pin * 1



Bracket *1



User guide*1

Quick Start Guide

This Door/Window Sensor only works when paired together with a Defiant hub.

iOS App Android App

Step 1:

Get the SMART HOME App for Android or iOS. Please scan below QR code to download and install the app.




Step 2:

Create an account and sign in the app.

Step 3:

Tap '+' button to add this sensor




Step 4:

Follow the instruction of the app to set up this door window sensor.

Product Introduction

Get real-time security alerts whenever a door or window opens with the Door/Window Sensor.



Indicator: If sensor has not been added to gateway, the LED will be blinking about once per second. The LED will be turned off after connecting the gateway.

Reset pin hole switch : **Press and hold** the pinhole switch for 3 seconds then release to reset the sensor. Sensor can be found if app/gateway is in pairing mode.

Tamper switch: When the sensor is removed from the bracket, it can trigger the anti-tamper switch to report tamper notification. Please be sure that the sensor is well mounted on the bracket to avoid an anti-tamper notification.

Installation


IMPORTANT:

- The distance between sensor and magnet must not exceed 0.8 inch in closed state.
- This sensor should not be mounted on a metal frame
- This sensor should only be installed indoors


Step 1: The door/window sensor can be mounted on a door or window.



Step 2: Fix the bracket to door or window with either screws or adhesive tape for different surfaces.



Step 3: Hang the sensor on the bracket, and affix the magnet to the door or window.



Operation

This Sensor needs working together with Defiant HUB.

- Make sure you have already set up the hub, and it is working normally.
- Remove the isolating plastic sheet from sensor battery cabinet.
- Press and hold the pin hole switch for 3 seconds to reset the sensor.
- Press “+” button in the App and following the guide in App adding a sensor.
- The sensor will be in pairing status. This will cause a LED indicator to flash once per second. If sensor enrolled successfully, LED will stop blinking and stay on for 10 seconds and then turn off

Trouble Shooting

Problem	Solution
Sensors are listed as offline in the app after installation.	they may be too far from Siren Hub. You can try to put them closer to the Siren Hub.
Sensor doesn't work caused by battery no power.	Make sure the battery has power and it is installed with the “+” side facing up to battery cover. Replace the battery if needed.
False anti-tamper alarm	Please make sensor well-mounted on the bracket to avoid false anti-tamper alarm.

To learn more, visit us at www.HOMEDEPOT.com/support

Maintenance

Battery replacement

The app will notify you when a device' battery gets low. To replace the battery, please disarm the system first to avoid unintended tamper alarm.

Reset to factory Settings

Press and hold the pin hole switch about 3 seconds, then the LED indicator will start blinking quickly. Once release the key, the sensor will reset to factory setting and the LED indicator blinks once per second to search a new enabled Zigbee network.

Check for updates

All devices in the system will automatically update its software, but you can manually check for updates if you want.

Changing the Batteries

The app will notify you when a device' battery gets low. To replace the battery, please disarm the system first to avoid unintended tamper alarm.

Step 1: Disarm the system.


Step 2: Remove the door/window sensor from the bracket.

Step 3: Loosen the screw on the battery cover. Open the battery cover.

Step 4: Remove the old battery and replace with new CR2032 battery.

Step 5: Close the battery cover. Fix the screw for the battery cover.

Step 6: Hang the door/window sensor on the bracket.



Compliance Information

FCC ID: 2AB2Q8ASSZEHO

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution:

Changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Statement:

"This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

Warranty

1 YEAR LIMITED WARRANTY

This product is guaranteed to be free of defects in materials and workmanship for 1 year from the date of purchase.

Guarantee does not include normal wear and tear, bulbs or batteries.

Contact the Customer Service Team or visit www.HOMEDEPOT.com.

Wireless protocol: ZigBee 3.0

This device is fully ZigBee 3.0 certified and will work with other open ZigBee 3.0 certified systems.



Questions, problems, missing parts? Before returning to the store, call Defiant Customer Service

M-F 9am-6pm PST

[1-888-XXXX-XXXX](tel:1-888-XXXX-XXXX)

HOMEDEPOT.COM