



**Endless Series**  
Magnetic wireless charging mobile power bank

### INTRODUCTION TO THE MANUAL

Thank you for choosing our portable power bank. This manual is designed to help you understand and safely use your new device. Please read the following instructions carefully before use to ensure optimal performance and longevity of your power bank.


### KEY HIGHLIGHTS

High Capacity: 10000mAh( 37 Wh)for extended usage.  
Fast Charging: Supports multiple input/output options for efficient charging.  
Wireless Charging: Compatible with 5W, 7.5W, 10W, and 15W devices.  
Compact Design: Slim and portable, measuring 109 × 69 × 22.4 mm.


### PRODUCT PARAMETERS

Series:	Endless
Model Number:	SJ-0030
Capacity:	10000mAh(37 Wh)
Type-C Input:	5V ≡ 3A, 9V ≡ 2A
Type-C Output:	5V ≡ 3A, 9V ≡ 2.22A, 12V ≡ 1.67A
Wireless Charge:	5W / 7.5W / 10W / 15W
Size:	109*69*22.4mm
Items Included:	1.Portable Power Bank*1 2.Type-C Charging Cable*1 3.Instruction Manual*1

### INTRODUCTION TO OPERATIONAL FUNCTIONS



- 1.The power input interface charges the portable power bank via Type-C.
- 2.The power output interface connects to other devices using a Lightning Cable, Type-C Cable, or wireless output.



### IMPORTANT SAFETY PRECAUTIONS

Before using the power bank, please carefully read and adhere to the following guidelines:

- 1. Initial Use or Long-Term Storage:** If the power bank is used for the first time or has been stored for an extended period, it may have self-discharged. Ensure it is fully charged before use. Optimal performance is achieved after 2-3 full charge and discharge cycles during initial use.
- 2. Use Approved Accessories:** Only use the designated charger, charging cables, and adapters provided or approved by the manufacturer. Unauthorized accessories may damage both the power bank and your electronic devices.
- 3. Charging Environment:** Charge the power bank in a well-ventilated area. Extreme temperatures (too high or too low) can negatively impact its performance.
- 4. Avoid Water and Moisture:** Do not expose the power bank to water, moisture, or rain, as this may cause damage.
- 5. Handle with Care:** Avoid dropping, hitting, shaking, or subjecting the power bank to strong impacts, as this may damage its internal components.
- 6. Storage:** Store the power bank and its accessories in a safe place, out of reach of children.
- 7. Heat Generation:** Slight heat generation during charging is normal. However, avoid placing the power bank near fire or other heat sources to prevent potential hazards.
- 8. Avoid Metal Contact:** Prevent metal objects from coming into contact with the charging and discharging ports to avoid short circuits and damage.
- 9. No Unauthorized Repairs:** Do not attempt to modify or repair the power bank yourself. Unauthorized repairs may void the warranty and render the product unusable.
- 10. Comply with Local Regulations:** Use the power bank in accordance with local laws and regulations. Avoid using it during aircraft takeoff and landing, or near medical equipment, to prevent interference.

CE FCC RoHS REACH  
Made in China

### FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
This device may not cause harmful interference.  
This device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception (which can be determined by turning the equipment off and on), the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Note:** The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

This device has been evaluated to meet general RF exposure requirements. The equipment complies with the FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.