




Model:CS20

USER MANUAL



Please read this user manual carefully and keep it for further reference.

Product Description



1.Volume Knob

Volume +: Clockwise Rotation Volume -: Counter-clockwise Rotation

2.Lighting Button:

①One Click: Change Lighting

Lighting-1: Rainbow Color Cycle Lighting-2: Single Color Changing

Lighting-3: Single Color Pulsing & Changing

Lighting-4: Choose One Solid Color

Lighting-5: Lighting Off

②Press for 3 Seconds: Wipe Off & Reset Bluetooth Connection

3.Mode Button

- ①One Click: Switch BT/USB Input Mode
- ②Press for 3 Seconds: Power On/Off

How to Setup

PC, Laptops, Macbook Pro/Air



- 1.Plug USB cable into USB side ports on devices;
- 2. Click "Mode" button to switch to "USB Mode";
- 3. Fix the settings: control panel/system preference sound settings - choose SENZER CS20 as audio output - save changes.
- 4. Device volume set to max., speakers volume adjust to proper level

How to Setup

Cellphones, iPad (Bluetooth Mode)



- 1.Plug the USB connector into a certified USB power supply (5V/1A); 2.Click the "MODE" button to switch Bluetooth mode;
- 3. Turn On Bluetooth on your cellphones, search and select device name "SENZER CS20", connect it and pair.

Notes:

If CS20 were paired with some other devices, and not able to pair now, please press the RGB Lighting button for 3 seconds to wipe off the bluetooth connection, and pair the SENZER CS20 with your devices via Bluetooth again.

Specifications

Audio Input:	Bluetooth/USB Input Mode
Bluetooth Version:	V5.3
Bluetooth Working Distance:	≤33ft/10 meter
Connector:	USB-A Type
Output Power:	5W*2
Speaker Size:	2.5inch*2
Speaker Impedance:	4Ω
Frequency Range:	150Hz~20KHz
Power Supply:	USB 5V/1A~2A (Not Included)

Customer Service

MANUFACTURER

Shenzhen Xuli Network Technology Co., Ltd. Add: 102, Buliding 8, Minle Industrial Park, Meiban Ave., Longhua New Dist., Shenzhen, China

Web: www.senzer.net Email: support@senzer.net
Facebook: www.facebook.com/senzer.official

(R) 6-Month Warranty Services

Lifetime Technical Support



Featured Items from SENZER

SENZER CS30

Computer Speaker Bar With Only USB Cable: USB Input/Bluetooth Mode Varied RGB Lighting With Dual Diaphragms for Supurb Sound



SENZER X100

Wireless Bluetooth Gaming Headset Immersive In-Game Sound Ultra-Comfortable Fit Clear Microphone



SENZER SG500

Stereo Sound Gaming Headset with 3.5mm Connecto Various Color Options Available Clear & Loud Microphone Soft Ear Padding for Comfortable



FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.