


User Manual

Multi-function UVC LED Sterilizer (Wireless Charging)

Please read this instruction guide carefully before using the product, and keep it safe

Product Overview




- ❶ Wireless charging output
- ❷ ON/OFF button
- ❸ Type-C input

Package Content



Multi-function UVC LED
sterilizer x1



TYPE-C power
cable x1



User manual x1

Technical Specification

Model: XW01

Input Voltage: 5V/2A 9V/2A

Rated Power: 18W

Wireless Output: 5W 7.5W 10W 15W

Ultraviolet Wavelength: 260-280nm

UVC light lifetime: 10000H

UVC lights: 4mW*3

Sensing Distance of Wireless Charging: ≤ 8 mm

Material: PC + Silica Gel

Item Weight: 240g(Wireless Charging)

Instructions

1. Open the package and take the UVC sterilizer out, pull up the lid to open it.
2. Please utilize the TYPE-C cable to connect the device to the power. When it's connected, the circle around the button will turn red.
3. Open the lid of the sterilizer, put the items to be disinfected into the box, then close the lid. The product should be well placed on the surface.
4. After pressing the power button the device will automatically start. The circle around the button will turn green, which shows the disinfection is proceeding normally. After 1 mins, the button will turn red again, to indicate the end of the disinfection process.
5. Open the lid and take out the sterilized items.
6. As for the wireless charging function, smartphones should be placed on the upper surface of the box to start the charging process.

Notes

1. To ensure a correct and safe usage of the UVC Sterilizer, please read the user guide carefully.
2. Do not put any liquid or food into the disinfection box.
3. Do not put the sterilizer into water or wash it with water. Otherwise, it could cause a short circuit.
4. Direct exposure of high intensity UVC lights to human body may cause skin allergies, damage to the eyes or other symptoms. During the disinfection, if the sterilizer is tilted, the UV light will automatically turn off, so as to keep users safe. After being well placed, the POWER button should be pressed again, so that the device can restart.
5. If you do not intend to use the device for a long period of time, please unplug the power cable and press the lid, let it shrink completely, for a better preservation.
6. If the UVC light is defective, please contact the hot line or email the technical assistance for a replacement.
7. Keep the sterilizer away from any damp or wet place.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.