



SAMBA65S**Quick Starter Guide****Quick starter guide**

Device location diagram
To turn on the device, press the switch button for 2-3 seconds.

**Battery Charging**

Batteries must be charged before they are first used.
When charging, the charger should be close to the power socket and easy to unplug.

**Insert card description**

This device uses standard 2 Nano-SIM Cards and 1 TF Card. If you need to replace or purchase SIM cards, please contact the network operator. Insert the needle into the small hole on the SIM card tray and pop up the card tray. Please insert the SIM card as shown in the picture.

This will prevent the phone from being recognized or causing damage to the card slot. In case the phone cannot be recognized or the card slot is damaged. In order to avoid the cell phone can not identify or cause damage to the card slot.

The above situation is a single channel feature of the mobile phone, which can significantly reduce power consumption, improve standby time, and has nothing to do with the network status of operators.

If other types of accessories are used, it may violate the warranty terms of the device and relevant provisions of the country where the device is located, and may lead to safety accidents.

For approved accessories, please contact the authorized service center.

In order to prevent possible hearing damage, do not use high volume for a long time.

Please use the device in the temperature range of 0 °C-35 °C, and store the device and accessories in the temperature range of -20 °C-45 °C. When the ambient temperature is too high or too low, it may cause device failure.

Do not expose the device and batteries to high temperature or

heating device, such as sunshine, heater, microwave oven, oven or water heater. Overheating of the battery may cause an explosion.

! Do not flashing by yourself

If the user adds the third-party ROM system or modifies the system files by cracking, the system maybe unstable and may bring security risks and threats. IPRO will not be responsible for these situations.

Please dispose the equipment, batteries and other accessories according to local regulations and do not treat them as domestic waste disposal. Batteries may explode if improperly disposed of.

Dual Sim dual standby

According to your mood of dual sim dual standby management, work and life are great.

In the setting interface, click SIM card management, select 3G card slot settings according to needs, and easily switch 3G networks

Dual card dual standby single channel instructions

Your mobile phone adopts the design of "dual sim dual standby" and the two cards inserted into the phone can't use voice services or data services at the same time

When one of the cards is on a call, the other card can't answer the phone. If someone just dials another card at the moment, you may hear voice prompts such as "the number you dialed is not in service area". The user you dialed can't be connected temporarily, please dial later".

When one of the cards is using data services, the data services of the other card can't be used.

For approved accessories, please contact the authorized service center.

In order to prevent possible hearing damage, do not use high

volume for a long time.

Please use the device in the temperature range of 0 °C-35 °C,

and store the device and accessories in the temperature range of -20 °C-45 °C. When the ambient temperature is too high or

too low, it may cause device failure.

Do not expose the device and batteries to high temperature or

heating device, such as sunshine, heater, microwave oven,

oven or water heater. Overheating of the battery may cause an

explosion.

! Do not flashing by yourself

If the user adds the third-party ROM system or modifies the

system files by cracking, the system maybe unstable and may

bring security risks and threats. IPRO will not be responsible

for these situations.

Please dispose the equipment, batteries and other accessories

according to local regulations and do not treat them as

domestic waste disposal. Batteries may explode if improperly

disposed of.

station antenna, the lower the power output.

Before a new model phone is available for sale to

the public, it must be tested and certified to the FCC

that it does not exceed the exposure limit established

by the FCC. Tests for each phone are performed in

positions and locations (e.g. at the ear and worn on

the body) as required by the FCC.

For body worn operation, this mobile phone has been

tested and meets the FCC RF exposure guidelines

when used with an accessory designated for this

product or when used with an accessory that contains

no metal and that positions the handset a minimum

of 1.0cm from the body.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference,

and (2) this device must accept any interference

received, including interference that may cause

undesired operation. Any changes or modifications

not expressly approved by the party responsible for

compliance could void the user's authority to operate

the equipment.

Note: This equipment has been tested and found to

comply with the limits for a Class B digital device.

pursuant to part 15 of the FCC Rules. These limits

are designed to provide reasonable protection

against harmful interference in a residential

installation. This equipment generates uses and can

radiate radio frequency energy and, if not installed

and used in accordance with the instructions, may

cause harmful interference to radio communications.

However, there is no guarantee that interference will

not occur in a particular installation. If this equipment

does cause harmful interference to radio or television

reception, which can be determined by turning the

equipment off and on, the user is encouraged to try to

correct the interference by one or more of the

following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment

- and receiver.

- Connect the equipment into an outlet on a circuit

- different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV

- technician for help.

the cell broadcast

Enter Message menu to view Broadcast list

The purpose of cell broadcasting is to inform mobile

phone users of the danger, such as serious threats,

child abduction and so on, through some alerts issued

by operators, the function is activated by default.