



Magnetic Selfie Stick
Tripod Stand

Magnetic Selfie Stick
Tripod Stand


User Manual Manual del usuario

Connecting / Bluetooth Pairing

1. Make sure the PureGear Magnetic Selfie Stick Tripod Stand remote is within 2-3 ft (0.6-0.9m) of the device you will be connecting to.
2. Turn on your device's Bluetooth. Most devices will automatically detect your PureGear Magnetic Selfie Stick Tripod Stand remote. Locate and select "**PG Selfie Stick**". If your device does not automatically detect your remote, make sure Bluetooth is turned on, do a **SEARCH** for "**PG Selfie Stick**" and then click **CONNECT**.

Operating the PureGear Magnetic Selfie Stick Tripod Stand

1. Lift up the bracket.



Connecting / Bluetooth Pairing


1. Make sure the PureGear Magnetic Selfie Stick Tripod Stand remote is within 2-3 ft (0.6-0.9m) of the device you will be connecting to.
2. Turn on your device's Bluetooth. Most devices will automatically detect your PureGear Magnetic Selfie Stick Tripod Stand remote. Locate and select "**PureGear Selfie Stick**". If your device does not automatically detect your remote, make sure Bluetooth is turned on, do a **SEARCH** for "**PureGear Selfie Stick**" and then click **CONNECT**.

Operating the PureGear Magnetic Selfie Stick Tripod Stand


1. Lift up the bracket.




2. For non-MagSafe phones, insert mobile phone into silicone holder.




3. For MagSafe phones, remove the silicone phone holder and attach directly to the magnetic ring.



4. To use tripod, open the base and extend the telescoping neck to the desired position.



Note: If the support does not close completely, please press the upper area with your fingers to close.




2. For non-MagSafe phones, insert mobile phone into silicone holder.



3. For MagSafe phones, remove the silicone phone holder and attach directly to the magnetic ring.



4. To use tripod, open the base and extend the telescoping neck to the desired position.



Note: If the support does not close completely, please press the upper area with your fingers to close.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference,
(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: YJW-11139PG

FCC ID: YJW-11139PG

Sin embargo, no se garantiza que dicha interferencia no ocurrirá en una instalación específica.

Si este equipo genera interferencia perjudicial en la recepción de radio o televisión, lo cual se puede determinar apagando y encendiendo el equipo, se sugiere que el usuario intente corregir la interferencia mediante una o más de las siguientes medidas:

- Mover o reorientar la antena receptora.
- Aumentar la separación entre el equipo y el receptor.
- Conectar el equipo a una salida o circuito distinto al que está conectado el receptor.
- Consultar al proveedor o a un técnico de radio o televisión con experiencia para que le ayuden.

El dispositivo ha sido evaluado para que cumpla con los requisitos generales de exposición a RF. El dispositivo se puede usar en condiciones de exposición portátil sin restricciones.



PUREGEAR®

pure-gear.com