

Size: 8.25”L x 5.75”H

Front

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.
- This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.
- FCC RF Radiation Exposure Statement Caution: To maintain compliance with the FCC's RF exposure guidelines, place the product at least 20cm from nearby persons.

This product is meant for use only in conjunction with a suitable device. Please consult your device packaging to determine whether this product is compatible with your particular device. Manufacturer is not responsible for any damages to any device or personal property incurred through the use of this product. Manufacturer shall in no way be liable to you or to any third party for any damages you or any third party may suffer as a result of use, intended or unintended, or misuse of this product in conjunction with any device or accessory other than the compatible device for which this product is designed or intended. Manufacturer will not be responsible for any damages you or any third party may suffer as a result of misuse of this product as outlined above. Samsung and Galaxy S are both registered trademarks of Samsung Electronics Co., Ltd. Apple and iPhone are trademarks of Apple Inc. Qi is a trademark of the Wireless Power Consortium.

SHARPER IMAGE® NAME AND LOGOS (INCLUDING THE 77 LOGO AND TOMORROW'S TOMORROW) ARE TRADEMARKS OR REGISTERED TRADEMARKS. DISTRIBUTED BY AND © 2020 MERCHSOURCE, LLC. IRVINE, CA 92618. ALL RIGHTS RESERVED. FOR TECHNICAL SUPPORT, PLEASE CALL 1-800-374-2744 PRINTED IN CHINA



SHARPER IMAGE®

WIRELESS CHARGING PAD

CONTENTS

- 1 Wireless Charging Pad
- 1 Micro USB Cable

SPECIFICATIONS

- Model: 1014041
- Input Power: DC 5V 2A (Max)
- Output Power: 5W
- Wireless Charging Version: Qi 1.2.4

COMPATIBLE WITH

- Apple iPhone 8 and newer and select Android smartphones
- Qi wireless technology enabled devices
- Non-metal phone cases up to 3mm thick


SAFETY WARNINGS: PLEASE READ BEFORE USE.

- Not a children's item. Keep out of reach of children.
- Use this item only for its intended purpose.
- For indoor use only.
- Do not expose to sunlight for extended periods of time.
- Do not expose to extreme temperatures or moisture.
- Thoroughly inspect products before every use. If the product appears worn, frayed / splintered, cracked, or broken in any manner, discontinue use and discard immediately.


CHARGING YOUR DEVICE

1. Connect the supplied Micro USB cable to the Wireless Charging Pad's input port and then connect it to a USB-A adapter (2 amps).


Note: Charging speeds will decrease if USB cable is plugged into an adapter or plug that is rated under 2 amps.



2. Remove any phone accessories. A non-metal phone case up to 3mm thick can be used.



3. Place your device on top of the pad, lining up the center of your device to the center of the charging pad.



4. The LED will light up when your device begins to charge.

