

Important safety instruction

- Please read the instructions carefully. Keep it in safe place for future reference.
- Use only accessories approved by the manufacturer.
- Install the instrument properly by following the instructions in the device connection section.
- Using the product in a 0-35°C environment is recommended. Shipping and storing the product in a 0-35°C environment is recommended.
- To reduce the risk of fire and electric shock, do not expose the product to rain or moisture.
- Do not use this product near water. Do not immerge the product into any liquid or have it exposed to dripping or splashing.
- Do not install or use this product near any heat source (e.g. radiator, heater, stove, or other devices that generate heat).
- Do not place any object filled with liquids, such as vases on the product; neither should any open fire, such as lighted candles be placed on the product.
- Do not block any ventilation openings. Do not insert any object into ventilation openings or slots. It may cause fire or electric shock.
- Keep sufficient clearance around the product to maintain good ventilation (minimum 5cm is recommended).
- Do not force a plug into the jack. Before connection, check for blockage in the jack and whether the plug matches the jack and is oriented to the right direction.
- Keep the provided accessories and parts (such as screws) away from children to prevent from being swallowed by mistake.
- Do not open or remove the housing yourself. It may expose you to dangerous voltage or other hazardous risks. Regardless the cause of damage (such as damaged wire or plug, exposure to liquid splash or foreign object falling in, exposure to rain or moisture, product not working or being dropped, etc.), the repair has to be performed by an authorized service professional immediately.
- Before cleaning the product with dry cloth, always turn off the product and disconnect the power plug first.
- Never use strong acid, alkali, gasoline, alcohol, or other chemical solvents to clean the product surface. Use only neutral solvent or clear water for cleaning.
- The product must be used at an altitude of lower than 2000m.



Excessively loud music may lead to hearing loss. Please keep the volume in a safe range.



Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

- For wireless product:
1. Wireless product may generate shortwave radio frequencies and interfere with the normal use of other electronic devices or medical equipment.
  2. Turn off the product when it's disallowed. Do not use the product in medical facilities, on airplane, at gas stations, near automatic gates, automatic fire alarm system or other automated devices.
  3. Do not use the product in the vicinity of a pacemaker within a 20cm range. The radio waves may affect the normal operation of the pacemaker or other medical devices.



This symbol is to alert the user to the presence of un-insulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is to warn the user not to disassemble the enclosure of the product and there is no user-replaceable part inside. Take the product to an authorized service center for repair.




This symbol indicates that the product is for indoor use only.



This symbol indicates that the product is a CLASS II or double insulated electrical device with no earth requirement.



The MAINS plug is used as the disconnect device, the disconnect device shall remain readily operable.

Product Description and Accessories



- ① Power switch
- ② Power cable
- ③ Bass adjustment
- ④ Connect to satellite speaker
- ⑤ AUX input
- ⑥ USB audio streaming input
- ⑦ Connect to active speaker
- ⑧ Connect to subwoofer
- ⑨ Connect to passive speaker

- ⑩ Indicator light
- ⑪ Power on/off
- ⑫ Volume up
- ⑬ Volume down
- ⑭ Multi-function "G" button




Note: Images are for illustrative purposes only and may differ from the actual product.



Power Connection

- Connect the subwoofer cable to the speaker.
- Connect the power cable to the AC outlet (100-240V~50/60Hz).
- Turn on the power switch and the speaker is power on.



Audio Input


Bluetooth input

- Press the "⓪" button to switch to Bluetooth mode, blue LED will blink.
- Select "HECATE G1500 MAX" in your device setting to connect.
- Blue LED will be solid when connected.




AUX input

- Press the "⓪" button to switch to AUX mode.
- Connect the speaker to audio sources using the AUX audio cable.
- Green LED indicates AUX mode.




USB audio streaming input

- Press the "⓪" button to switch to USB audio streaming mode.
- Connect the speaker to audio sources using the USB audio cable.
- Red LED indicates USB mode.



Controls

- ⓪ x1 Input mode switch  
USB/AUX/Bluetooth
- ⓪ x2s Power on/off
- + x2 Disconnect Bluetooth
- + x1 Volume up
- + x2s Volume up gradually
- x1 Volume down
- x2s Volume down gradually
- G x1 Sound mode switch  
Music/Game/Movie
- G x2 Light effects switch
- G x2s Light effects on/off



Specifications

Power output: R/L(mid-treble): 7.5W+7.5W  
SW(bass): 15W  
Signal to noise ratio: R/L(mid-treble): ≥80dB(A)  
SW(bass): ≥85dB  
Frequency response: 60Hz-20KHz  
Distortion: ≤7%

Declaration for EU  
Frequency Band: 2.402GHz ~ 2.480GHz  
RF Power output: ≤13 dBm (EIRP)  
There is no restriction of use.

Troubleshooting

No sound

- Check if the speaker is ON.
- Turn up the volume by using the volume control.
- Ensure the audio cables are firmly connected and the input is set correctly on the speakers.
- Check if there is a signal output from the audio source

Cannot connect via Bluetooth

- Make sure the speaker is switched to Bluetooth input. If it is in other audio input modes, Bluetooth will not connect. Disconnect from any Bluetooth device by pressing the "⓪" button twice, then try again.
- Effective Bluetooth transmission range is 10 meters; please ensure that operation is within the range.
- Try another Bluetooth device for connection.

The G1500 MAX does not turn on

- Check if USB power cable is connected.

Noise coming from speakers

EDIFIER speakers generate little noise, while the background noise of some audio devices may be too high. Please unplug audio cables and turn the volume up, if no sound can be heard at 1 meter away from the speaker, then there is no defect.

To learn more about EDIFIER, please visit [www.edifier.com](http://www.edifier.com)  
For Edifier warranty questions, please visit the relevant country page on [www.edifier.com](http://www.edifier.com) and review the section titled Warranty Terms.  
USA and Canada: <https://support.edifier-online.com/hc/en-us>  
South America: Please visit [www.edifier.com](http://www.edifier.com) (English) or [www.edifierla.com](http://www.edifierla.com) (Spanish/Portuguese) for local contact information.

G1500MAX 桌面2.1游戏音箱V1.0版

尺寸：80x125mm（折后）

材质：80g书纸

工艺：风琴折，双面印刷，封面黑色印刷，其他页80%灰

